

Flexible combination without piping or problems!

New Product


Air unit CXU Series

AIR UNIT CXU SERIES



CKD Corporation cc-901A 5

New-Generation Pneumatic Unit



The air unit CXU series modularizes and joins the wide variety of air components indispensable for pneumatic control and actuator drives between filters or regulators and valves. This series dramatically reduces conventional design and piping labor hours.




配管不要・手間要らず

Piping-versatile, space-saving

Bothersome piping design and work have been eliminated. All work is completed by preparing a single unit. Installation space is also reduced with the elimination of piping and tubes.

This also makes for a neater appearance.

Mounting positions for separate components are eliminated, and errors in mounting dimensions caused when pipes are tightened are solved.



Improved quality

No threading sections, no external leaks!

This also prevents foreign materials from entering during piping work.



Vertical or horizontal


Vertical and horizontal pipes can be arranged versatilely. Solenoid valves can also be connected directly. The simple layout greatly reduces piping design labor hours. (AIR UNIT custom order parts)



Easy change and expansion

Module joining lets air components be changed and expanded freely. Components can be attached and removed from the front face. This also facilitates maintenance. Example of major applications





Assembled delivery

Valve air unit (model no. for manifold)

		Series		
Model	Model no.	1000	2000 3000 4000	Page
2 port direct acting solenoid valve	CXU10-GEXA NEW	•		2
5 port pilot operated valve	CXU30-M4G2		•	6

Air unit (model no. for discrete part)

		Series		
Model	Model no.	1000	2000 1000 3000 4000	
	CXU10-EXA NEW	•		14
2 port direct acting solenoid valve	CXU10-FAB3	•		16
	CXU30-FAB4U		•	18
2 port pilot kick solenoid valve	CXU30-ADK		•	20
2 port pilot operated solenoid valve	CXU30-FAD		•	22
5 port pilot operated valve	CXU30-4G2		•	24
Contact confirmation switch	GPS2, MGPS2	•		30
Modular check valve	CXU10-CHV	•		34
	CXU10-D4	•		36
4 directional distributor	CXU30-D4		•	36
	CXU10-TA	•		38
Turn adapter	CXU30-TA		•	38
Masking adapter	CXU10-MA	•		39
Module transform adaptor	CXU13-CA			40



Custom air unit (Model no. for custom combinations)

		Sei	ries	
Model	Model no.	1000	2000 3000 4000	Page
CXU10 Series	CXU10-UN-	•		46 to 47
CXU13 Series	CXU13-UN-			52 to 53
CXU30 Series	CXU30-UN-		•	48 to 51

Order made air units

		Sei	ries	
Model	Model no.		2000 3000 4000	Page
Order made air units	CXUZ-FL	•	•	89



Safety precautions

Always read this section before starting use.

When designing and manufacturing a device using CKD products, the manufacturer is obligated to check that device safety mechanism, pneumatic control circuit, or water control circuit and the system operated by electrical control that controls the devices is secured.

It is important to select, use, handle, and maintain the product appropriately to ensure that the CKD product is used safely. Be sure to observe the description given under DANGER, WARNING and CAUTION to assure safety of the equipment. Check that device safety is ensured, and manufacture a safe device.



1 This product is designed and manufactured as a general industrial machine part.

It must be handled by an operator having sufficient knowledge and experience in handling.

2 Use this product in accordance of specifications.

This product must be used within its stated specifications. It must not be modified or machined.

This product is intended for use as a general-purpose industrial device or part. It is not intended for use outdoors or for use under the following conditions or environment.

(Note that this product can be used when CKD is consulted prior to use and the customer consents to CKD product specifications. The customer must provide safety measures to avoid risks in the event of problems.)

Use for special applications requiring safety including nuclear energy, railroad, aviation, ship, vehicle, medical equipment, equipment or applications coming into contact with beverage or food, amusement equipment, emergency shutoff circuits, press machine, brake circuits, or for safeguard.

2 Use for applications where life or assets could be adversely affected, and special safety measures are required.

3 Observe corporate standards, regulations, etc., related to the safety of device design and control, etc.

ISO4414, JIS B 8370 (pneumatic system rules)

Principles for pneumatic cylinder selection and use

Including High Pressure Gas Maintenance Law, Occupational Safety and Sanitation Laws, other safety rules, body standards and regulations, etc.

4 Do not handle, pipe, or remove devices before confirming safety.

- Inspect and service the machine and devices after confirming safety of the entire system related to this product.
- 2 Note that there may be hot or charged sections even after operation is stopped.
- When inspecting or servicing the device, turn off the energy source (air supply or water supply), and turn off power to the facility. Discharge any compressed air from the system, and pay enough attention to possible water leakage and leakage of electricity.
- When starting or restarting a machine or device that incorporates pneumatic components, make sure that the system safety, such as pop-out prevention measures, is secured.
- 5 Observe warnings and cautions on the pages below to prevent accidents.

The safety cautions are ranked as "DANGER", "WARNING" and "CAUTION" in this section.

DANGER: When a dangerous situation may occur if handling is mistaken leading to fatal or serious injuries, or when there is a high degree of emergency to a warning.

WARNING: When a dangerous situation may occur if handling is mistaken leading to fatal or serious injuries.

CAUTION: When a dangerous situation may occur if handling is mistaken leading to minor injuries or physical damage.

Even items described under CAUTION may cause serious results. In any case, important information that must be observed is explained.

Disclaimer

1 Term of warranty

"Warranty Period" is one (1) year from the first delivery to the customer.

2 Scope of warranty

In case any defect attributable to CKD is found during the Warranty Period, CKD shall, at its own discretion, repair the defect or replace the relevant product in whole or in part, according to its own judgment.

- This Limited Warranty will not apply to:
- ① Product abuse/misuse contrary to conditions/environment recommended in its catalogs/specifications.
- 2 Failure due to other causes.
- 3 Use other than original design purposes.
- ④ Third-party repair/modification

(5) Failure caused by reason that is unforeseeable with technology put into practical use at the time of delivery

6 Failure attributable to force majeure.

In no event shall CKD be liable for business interruptions, loss of profits, personal injury, costs of delay or for any other special, indirect, incidental or consequential losses, costs or damages.

Compatibility confirmation

In no event shall CKD be liable for merchantability or fitness for a particular purpose, notwithstanding any disclosure to CKD of the use to which the product is to be put.



Safety precautions Fluid control components: Warnings, cautions

Refer to the "General purpose valve (No. CB-03-1SA)" for precautions for general-purpose control components. Always read this section before starting use.

Specific precautions 2 port direct acting solenoid valve CXU10-FAB3, CXU30-FAB4U/2 port pilot operated solenoid valve CXU30-FAD, 2 port pilot kick type solenoid valve CXU30-ADK

Design & Selection

1. Design for Safety

WARNING

This product can not be used as an emergency shut off valve.

Valves in this catalog are not designed to ensure safety such as emergency shutoff. When using in such a system, provide other measures to ensure safety.

Take measures to prevent harm to operators or objects should this product fail.

■ Leakage current from other fluid control components When using a programmable controller, etc., with CR circuits to absorb the surge voltage generated by switching elements, leakage current could pass and adversely affect the operation of the solenoid valve. Keep leakage current to less than the value given in precautions for products in this catalog or values given for products.

■ Minimum working pressure difference

The pilot valve must be used at the minimum working pressure difference or higher listed in specifications in this catalog. (CXU30-FAD)

2. Working fluid

A WARNING

Quality of fluid

Iron rust and dirt, etc., in fluid can cause operation faults or leaks, and lowering product performance. Eliminate such substances.

Temperature of fluid

Do not use beyond specified temperature range.

3. Working conditions

WARNING

- Only explosion-proof solenoid valves and air-driven valves can be used in an explosion-proof atmosphere. Explosion proof solenoid valves are not available for an air unit. Select from "General purpose valve" (No.CB-03S-1)
- When using AC voltage, a large noise may be generated, depending on working conditions.
 Salect DC specifications if humming could become an issue.

Select DC specifications if humming could become an issue.

Do not use this product in an environment in which corrosive gases could impregnate configuration materials.

- Do not use this product near heat-generating elements or where it may be subject to radiated heat.
- Use the product within the specified ambient temperature range.
- Take appropriate antifreeze measures when using in a cold district.

When insulating the solenoid valve, etc., do not treat the coil.


- Take appropriate safeguards for protective structures listed in catalog specifications.
- Take appropriate safeguards when using this product in places where oil or spatter from welding, etc., could come in contact.

4. Securing space

Securing maintenance space Secure sufficient space for maintenance and inspection.

5. Leakage current

■ Leakage current from other fluid control components When operating the solenoid valve with a programmable controller etc., confirm that the leak current output from the programmable controller is within the following specifications.



Voltage Model no.	AC100V	AC200V	DC12V	DC24V
CXU10-FAB3 CXU30-FAB4U CXU30-FAD	6mA 3mA or less or less	1mA or less	2mA or less	
CXU30-ADK	6mA or less	3mA or less	2mA or less	1mA or less

CXU Series

Installation & Adjustment

1. Installation

- Always thoroughly read the Instruction Manual before installing this product.
- Do not apply external force to the coil section.
- After installing, check for leaks from pipes and wire connections, and check that the product is correctly installed.

2. Piping

- If the pipe vibrates when the solenoid valve is opened and closed, secure piping.
- The solenoid valve may chatter depending on the circuit. Contact CKD if chattering occurs.
- If the piping cross-section area on the fluid inlet is reduced, the operation may become unstable due to a differential pressure fault during valve operation. For fluid supply piping, the pipe size must match the valve's bore side, and the piping diameter must have no restricted sections. (CXU30-FAD, CXU30-ADK)

3. Wiring

ACAUTION

■ Use within the allowable volta ge range. Use outside of the allowable voltage range may lead to operation faults or coil damage.

- Provide a circuit breaker, such as a fuse, on the control circuit to protect electrical equipment.
- If electrical circuitry is susceptible to solenoid surges, provide measures such as inserting a surge absorber parallel to the solenoid.
- Use a wire more than 0.5mm² of nominal section area as the reference. Check that no excessive force is applied to leads.
- ■Use of a switching circuit that does not cause contact chatter will lengthen the life of the solenoid valve and motorized valve.

During Use & Maintenance

1. Maintenance Inspection

WARNING

- Do not tighten while pressure is applied. The solenoid valve's coil and actuator will heat up when electricity is passed through them. Depending on the product, directly touching these sections could cause burns.
- Do not touch coils or actuators with hands while power is on or immediately after turning power on. There is a risk of electric shock.

Touching electrical wire connections while power is on could lead to electrical shocks.

- ■Use within the maximum service pressure and maximum working pressure difference range.
- To ensure that the product is used optimally, regularly inspect the product every six months. This frequency varies with the frequency of use.

ACAUTION

- Do not step the valve, nor put the heavy things on it.
- When using the product with continuous energizing and low frequency, consult with CKD.
- If the product has not been used for more than a month, carry out trial operation.
- Read the instruction manual thoroughly before starting maintenance to ensure correct operation.
- Turn power off and release fluids or pressure before starting maintenance.
- Check that the filter is not clogged.

Cautions

During Use & Maintenance


2. Assembling & Disassembling

- When cleaning the product, use a low-polluting cleaning agent such as a neutral detergent. (However, rubber parts must be replaced since it may swell)
- Consult with CKD on questions about consumables, etc.
- The coil assembly mounting screw must be tightened with the following torque for disassembly and assembly.

Model no.	Coil assembly mounting screw
CXU10-FAB3	
CXU30-FAB4U	1.1 to 1.8Nm
CXU30-FAD	
CXU30-ADK	

3. How to connect terminal box

- DIN terminal box with indicator light (Pg11)
 - ① Use the following cabtire cable.
 - Cable outer diameter: ø6 to ø10
 - Nominal sectional area: 0.5 to 1.5mm²
 - ② Insert a bare crimp terminal for copper wire into the lead wire of the cabtire cable and caulk the terminal. M3 terminal screws are used with the terminal box.
 - ③ Tighten screws with the following tightening torque.
 - Setscrew tightening torque ··· 0.5Nm
 - Terminal screw tightening torque ··· 0.5Nm



Wire the terminal box following steps 1 to 2

* The orientation of the cable lead out port can be changed by removing the terminal box from the case, rotating it by 90°, then returning the terminal box to the case.

4. Instantaneous leakage phenomenon

■Instantaneous leakage phenomenon

When using the 2 port pilot operated solenoid valve, sudden application of pressure (e.g. starting up compressor) could momentarily open a closed valve and cause fluid to leak. Excercise caution. (CXU30-FAD, CXU30-ADK)



Safety precautions Fluid control components: Warnings, cautions

Always read this section before starting use.

Refer to the "General Purpose Valves (Catalog No. CB-03-1S)" for details on precautions for general purpose valves.

Specific precautions: 2 port pilot operated solenoid valve CXU-EXA Series

Design & Selection

1. Confirmation of specifications

A WARNING

Use within the product's specific specification range. Use with pressure or temperature exceeding the specification range may result in damage or operation faults. Refer to specifications.

Contact CKD when using for fluids other than compressed air.

Working fluid


Active gases are not applicable. Consult with our sales office when using it.

2. Safe design

A WARNING

Take measures to prevent harm to operators and product failure.

- Check leakage current to prevent other fluid control components from malfunctioning due to leakage current.
 - When using a programmable controller, etc., the solenoid valve could malfunction because of leakage current. The value affected by leakage current differs with the solenoid valve.



- Follow the precautions below when using nylon tubes or urethane tubes.
 - Use flame resistant tubes where spatter could scatter.
 - When using the standard push-in joint on the spiral tube, fix the base of the tube with a hose band. The tube will rotate and holding force will drop if not fixed.

3. Working environment

■Use clean air.

- The product could break or malfunction if used with compressed air containing chemicals, synthetic oils containing organic solvents, salt, or corrosive gases, etc.
- Maintain the ozone concentration in the compressed air below 0.1ppm. Increase in ozone concentration will result in deficiencies such as malfunctions and leaage.
- DIN terminal box connection type protection property symbol (IPX5) IP X5 (IEC 60529 (IEC 529: 1989-11)) standards are applied to the test. Avoid use in condition which water or coolant could directly contact the valve.

Explanation of protection property symbols and examination method of IPX5 • Protective structure

Note: IP-X5 is a test based on the following stand	dard						
EC (International Electrotechnical Commission) Standards (IEC60529 [IEC529: 1989-11])							
	Protec	ction property syn	nbols (Internation	al Protection)			
1st characteristic number (protective class against external solids)	2nd ch	naracteristic numb	per (protective cla	ss against entry of water)			
	Grade	Degree of	protection	Overview of test method (fresh water is used.)			
	5	Protection against powerful jets = - + + + + + + + + + + + + + + + + + +	Water projected in powerful jets shall not enter products in adverse amounts.	Using the following test equipment, the sample will be sprayed from all direction on a surface area of 1m ² for 1 minute, total of 3 minutes or longer Spray nozzle inner diameter: ø6.3mm			

CXU series Specific precautions


4. Durability

A WARNING


■ Use in continuous energizing could deteriorate the solenoid valve's performance. Contact CKD for such applications.

5. Pneumatic pressure source

Install the air filter just before the circuit using the pneumatic component.



- Do not supply other than compressed air.
- Use clean compressed air that does not contain corrosive gases.
- Use dry compressed air that does not cause condensation in piping.



- Drainage will remove lubricant, and cause lubrication faults.
- Drain will inter the air path in pneumatic components to block the flow path instantaneously, causing malfunction.
- Drainage could cause rust, causing the pneumatic device to fail.
- Use compressed air that does not contain oxidized oil, tar, carbon, etc., from the air compressor.
 - If oxidized oil, tar, or carbon enter the air compressor and solidifies, resistance at the sliding section will increase, and could lead to operation faults.
- Use compressed air that does not contain solid foreign matter.
 - Solid foreign matter in compressed air could enter the air compressor and cause wear, sticking. or leakage at the sliding section.


6. Surge supressor

The surge suppressor enclosed with the solenoid valve is to protect the output contact for that solenoid valve's drive. There is no significant protection for the other peripheral devices, and devices could be damaged or malfunction by the surge. Surge generated by other devices could be absorbed, resulting in damage or accidents such as burning. Note the following points. The surge suppressor functions to limit a solenoid valve surge voltage, which can reach several hundred V, to a low voltage level that the output contact can withstand. This may be insufficient for the output circuit, however, and could result in damage or malfunction. Check that the surge suppressor is adequate for the surge voltage limit of the solenoid valve used, the output device withstand voltage, and circuit configuration, and the degree of return delay time. Provide separate surge measures if necessary. Reverse voltage surge generated at OFF is suppressed to the following levels by the solenoid valve with surge suppressor of this product.


Rated voltage	Reverse voltage value when power turned OFF
24VDC	Approx. 47V

When using the NPN output unit, a surge voltage equivalent to the voltage above plus the power voltage surge could be applied. Provide contact protection circuit.


(example of output transistor protective circuit installation 1)



(example of output transistor protective circuit installation 2)



If another device or solenoid valve is connected in parallel to the solenoid valve, the inverse voltage surge generated when the valve is OFF would apply to those devices. Even when using the solenoid valve for the surge suppressor for 24 VDC, surge voltage may reach minus several ten V depending on the model. This reverse polarity voltage could damage or cause other devices connected in parallel to malfunction. Avoid parallel connection with a device having weak reverse polarity voltage. (Example: LED indicator.) When driving several solenoid valves in parallel, the surge from other solenoid valves could enter the surge suppressor of one solenoid valve with a surge suppressor. Depending on the current value, that surge suppressor could burn. When driving several solenoid valves with surge suppressors in parallel, surge current could concentrate at the surge suppressor with the lowest limit voltage and cause similar burning. Even if the solenoid valve is the same, surge suppressor limit voltage is inconsistent and in the worst case could result in burning. Avoid driving several solenoid valves in parallel.



The surge suppressor incorporated in the solenoid valve will often short-circuit if damaged by excessive voltage or current the other solenoid valves. After such damage, large current flows when output is turned on, and in the worst case, the output circuit or solenoid valve is damaged or fires start. Do not leave the solenoid valve energized in a faulty state. Provide an overcurrent protection circuit on the power or drive circuit, or use a power supply with overcurrent protection so that no large current flows continuously.



CXU Series

7. 100VAC specifications

■ For 100 VAC, all wave rectified circuit is incorporated.

When using an SSR to turn the solenoid valve on and off, a solenoid valve reset fault may occur depending on the SSR.

Select the SSR appropriately. Consult with the relay or PLC manufacturer for details.)

Installation & Adjustment

1. Installation

🛦 warning

- Avoid washing with water or solvents or painting after installation.
 - Resin parts could be damaged.
- Make sure that the joint and tube are not twisted or pulled, and that moment load is not applied.
- Check that tubing is not worn or damaged.
 Tubing could be crushed, ruptured, or dislocated.

2. Confirmation before operation

- ■When supplying compressed air for the first time after connecting pipes, do not apply high pressure suddenly.
 - Tube may come off and fly out, causing an accident.
- When supplying compressed air for the first time after connecting piping, confirm that no air is leaking from any pipe connections.
 - Apply a leakage detection agent on pipe connections with a brush, and check for air leaks.

3. Piping

- Connect piping so that connections are not dislocated by system movement, vibration, or tension.
 - When using the push in joint, cut the tube at right angles using a dedicated tool.
 - Confirm that the tube has been inserted properly, and make sure that there is no tension during use. The tube could be dislocated or damaged if there is any tension.
- Make sure that the joint and tube are not twisted or pulled, and that moment load is not applied.
- Use the designated tube.
 - Mount an insert sleeve especially when using extremely flexible urethane tubing.

- Securely insert the tube to the tube end, and make sure that the tube cannot be pulled off.
- Cut the tube at right angles using a dedicated cutting tool.

4. Lead wire wiring

■ Wire in a suitable method for the lead wire.

The used lead wires are as follows.


Electric connection symbol	Descriptions	Conductor size	Conductor cross-section areas	Isolator outer diameter	Sheath outer diameter
Blank	Grommet lead wire	AWG#24	0.22 equivalent	1.42	-

5. DIN terminal box

🛕 WARNING

Turn power OFF before disassembling or assembling the terminal box. There is a risk of electric shock.

- Disassembly
 - Loosen the screw ①, and pull the cover ② in the direction of screw ①. The connector will come off the coil assembly ⑫.
 Dull the second ② out of the second ③
 - Pull the screw 1 out of the cover 2.
 - There is a notch (9) (next to GDSN mark) on the bottom of the terminal block (3). Insert a small flat-tip screwdriver between the housing (2) and terminal block (3), and twist it. The terminal block (3) will come off the cover (2). (Refer to Fig. 1.) Remove the terminal box without applying excessive force. may result in damage
 - Remove the cable gland ④, and remove the washer ⑤ and rubber packing ⑥.





J Series

- Wiring
 - Pass the cable gland ④, washer ⑤ and rubber packing (6) in order through the cable (7), and insert into cover (2).
 - · Connect to terminal 1 and 2. There is no polarity. There is no polarity.
 - Recommended tightening torque is 0.2 to 0.25N·m.

Assembly

- Set the wired terminal gland ③ on cover ② Press in until it clicks.)
 - * The terminal block can be set in four directions.
- Set the rubber packing (6) and washer (5) in order into the cover ② cable lead-in port, and then securely tighten the cable gland ④.

Remarks: Reference tightening torque of cable gland is 1.0 to 1.5N·m.

Check that the cable cannot be pulled out.

Set the gasket (8) between the bottom of the terminal block ③ and the coil assembly ¹/₂ plug, and insert the connector. Insert the screw ① from the top of the cover ② and tighten. Remarks: Recommended tightening torque of a screw is 0.2 to 0.25 N·m.

[Fig. 2]

During Use & Maintenance

1. Common

Energizing for a long time could impair solenoid valve performance. Similar caution is required in the following use.

During intermittent energizing, when the energized time is longer than the non-energized time. During intermittent energizing which one energizing session exceeds 30min. Consider heat dissipating measures at installation. Consult with CKD when energizing this device continuously.

Instantaneous leakage phenomenon

When using the 2 port pilot operated solenoid valve, sudden application of pressure (e.g. starting up compressor) could momentarily open a closed valve and cause fluid to leak.

Disassembly

Do not disassemble this valve.

Disassembling this valve may drop the valve performance.


Do not touch coils or actuators with hands or otherwise while power is on or immediately after turning power on. The solenoid valve's coil and actuator will heat up when electricity is passed through them.


- Differential pressure Keep the differential pressure with the valve open above 0.01MPa in the following situations.
 - If a restriction, such as a nozzle is included to the secondary side.
 - When valves are simultaneously opened in a state where multiple solenoid valves are piped (modular connection) in parallel. (differential pressure will become difficult to generate between the primary and secondary, due to the drop in source pressure)
- Do not apply tension to the coil section lead wire during installation.
- Hold the product body when carrying the product. (Do not hold onto the lead wire)
- When the regulator and solenoid valve are directly connected, the parts could mutually vibrate causing resonance and chattering.
- If the piping cross-section area on the fluid inlet is reduced, the operation may become unstable due to a differential pressure fault during valve operation. Use a pipe that matches the port size on the supply side.
- Depending on the working conditions, the operation of the solenoid valve may become unstable if left unused for a long period. Always have a trial run before using.



Cautions

- Either twisted wires or single conductors are connected. · When using twisted wires, avoid connecting soldered wires.
- When using a crimping sleeve (1) on the end of the twisted wire, use the Japan Weidmuller H0.5/6 (0.3 to 0.5 mm²), H0.75/6 (0.75 mm²) or another equivalent product. The crimping sleeve must be prepared by the user. The crimping sleeve must be prepared by the user.







Pneumatic components

Safety precautions

Always read this section before starting use. Refer to Pneumatic valves Catalog No. CB-023SA for the general valves.

Specific precautions: 5 port pilot operated valve CXU30-4G2 Series

Design & Selection


1. Surge supressor

- The surge suppressor enclosed with the solenoid valve is to protect the output contact for that solenoid valve's drive. There is no significant protection for the other peripheral devices, and devices could be damaged or malfunction by the surge. Surge generated by other devices could be absorbed, resulting in damage or accidents such as burning. Note the following points.
 - The surge suppressor limits solenoid valve surge voltage, which can reach several hundred volts, to a lower voltage level withstandable by the output contact. This may be insufficient for the output circuit, however, and could result in damage or malfunction. Check that the surge suppressor is adequate for the surge voltage limit of the solenoid valve used, the output device withstand voltage, and circuit configuration, and the degree of return delay time. Provide separate surge measures if necessary. The 4G Series solenoid valve surge suppressor suppresses reverse voltage surge generated at OFF as shown in the following table.


Rated voltage	Reverse voltage value when power turned OFF
24VDC	Approx. 47V

When using the NPN output unit, a surge voltage equivalent to the voltage above plus the power voltage surge could be applied. Provide contact protection circuit.

(Example of output transistor protective circuit installation 1)



(Example of output transistor protective circuit installation 2)



- If another device or solenoid valve is connected in parallel to the solenoid valve, reverse voltage surge generated when the solenoid valve is off is applied to these devices. Even when using the solenoid valve for the surge suppressor for 24 VDC, surge voltage may reach minus several ten V depending on the model. This reverse polarity voltage could damage or cause other devices connected in parallel to malfunction. Avoid parallel connection with a device having weak reverse polarity voltage. (Example: LED indicator.) When driving several solenoid valves in parallel, the surge from other solenoid valves could enter the surge suppressor of one solenoid valve with a surge suppressor. Depending on the current value, that surge suppressor could burn. When driving several solenoid valves with surge suppressors in parallel, surge current could concentrate at the surge suppressor with the lowest limit voltage and cause similar burning. Even if the solenoid valve is the same, surge suppressor limit voltage is inconsistent and in the worst case could result in burning. Avoid driving several solenoid valves in parallel.
- The surge suppressor incorporated in the solenoid valve often shortcircuits if damaged by overvoltage or overcurrent from a source other than the solenoid valve. After such damage, large current flows when output is turned on, and in the worst case, the output circuit or solenoid valve is damaged or fires start. Do not leave the solenoid valve energized in a faulty state. Provide an overcurrent protection circuit on the power or drive circuit, or use a power supply with overcurrent protection so that no large current flows continuously.

2. 100VAC specifications

ACAUTION

For 100 VAC, all wave rectified circuit is incorporated. When using an SSR to turn the solenoid valve on and off, a solenoid valve reset fault may occur depending on the SSR.

Select the SSR appropriately. Consult with the relay or PLC manufacturer for details.)

Installation & Adjustment

1. Lead wire wiring

Lead standards differ with the type of wire connection. Connect wires appropriately.

 Electric connection symbol
 Descriptions
 Conductor size
 Conductor consection areas
 Isolator outer diameter

 E
 E-connector with lead wire
 AWG#26
 0.13 equivalent
 1.35


 When connecting wires, check that leads do not apply tension to the solenoid valve coil.
 tension
 tension

2. How to use E-connector

The E-connector is a top/side common connector to which the sockets can be connected to either the top or side directions. The socket assembly is enclosed with the valve. Select the connection direction based on installation.


How to mount or dismount socket

- When installing the socket, hold the lever and socket with your fingers and insert straight into the square window on the connector. Align the lever with the groove on the connector and lock. When installing from the top, face the socket so that the lever is in front. When installing from the side, face the socket so that the lever is on the top.
- When pulling the socket out, press down on the lever to release jaws from the groove, then pull straight out.



How to connect lead wire

- Strip 3 mm of the lead end, arrange the ends of the core wires and insert them into the contact terminal. Crimp both the sheath and wire, and check that 0 to 0.5 mm of the core wire is visible.
- After crimping, turn the contact terminal as shown below, and insert into the square window on the socket. The terminal locks when it is inserted to the end. After insertion, tug lightly on the terminal to check that it is locked.




3. DIN terminal box

WARNING

■ Turn power OFF before disassembling or assembling the terminal box. There is a risk of electric shock.

Disassembly

- Loosen the screw ①, and pull the cover ② in the direction of screw ①. The connector will come off the coil assembly ⑫.
- Pull the screw 1 out of the cover 2.
- There is a notch (9) (next to GDSN mark) on the bottom of the terminal block (3). Insert a small flat-tip screwdriver between the housing (2)) and terminal block (3), and twist it. The terminal block (3) will come off the cover (2). (Refer to Fig. 1.) Remove the terminal box without applying excessive force. may result in damage
- Remove the cable gland ④, and remove the washer ⑤ and rubber packing ⑥.



Wiring

Wiring preparation

- · Applicable dimensions for cable 0 are VCTF2 (3) core (ø3.5 to 7) specified in JISC3306.
- Strip 10mm of the cable's lead sheath.
- · Either twisted wires or single conductors are connected.
- When using twisted wires, avoid connecting soldered wires.
- When using a crimping sleeve (1) on the end of the twisted wire, use the Japan Weidmuller H0.5/6 (0.3 to 0.5 mm²), H0.75/6 (0.75 mm²) or another equivalent product. The crimping sleeve must be prepared by the user. The crimping sleeve must be prepared by the user.

Wiring

- Pass the cable gland ④, washer ⑤ and rubber packing ⑥ in order through the cable ⑦, and insert into cover ②.
- Connect to terminal 1 and 2. There is no polarity. There is no polarity.
 Recommended tightening torque is 0.2 to 0.25N·m.

Installation & Adjustment

Assembly

- Set the wired terminal gland ③ on cover ② (Press in until it clicks.)
 - The terminal block can be set in four directions.
- Set the rubber packing (6) and washer (5) in order into the cover (2) cable lead-in port, and then securely tighten the cable gland (4).
- Remarks: Reference tightening torque of cable gland is 1.0 to 1.5N·m.
 - Check that the cable cannot be pulled out.
- Set the gasket
 between the bottom of the terminal block ③ and the coil assembly ^① plug, and insert the connector. Insert the screw ① from the top of the cover ② and tighten.

During Use & Maintenance

1. Common

ACAUTION

- Energizing for a long time could impair solenoid valve performance. Similar caution is required in the following use.
 - During intermittent energizing, when the energized time is longer than the non-energized time.
 - During intermittent energizing which one energizing session exceeds 30min. Consider heat dissipating measures at installation. Consult with CKD when energizing this device continuously.


2. Manual override

WARNING

- CXU30-4G2 series is an internal pilot operated solenoid valve. If air is not supplied to the P port, the main valve will not change even if the manual override is operated.
- A protective cover of manual override is provided as standard. The manual override protective cover is closed when the valve is shipped to protect manual override, which cannot be seen when delivered. Open the protective cover and operate the manual override.


The protective cover will not close unless the manual override is unlocked.

- ■Manual override is used for both non-locking and locking. The lock is applied by pressing down and turning manual override. When locking, press down and turn. If manual override is turned without being pressed down, it could be damaged or air could leak.
- How to open and close protective cover of manual override Do not excessively force the manual protective cover when opening and closing it. Excessive force could cause faults. (less than 5N)



Turn type


Remarks: Recommended tightening torque of a screw is 0.2 to 0.25 N·m.



■ Make sure that the joint and tube are not twisted or pulled, and that moment load is not applied.

- How to operate manual override Push/non-locking operation Push in the direction of the arrow until it stops. Manual override is unlocked when released
 - Push/locking operation

Push manual override and turn 90° in the direction of the arrow. Manual override is not unlocked even when released.



- ■When conducting manual operations, make sure that there are no people near the moving cylinder.
 - 3. How to replace coil


WARNING

■ E type connector coil assembly

Replace the coil by removing the set screw shown below. Loosening the other screws could cause operation faults. When installing, check that the gasket is installed on the coil side, and note tightening torque. Improper installation could result in air leaks or operation faults.

DIN terminal box coil assembly

Replace the coil assembly by removing the set screw shown below. Loosening the other screws could cause operation faults. When installing, check that the gasket is installed on the coil assembly side, and note tightening torque. Improper installation could result in air leaks or operation faults. The grommet lead, E-connector specification and DIN terminal box specification coil assembly cannot be replaced.





Pneumatic components (F.R.L. unit (modular design))

Safety precautions

Always read this section before starting use. Refer to "Pneumatic, vacuum and auxiliary components CB-024SA".

Specific precautions: F.R.L. (modular design)

Design & Selection

1. Common

A WARNING

- This product is for industrial use only. Must not be used in components or circuits for medical equipment or components that involve human lives.
- Air filter, lubricator plastic bowl, lubricator' drip window, and pressure gauge lens


Material is polycarbonate. Do not use in the atmosphere with synthetic oil, organic solvent, chemical materials, coolant, screw locking adhesive, liquid soap, hot water, etc., or possible exposure to these substances.

Refer to page 16 for details on bowl chemical resistance.

Piping load torque

Check that the piping load or torque is not applied to the body or piping sections.

Series	1000	2000	3000	4000
Max. torque N•m	10	10	50	50



With the 1000-W Series, application of a torque of $20N \cdot m$ or more on piping could damage piping. Use within the specified torque, even when using the piping adapter.

■Large drainage

Install the air dryer and drain separator before the air filter.

If there is a large drainage from the compressor. Hot and highly humid air could shorten the device life or result in corrosion.

■Ultra dry air

Rubber parts for the regulator could deteriorate quickly, so use of a fluorine rubber valve assembly is recommended. Consult with CKD for more information.

Water lubricated compressor circuit

Take measures to prevent chlorine-based substances from entering the compressed air.

- Use the automatic drain under the working conditions below. Failure to observe these conditions could result in malfunction.
 - N.O. type automatic drain (exhaust without pressurized): F
 - Use a compressor with a capacity of 0.75 kW {90l/min [ANR]} or more.
 - Set the working pressure to 0.1 MPa or more. (Initially generated drainage and air are purged until pressure reaches 0.1 MPa.)
 - N.C. type automatic drain (exhaust without pressurized): F1
 - Can be used with compressor with 0.75kw or less.
 - Set the working pressure to 0.15 MPa or more.
 - 1000 Series NC automatic drain
 - The working flow must be less than the maximum working flow.
 - In places with high vibration, such as where the compressor is installed, air could leak from the drain port when the float vibrates. Avoid this use.
 - Do not let the drain overflow as it may lead to malfunctioning.


CXU Series

2. Regulator, filter with regulator

A WARNING

- Install a safety device where an output pressure exceeding the regulator's set pressure value could result in damage or faulty operation of secondary side devices.
- The regulator cannot process residual pressure (remove secondary pressure) when primary pressure is released. Use a regulator with a check valve when residual pressure must be processed.
- In some cases, the regulator cannot be used for secondary side sealing circuits or balance circuits. Consult with CKD for these types of applications.

- Set the regulator's secondary pressure to 85% or less that of the primary side. The pressure could drop further.
- When using regulators in parallel as shown below, do not use the OUT side as a closed circuit. If a closed circuit is required, set a check valve at the regulator's OUT side.



3. Lubricator

WARNING

■ Lubricator

Consult with CKD for using lubrication with an air motor or bearings. Also consult with CKD when using this unit at a high frequency such as in a press machine.

If the working air rate is low for the lubricator, oil may not drip.

Check the minimum air rate required for dripping oil.

4. Pressure switch

When using a digital pressure sensor PPX or compact pressure switch PPD, avoid using it as a set with the lubricator. The switch is not a drip-proof structure, so operation could be disabled if the lubricating oil comes in contact with it.

5. Shut-off valve

WARNING

Precautions for shut-off valve

● The EXH port is dedicated for installation of the silencer. Tighten with a torque of 3 N·m or less -- as far as is tightened manually.

Avoid piping that applies piping load or torque, etc., to the EXH port.

 If exhaust is incomplete because of air quality, manually discharge air by operating the knob (turn and raise).

6. Modular check valve

This valve can not be used as a stop valve that has no leakage. Due to its structure, a few leakage will occur.



U Series

Specific precautions

Installation & Adjustment

1. Common

CAUTION

- Avoid installing this product where it is subject to direct sunlight.
- Flush and clean pipes before use.
 - Dirt or foreign materials in piping will lower product performance.
- Check that foreign materials do not enter when tightening pipes or joints.

When screwing in piping or joints, check that swarf from piping threads or sealing agent does not get inside. Dirt or foreign materials in piping will lower product performance.

- How to use the F.R.L. correctly
 - 1 Set the regulator pressure setting to increase. After setting pressure, lock the handle. Check primary pressure carefully before setting pressure.
 - 2 Check the arrow indicating the air inlet before connection. Reverse connection causes malfunctions.
 - 3 Install the air filter and lubricator vertically with the bowl facing downward. Failure to do so could lead to disconnection or malfunction.
 - 4 Use of the automatic drain where vibration is present could cause faults and malfunctions.

Pipe the automatic drain in the following conditions. Otherwise, malfunctioning may occur.

Use a drain discharge pipe with ø5.7 or larger size. Keep the pipe length within 5 m, and avoid an upward slope.

Do not pipe in a manner which will apply lateral load to the bowl.

Fix the hexagon side of the cock before screwing the joint, etc., into the Rc1/8 female screw.

Piping screw-in torque Make sure that excessive torque is not applied on the body and piping when piping.

· · · · · · · · ·	F F 5	FF 3		
Series	1000	2000	3000	4000
Max. torque N∙m	15	30	30	30




■ Drain piping

Confirm that the drain cock is closed before inserting the tube. The drain piping for the plastic bowl has a barbed nipple, and can be directly installed. However, confirm that the drain cock is closed before inserting the tube.

■ Drain cock tightening torque

- The max. tightening torque of the drain cock for the plastic bowl is as follows.
 - · 1000 Series: 0.1N·m
 - · Others: 0.5N · m
- Drain piping of metal bowl with automatic drain
 - Fix the cock's hexagonal face before screwing the joint, etc., into the drain port's female threads. When using the metal bowl with automatic drain, if the drain is piped with a tightening joint, manual operation is not possible.



CXU Series

2. Regulator, filter with regulator


Regulator, filter with regulator

- Lightly tighten (0.6 N·m or less) mounting screws for embedded pressure gauge G401-W-OP, G401-W, and gauge plug.
- When installing the pressure gauge with a safety mark on the gauge plug, or when installing a general screw-in pressure gauge, tighten with a torque of 10 to 15 N·m or less.
- Do not move or swing the product holding the adjustment knob on the regulator.
- Do not apply pressure exceeding the pressure gauge's full scale, This will cause the pressure gauge to break. (Pay extra caution when using 0.2 and 0.4 MPa pressure gauges)

3. Lubricator

Adjustment of lubricator drop down

 Adjust the oil rate by turning the adjusting dome with bare hands. When closing the dome, tighten with a torque of 0.5 N·m or less. The numbers (scale) on the dial are a guide used after adjustment, and do not indicate the oil drip.



4. Pressure switch

■ How to mount pressure switch (PPD)


- Separate the body from the base.
- Attach an O ring.

* Refer to the outline drawings for the direct installation type (PPD-****-1F-1) (PPD-****-1F-2) on the left, and attach the O ring to the O ring groove with a clean finger.

Install the base


Install the base with the two enclosed screws (M3). * Carefully install at the designated position in the designated direction while taking care not to dislocate the O ring.

* Do not tighten one screw completely at once, and instead tighten the two screws so that they are balanced. (Tightening torque 0.5 ± 0.1 N·m)



Install and fix the body.

Make sure no dirt or foreign matter is on the base, and then insert the body. Make sure that the body does not catch on the base. Then, insert the two keys. While pressing the body exterior against the base, set the heads of the keys so that they face each other, then insert them so that they are completely stored in the recesses on the base.



Note: Install both keys. Check that both keys are installed before pressurizing.

Note: When changing the position or orientation of the PPD which has been installed once, install using the new keys, O rings and installing screws enclosed with the option kit.


5. Pressure gauge

CAUTION

Pressure gauge

Repeated and sudden increases and decreases in pressure and pressure pulsation must be avoided because it could adversely shorten pressure gauge life. Either ease pressure fluctuation in the circuit or consult with CKD so that a pressure gauge with a cushioning screw can be prepared. Applying pressure exceeding the pressure range could damage the pressure gauge.

Removing resin bowl



During Use & Maintenance

1. Common

A WARNING

Regularly, once or more in six months, check the air filter and lubricator's plastic bowl for cracks, damage, and other deterioration.


Cracks, damage or other deterioration could result in breakage, so if found, replace with a new bowl or with a metal bowl.


- Check the air filter, lubricator plastic bowl, and lubricator drip window periodically for contamination.
 - If parts are heavily contaminated or if transparency has dropped, replace with a new bowl or drip window.
 - Use a diluted neutral household detergent to wash parts, and then rinse well with clean water. Use of other agents could result in breakage.
- Removing filter, lubricator bowl Before removing the bowl, the compressed air, discharge pressure in the bowl completely, and confirm that no residual pressure remains.


ACAUTION

- Check the oil drip rate once a day. If the oil drip is faulty, problems could occur in the unit being lubricated.
- Do not branch the air into lubricating air and oilless air with a distributor. The lubricator oil could reverse flow.
- Filter element clogging will decrease vacuum source conductance. Regularly inspect, clean, and replace the element.
- Do not disassemble or modify the product.
- Read instructions and precautions enclosed with the product before starting use or maintenance.

Cautions







Specific precautions

(U Series



 Drainage is started when the cock is turned to the O side, and the discharge is stopped when the cock is turned in the S direction.
 Tighten in the S direction with your hands.

Metal howl

(manual cock)


When the automatic drain is provided, drainage is discharged automatically when it accumulates. Drainage is also discharged manually.

CXU Series

2. Filter · regulator

Element of the W1000 to W4000 Series Inspect the valve assembly when it is removed during maintenance.

Do not lose internal parts when removing the coil.






A WARNING

Drain so that air filter drainage does not accumulate beyond the maximum.

Components could malfunction if drainage flows into the secondary side.





Metal bowl

Metal bow

The resin bowl must not be filled beyond the "MAX LEVEL" stamped on the bowl guard.

■ Submicron 0.3µm element

Washing cannot restore functions. When the pressure drops to 0.07 MPa, replace the filter with a new one. (Excluding 1000 Series)

■ Oil mist filter

The mantle (element) life ends after one year (6000 hours) or when pressure drops to 0.1 MPa (Except for the X type,) Replace the mantle when life is reached. (Do not touch the urethane foam layer during replacement.)

4. Regulator, filter with regulator

Pull the pressure adjustment knob and release the lock before setting the regulator pressure. The regulator could be damaged if the pressure is set without unlock.

5. Lubricator


WARNING

Use Class 1 turbine oil (nonadditive) ISO VG32 for the lubricator.

Use of other oil will result in damage or malfunction.

Removing the lubricator's filling plug

To prevent the filling plug from popping out, loosen the filling plug by one turn, and then completely depressurize the bowl before removing the filling plug. Wipe away any dirt around the fill plug that could scatter.



- Close the fill plug after lubricating.
- Do not remove the bowl without removing the filling plug while the bowl is pressurized. (L3000 to L4000)
- With the 1000 Series, never remove the bowl with the filling plug set to the SHUT side (while the bowl is pressurized). (L1000)

CAUTION

- Periodically replenish oil in the lubricator bowl so that it does not drop below the lower limit.
- When lubricating the L1000-W, pressure in the bowl is released by turning the fill plug. Refer to the above for the operation of the filling plug. (Lubrication can be carried out while the pipes are pressurized.)

Check that there is no pressure in the bowl, remove the bowl and bowl guard, and then directly lubricate to the bowl.

Refer to the previous page for details on removing the bowl.

■ When lubricating L3000 to L4000, loosen the filling plug slightly to release the pressure in the bowl, and then remove the filling plug. Refer to the above for the operation of the filling plug.

(By removing the filling plug, lubrication can be carried out while the pipes are pressurized.)

Oil can also be supplied from the filling plug hole, and the bowl can be directly lubricated by removing the bowl and bowl guard.

Refer to the previous page for details on removing the bowl.



Specific precautions: F.R.L. components

Chemical resistance of plastic parts

WARNING

- The chemical resistance of plastic parts is shown below.
- Avoid using products in an atmosphere where chemicals are contained in compressed air, the atmosphere, or where they could adhere to parts.
- Use in this state could lead to bowl damage and accidents.
- Avoid using these types of chemicals or in an atmosphere containing these chemicals.
- A metal bowl is available if these chemicals must be used.

Chemical resistance of plastic bowl and body Use a metal bowl in an atmosphere containing the following chemicals. Check whether the testing solutions, sealing agents and adhesives contain the following chemicals.

Types of chemicals	Categories of chemicals	Main products containing the chemical	Example of general usage	Polycarbonate bol	Nylon Bowl	Nylon Body
	Acid	Acid Hydrochloride, sulfuric acid, fluorine, phosphoric acid, washing of metals, acidic degreasing solution, coating fluid, etc.		×	×	×
Inorganic chemicals	Alkaline Alkalies such as caustic soda, caustic potash, calcium Alkaline degreasing of metals Hydroxide, ammonium water, or sodium carbonate Water-based coolant, leakage detection agent		×	0	0	
	Inorganic salts	Alkalies such as caustic soda, caustic potash, calcium hydroxide, ammonium water, or sodium carbonate		×	0	0
	Aromatic Hydrocarbon	Benzene, toluene, xylene, ethyl benzene, styrene, etc.	Contained in paint thinner (benzene, toluene, xylene)	×	×	×
	Chlorinated aliphatichydrocarbon Hydrocarbon	Methyl chloride, ethylene chloride, methylene chloride, acetylene chloride, chloroform, trichylene, perchloro ethylene, carbon tetrachloride	Organic solvent based washing solution for metals (Trichylene, perchloro ethylene, carbon tetrachloride)	×	0	0
	Chlorinated aromatic Hydrocarbon	Chlorobenzene, dichlorobenzene, benzene hexachloride (B, H, C), etc.	Agricultural chemicals	×	0	0
ſ	Petroleum components	Solvent naphtha, gasoline, kerosene		×	0	0
	Alcohol	Methanol, ethanol, cyclohexanol, benzyl alcohol	Anti-freeze Leakage detection agent	×	×	×
	Phenol	Carbolic acid, cresold, naphthol, etc.	Antiseptic solution.	×	×	×
	Ether	Methyl ether, methyl ethyl ether, ethyl ether	Brake oil additive	×	0	0
Organic chemicals	Ketone	Acetone, methyl ethyl ketone, cyclohexanone, acetophenone, etc.		×	×	×
	Carboxylic acid	Formic acid, acetic acid, butyl acid, acrylic acid, oxalic acid, phthalic acid, etc.	Dust/jet-proof Dyes; oxalic acid for aluminum processing, Phthalic acid is used for paint base. Used as leakage detection agent	×	×	×
	Ester	Dimethyl phthalate (DMP), diethyl phthalate (DEP), dibutyl phthalale (DBP), dioctyl phthalate (DOP)	Lubricant, synthetic oil, additive for rust preventing agent Used as plasticizer for synthetic resin.	×	0	0
	Oxo acid	Glycocholic acid, lactic acid, malic acid, citric acid, tartarate		×	×	×
	Nitro compounds compunds	Nitromethane, nitroethane, nitroethylene, nitrobenzene, etc.		×	0	0
	Amine	Methylamine, diethylamine, ethylamine, aniline, acetoacetanilide, etc.	Brake oil additive	×	×	×
-	Nitrile	Acetonitrile, acrylonitrile, benznitrile, aceloylidyne nitrile, etc.	Raw material for nitryl rubber	×	0	0

○: Permissible ×: Not permissible (plastic will be damaged)



Pneumatic component (Air unit (CXU Series))

Safety precautions


Always read this section before starting use.

Refer to the "Pneumatic, Vacuum and Auxiliary Components (No. CB-024SA)" for precautions for general purpose pneumatic pressure components.

Specific precautions: Air unit CXU Series

Design & Selection

Use the T-type bracket in regular intervals. Single support joiners can be used for three or fewer stations.




Use 3 stations or less for single support.

Use 5 stations or less for double support.

■ When using 5 port pilot operated valve (CXU30-4G2) at maximum flow rate, use with 3 or less stations.


One station consists of two solenoid valves. Up to six solenoid valves can be used.



When using 2 port pilot operated solenoid valve (CXU10-EXA) at maximum flow rate As a reference, use only 1 station when 1000 Series

regulator is connected,

and use upto 4 stations when 3000 Series regulator is connected.



Installation & Adjustment

- ■With the 1000 Series unit, the bracket may twist and rise on one side. Tighten and fix the bracket in this case. The bracket can be mounted stably and poses no problem for use.
- Precautions when selecting CXU-13-UN If 1000 Series and 3000 Series are combined together with single support, its load may destroy the joiner. Use double support.
- Tighten the fixing screw for the 1000 Series joiner with a torque of 1 to 1.2 N•m, tighten the fixing screw for the 3000 Series with a torque of 3 to 4 N•m.

Intro 21 CKD

Valve air unit Manifold model no.

General Description

The valve air unit is a unit component that lets the solenoid valve be connected to components such as regulators.

it can be used immediately without piping.

Features

1 Simplified order form

The CXU can be ordered with only 1 form, making purchasing and delivery management easy.

② Reduce man-hours

The FR component and solenoid valve are connected as modules, eliminating work such as piping.

3 Low profile


Piping free, fitting free sleek design. Ideal for use in limited space.

Description of icons

Easy Manifold

Series Variation

① Easy to select models Eliminated complex options to allow easier selection.



CONTENTS

- 2 port pilot operated solenoid valve **CXU10-GEXA Series** • 5 port pilot operated valve
 - CXU30-M4G2 Series

2

6

Valve air unit

Air unit component

		age	Port F.R. component Electri					c connection					
Series Model no.	DC 24 V	AC 100 V	Connection Port size (IN)			size JT)		Regulator	Fil Regu	ter ılator	Grommet lead	E-connector	DIN terminal box
	v	V	3/8	ø4	ø6	ø8	1/4	R2000	W2000	W3000	Gro	Ч	DIN
 2 port pilot operated solenoid valve CXU10-GEXA Easy Manifold 	•	•	•		•	•		•	•		•		•
 5 port pilot operated valve CXU30-M4G2 Easy Manifold 	•	•	•		•	•		•				•	•



2 port pilot operated solenoid valve for compressed air Manifold model no.

CXU10-GEXA Series


NC (normally closed) Order as a manifold with a regulator connected



JIS symbol



(e.g.) CXU10-GEXA-C6-R-3-2C-3



Specifications							
Descriptions		CXU10-GEXA					
Working fluid		Compre	ssed air				
Working pressure differential range MPa		0.01 t	o 0.7				
Max. working pressure MPa		0.	7				
Withstanding pressure MPa		1.()5				
Fluid temperature °C		0 to	55				
Ambient temperature °C		-5 to	55				
Atmosphere	Does	not contact water, co	prrosive or flammabl	e gas.			
Valve structure		Pilot operated dia	phragm structure				
Valve leakage cm ³ /min (ANR)		10 or	less				
Mounting		Flex	ible				
Port size (IN)		IN: R	c3/8				
Port size (OUT)	ø6 push-in fitting	ø6 push-in fitting L type	ø8 push-in fitting	ø8 push-in fitting L type			
C [dm ³ / (s·bar)] Note 2	1	.6		3			
b	0.	37	0	.32			
Electrical specifications							
Rated voltage		100VAC,	24VDC				
Rated voltage VA		1.2					
Power consumption W DC	0.6						
Heat proof class	В						
Protective structure		d wire type: IPX0, with	h DIN torminal box:				
(IEC standards 529)	Lead	u wire type. IFAU, Will					
Nuclei di Malline e di scher di scher e	100/						

Note 1: Voltage fluctuation range is ±10%

Note 2: Effective sectional area S and sonic conductance C are converted as $S \doteq 5.0 \times C$.

Regulator specificat	tions		
Set pressure range	MPa	0.05 to 0.7	Note 3
Relief		With relief mechanism	
Port size		Rc3/8	
Filter specifications			
Filtration rating	μm	5	
Drain capacity	cm³	12	
Port size		Rc3/8	

Note 3: Set pressure range will be limited by the working pressure of CXU10-EXA.

Weight

Weight	(unit: kg)
Descriptions	Descriptions
F.R. components (includes T type brackets and joiners)	
A: Piping adaptor	0.21
R: Regulator	0.58
RT8: Regulator (without pressure gauge)	0.57
W: Filter · regulator	0.7
WT8: Filter regulator (without pressure gauge)	0.69
2 port solenoid valve	
CXU10-EXA (discrete valve and joiner) Note 4	0.11

Weight: FR device used + 2 port solenoid valves X number of stations.

Note 4: Models with DIN terminal box weighs 20g more.

CXU10-GEXA Series

How to order

How to order	
CXU10-GEXA-C6-R-3-2C-3	
	Symbol Descriptions
	A Port size (OUT)
Port size (OUT)	C6 ø6 push-in fitting
	CL6 ø6 push-in fitting L type
	C8 ø8 push-in fitting
	CL8 ø8 push-in fitting L type
	B FR component options
B FR component options	Pipe adaptor (Rc3/8)
	R Regulator (Rc3/8) R Regulator (R2000-10-W-X2 Note 2) RT8 Regulator (R2000-10-W-T8X2 Note 2) Without pressure gauge (port Rc1/4 open) W Filter: Regulator (W2000-10-W-F1 Note 2)
	RT8 Regulator (R2000-10-W-T8X2 Note 2)
	Without pressure gauge (port Rc1/4 open)
	ອື່ W Filter · Regulator (W2000-10-W-F1 Note 2)
	Note 1 WT8 Filter Regulator (W2000-10-W-F1 T8 Note 2)
	Without pressure gauge (port Rc1/4 open)
	Direction Blank IN side Left
	X IN side Right
	Solenoid valve station no.
Solenoid valve station no	1 1 station
	to to
	4 4 stations
	DCoil option Note 3, 4
Coil option	2C Standard Lead wire (without indicator light and surge suppressor)
	2H DIN terminal box (Pg7). with indicator light inside terminal box
	Option DIN terminal box (Pg7). with indicator light
	2HS and surge suppressor inside terminal box
	Rated voltage
Rated vol	Itage 1 100 VAC
	3 24 VDC

A Cautions for model No. selection

- Note 1: Standard filter regulator is NC automatic drain type.
 - Select "A" unless component option R, RT, W, WT8 is selected.
- Multiple FR device options cannot be selected. Note 2: Model no. for IN side Left (FR device direction option "Blankl").
- Note 3: Refer to the table on the right for available combinations of coil options and voltage.
- Note 4: Contact CKD for models with M12 connector cable.

Internal structure drawing

Models	Listed catalog and page no.
CXU10-EXA	Page 15
CXU10-TA	Catalog No.CC-901A
CXU10-MA	Catalog No.CC-901A
R2000	Catalog No.CB-024A
W2000	Catalog No.CB-024A


Coil	Volt	age
Option	1	3
2C	●	
2H		
2HS		


Select a	combination with a	circle mark
OCIECT a	combination with a	CITCLE ITTAIR.


CXU10-GEXA Series

Dimensions

Grommet lead wire type
 CXU10-GEXA-*-A-*-2C-*
 Cartridge fitting: Straight







Magnified drawing of bracket section

Configuration table


No.	Product name	Model no.				
1	Piping adaptor Note 1	(FR component options -A)				
2	T type bracket	B110-W				
3	Turn adapter	CXU10-TA-00				
4	2 port pilot operated solenoid valve	CXU10-EXA-				
5	Turn adapter	CXU10-TA-00				
6	Masking adapter	СХU10-МА-00-В				
Note 1:	Note 1: The final product may differ depending on FR component options.					

Option dimensions


Option	Α	В	С	D	Е
C6	27	ø6 push-in fitting	-	-	-
CL6	-	ø6 push-in fitting	31	37	18.5
C8	27	ø8 push-in fitting	-	-	-
CL8	-	ø8 push-in fitting	32	39	21

Elbow type fitting


,, ,,




n: Solenoid valve station no.



● With DIN terminal box (Pg7) CXU10-GEXA-*-A-*-2HS-*






5

Dimensions


● F.R. component option: regulator type CXU10-GEXA-*-^R_{RTB}-*-*-*



Pressure gauge dimensions

•			
Pressure gauge (sold separately)	x	Y	
G49D	(73.5)	ø43.5	
G59D	(76)	ø52	
G40D	(75.5)	ø42.5	
G50D	(75.5)	ø52.5	
G41D	(74)	ø42	
G52D	(79)	ø52.5	


● F.R. component option: filter regulator type CXU10-GEXA-*-^W_{WT8}-*-*-*



Pressure	gauge	dimensions	

Pressure gauge (sold separately)	x	Y
G49D	(73.5)	ø43.5
G59D	(76)	ø52
G40D	(75.5)	ø42.5
G50D	(75.5)	ø52.5
G41D	(74)	ø42
G52D	(79)	ø52.5

• F.R. components option: reverse flow CXU10-GEXA-*-^R_{RTB}X-*-*-*



Note: When reverse flow option X is selected, the IN side and FR device are on the right. The drawing at left is for the regulator. Valve air unit

Air unit component



5 port pilot operated valve

CXU30-M4G2 Series

Order in manifolds with a regulator connected



Common specifications

	Descriptions	
Type of valve/operation method	Pilot operated soft spool valve	
Working fluid	Compressed air	
Max. working pressure MPa	0.7	
Min. working pressure MPa	0.2(2 position, 3 position)	
Withstanding pressure MPa	1.05	
Fluid temperature °C	5 to 55	
Ambient temperature °C	-5 to 55 (to be unfrozen)	
Norking onvironment	Area without corrosive or explosive gases	
Working environment	and away from water.	
Port size	Push-in fitting ø4, ø6, ø8	
R1, R2 port	Rc1/4	
Manual override	Locking/non-locking common type	
Pilot exhaust method	Main valve, pilot valve common exhaust type	
Lubrication Note 1	Not required	
Protective structure Note 2	Dust proof	
Vibration/impact m/s ²	50 or less / 300 or less	

Electrical specifications

Descriptions		Descriptions	
Rated voltage	DC	24	
V	AC	100	
Rated voltage flu	ctuation range	±10%	
Holding current	24VDC	0.023 (0.025)	
Note 3 A	100VAC	0.010 (0.012)	
Power consumption	24VDC	0.55 (0.6)	
Note 3 W	100VAC	0.55 (0.6)	
Apparent power VA	100VAC	1.0 (1.2)	
Heat proof class		В	
Temperature increase °C		50	
Surge suppressor		Standard	
With indicator		light (standard)	

Note 3: Values in parentheses include light.

Note 1: Use the turbine oil Class 1 ISO VG32 if lubricated.

Excessive or intermittent lubrication results in unstable operation. Note 2: Check that water drops or oil, etc., do not come into contact.

IP65 (jet-proof type) is used for DIN terminal box specifications.

Note that the box must be fixed using the specified adaptive cord outer diameter and tightening torque.

JIS symbol

2-position single solenoid





2-position double solenoid

3-position all ports closed


5 1 3 (R1)(P)(R2)


3 position ARB connection





3-position PAB connection





Weig	ht		(unit: kg)	
	Description	າຣ	Desc	riptions
F.R. con	ponents (includes T type	brackets and joiners)		
A: F	iping adaptor			0.54
R: F	Regulator			0.8
RT8	: Regulator (without p	ressure gauge)		0.79
W: F	-ilter · regulator		1.06	
WT8: Filter • regulator (without pressure gauge)			1.05	
5 port valve: solenoid position		Discrete valve	Valve sub-base	
With	Without solenoid valve: masking plate		0.02	
	Single	E-connector	0.08	
2 position	Single	DIN terminal	0.1	
2-position	Double	E-connector	0.1	0.32
	Double	DIN terminal	0.14	
2 position	All parts closed	E-connector	0.11	
3-position	All ports closed	DIN terminal	0.15	

Weight: FR device used + solenoid valve ① to ④ + valve sub-base.

Flow characteristics

Solenoid position		P→A/B		A/B→R1/R2	
		C [dm³/ (s•bar)]	b	C [dm³/ (s•bar)]	b
2	-position	2.3	0.29	1.8	0.24
	All ports closed	2.1	0.27	2.3	0.27
3-position	A/B/R connection	2.1	0.34	1.7	0.2
	P/A/B connection	2.2	0.34	2.4	0.29

Note 1: Effective sectional area S and sonic conductance C are converted as $S = 5.0 \times C$. Note 2: The value for 2 position and ABR connection is the value when a check valve is integrated.


Note 2: The value for 2 position and ABR connection is the value when a check valve is integrated

Regulator specifi	cations			
Set pressure range	MPa	0.2 to 0.7 Note 3		
Relief		With relief mechanism		
Port size		Rc3/8		
Filter specification	ons			
Filtration rating	μm	5		
Drain capacity	cm ³	45		
Port size		Rc3/8		

Note 3: Set pressure range will be limited by the working pressure of CXU30-4G2.

CXU3	80-M4	G2	Series

How to order



E20

1

3

G Rated voltage

GRated voltage

24VDC

- The 3 position all ports closed and P/A/B connection cannot be used with the check valve. Note 3: If port size, wire connection or voltage is
- different for each solenoid valve, the product will be processed as a customized order.
- Note 4: Standard filter regulator is N.O. automatic drain type. Multiple FR device options cannot be selected.
- Note 5: Model no. for IN side Left (FR device direction option "No symbol").
- Note 6: Two silencers (SLW-8S) are enclosed with one sub-base. Note 7: Refer to dimensions drawings for positions of solenoid valves ① to ④
- Note 8: When masking plates are used for all solenoid valves, wire connection and rated voltage options must be left blank.

Internal structure drawing

Models	Listed catalog and page no.
CXU30-4G2	Page 26
CXU10-MA	Page 39
CXU13-CA	Page 40
R2000	Catalog No.CB-024A
W3000	Catalog No.CB-024A

Valve air unit

Air unit component

E-connector Lead wire (500mm) with surge suppressor and light


100VAC (rectified bridge integrated)

CXU30-M4G2 Series

Dimensions

CXU30-M4G2 -A

E connector type (E) Cartridge fitting: Straight



Configuration table

No.	Product name	Model no.	
1	Piping adaptor Note 1	(FR component options -A)	
2	T type bracket	B310-W	
3	5 port pilot operated valve CXU30-4G2-*		
4	T type bracket	B310-W	
5	Module transform adaptor	CXU13-CA-00	
6	Masking adapter	CXU10-MA-00	

Note 1: The final product may differ depending on FR component options.


Solenoid valve and modular sub-base quantity

Model no.	Solenoid valve qty.	Modular sub-base qty.
CXU30-M4G2-①②	2	1
CXU30-M4G2-①②③④	4	2


Note: Masking plate count as a solenoid valve quantity. There will be 2 solenoid valves for each modular sub base.

Dimensions

 DIN terminal box type B Cartridge fitting: Straight 2-position single solenoid




Double, 3 position




Note: The DIN terminal box assembly is shipped facing inward.

• ø6 push-in fitting L (rear)



● F.R. component option: regulator type CXU30-M4G2-**_*-^R_{RT8}-*-*



Pressure gauge dimensions

Pressure gauge (sold separately)	x	Y
G49D	(73)	ø43.5
G59D	(75.5)	ø52
G40D	(75)	ø42.5
G50D	(75)	ø52.5
G41D	(73.5)	ø42
G52D	(78.5)	ø52.5


Refer to catalog No. CB-024SA for the discrete model no. of the pressure gauge.

9

CXU30-M4G2 Series

Dimensions


● F.R. component option: filter regulator type CXU30-M4G2-**-*-^W_{WT8}-*-*



Pressure gauge dimensions

Pressure gauge (sold separately)	x	Y
G49D	(69.5)	ø43.5
G59D	(72)	ø52
G40D	(71.5)	ø42.5
G50D	(71.5)	ø52.5
G41D	(70)	ø42
G52D	(75)	ø52.5

● F.R. components option: reverse flow CXU30-M4G2-**-*-^R_{RT8}X-*-*



Note: When reverse flow option X is selected, the IN side and FR device are on the right. The solenoid valve is arranged in order from the left. The drawing at left is for the regulator.

Air unit component Discrete model no.

Overview

Air unit components are dasy to add on to existing units. It is also easily avaioable for maintenance as well. General purpose components can be purchased together and assembled with air unit components.

Features

- Modular connection of solenoid valves. Connect 2 port, 5 port valves to conventional F.R.L.s.
- ② Connect easily with a joiner Conventional piping materials and tubes are not used, so there is no possibility of foreign materials entry or pressure loss.
- ③ Various modular components available Modules can be split into four directions, twisted 90°, and resized.

Description of icons

module indents.



hread free

open type

In line


- ① Gasket connection on the IN side A gasket is required for connecting
- ② Can not be used at terminals Since there is no connection screw is provided, a masking adapter or piping adapter is required for use at the terminal.

③ Easy to expand stations IN structures are used on both s

IN structures are used on both sides of the module connection section, making it easy to expand stations.

④ Main inline

The component can be used as main inline. This structure is the opposite of the expandable type.



CONTENTS	
2 port pilot operated solenoid valve CXU10-EXA Series	14
2 port direct acting solenoid valve	16
CXU10-FAB3 Series	
 2 port direct acting solenoid valve CXU30-FAB4U Series 	18
 2 port pilot kick solenoid valve 	20
CXU30-ADK Series	20
2 port pilot operated solenoid valve	22
CXU30-FAD Series	
5 port pilot operated valve	24
CXU30-4G2 Series	
Contact confirmation switch	30
GPS2, MGPS2 Series	
Modular check valve	34
CXU10-CHV Series	26
 4 directional distributor CXU10-D4 Series 	36
CXU30-D4 Series	
 Turn adapter 	38
CXU10-TA Series	00
CXU30-TA Series	
Masking adapter	39
CXU10-MA Series	
Module transform adaptor	40
CXU13-CA Series	
 Bracket, joiner, O-ring/gasket, pipe plug 	41
B-W J-W ORING GASKET CXU-PP	

Series variation

Air unit component

<Solenoid valve>

Series	Major applications	JIS symbol	Model no.	
2 port pilot operated solenoid valve Coster Coster	Air blow		CXU10-EXA	
2 port direct acting solenoid valve	Air blow		CXU10-FAB3	
2 port direct acting solenoid valve The case of the case	Air blow		CXU30-FAB4U	
2 port pilot kick solenoid valve	ON/OFF of main		CXU30-ADK	
 2 port pilot operated solenoid valve Serie: In the solenoid valve 	ON/OFF of main		CXU30-FAD	
● 5 port pilot operated valve	Cylinder actuation	(e.g.) CXU30-4G2-13-C6-B-1	CXU30-4G2	
Contact confirmation switch Contact confirmation switch Contact confirmation switch Contact confirmation switch	Workpiece contact confirmation Clamp confirmation	(e.g.)	GPS2 MGPS2	

<Distributor, adaptor>

Ourise		Annelisetienee	Madalas	
Series	Major applications	Applications	Model no.	
Modular check valve IN Casket Stref fre (ref lige	Reverse flow prevention		CXU10-CHV	
• 4 directional distributor	Branch to 4 directions		CXU10-D4	
Saver Note 2		T	CXU30-D4	
Turn adapter	Convert module direction by 90°		CXU10-TA	
Some free open type			CXU30-TA	
 Masking adapter 	Masking the module	Sun o	CXU10-MA	
Module transform adaptor Saster Source were type	Connecting 1000 Series and 3000 Series		CXU13-CA	



Module			Port size (OUT)				Flow characteristics			
1000 Series	2000	ø4	ø6	ø8	1/8			1/2	C [dm³/ (s•bar)] Note 1	Page
•			•	•					1.4 to 3.2	14
•			•	•					1.2	16
	•					•			2.1	18
	•								11	20
	•								18	22
	•	•	•	•					2.2 to 2.7	24
•					•				-	30

Note 1: Effective sectional area S and sonic conductance C are converted as S \doteqdot 5.0 x C.

Note 2: CXU has port size.

· ·						
	Мос	dule	Port size			
	1000 Series	2000 3000 Series 4000	3/8	Page		
	•			34		
	•	•	•	36		
	•	•		38		
	•			39		
		•		41		


Valve air unit



2 port pilot operated solenoid valve for compressed air

CXU10-EXA Series

N.C. (normally closed) type, diaphragm structure type JIS symbol Modular connection with 1000 Series Ideal for modular component blow valves




Specifications

Descriptions	CXU10-EXA					
Working fluid	Compressed air					
Working pressure differential range MPa	0.01 to 0.7					
Max. working pressure MPa		0.	7			
Withstanding pressure MPa		1.()5			
Fluid temperature °C		0 to	55			
Ambient temperature °C		-5 to	55			
Atmosphere	Does	not contact water, co	orrosive or flammabl	e gas.		
Valve structure		Pilot operated dia	phragm structure			
Valve leakage cm ³ /min	10 or less					
Mounting	Flexible					
Port size (IN)	None					
Port size (OUT)	ø6 push-in fitting	ø6 push-in fitting L type	ø8 push-in fitting	ø8 push-in fitting L type		
C [dm ³ / (s·bar)] Note 2	1	.6		3		
b	0.	37	0.32			
Weight g Note 3	98	95	98	100		
Electrical specifications				ĺ		
Rated voltage	100VAC (50/60Hz), 24VDC Note 1					
Apparent power VA	1.2					
Power consumption W DC	0.6					
Heat proof class	В					
Protective structure		d wire type: IDX0 wit	h DIN terminal box:			
(IEC standards 529)	Lead wire type: IPX0, with DIN terminal box: IPX5					

Note 1: Voltage fluctuation range is ±10%

Note 2: Effective sectional area S and sonic conductance C are converted as S \doteqdot 5.0 x C.

Note 3: Models with DIN terminal box weighs 20g more.



options and voltage.

Note 2: Contact CKD for models with M12 connector cable.


2C

2H

2HS

CXU10-EXA Series Internal structure • external dimensions

Internal structure and parts list





No.	Parts name	Material	
1	Cover (Note 1)	PBT	Polybutylene terephthalate
2	Bush	NBR	Nitrile rubber
3	Coil assembly	—	—
4	Stuffing	PPS	Polyphenylene sulfide
5	Diaphragm assembly	H-NBR/PPS	Hydrogenated nitrile rubber/polyphenylene sulfide
6	Body	PA66	Polyamide resin
7	Spring	SUS	Stainless steel
8	Valve body	PBT	Polybutylene terephthalate
9	Gasket	H-NBR	Hydrogenated nitrile rubber
10	Pin	SUS	Stainless steel
11	Fitting		

Note 1 PA66, polyamide will be used if DIN terminal box is included.

Dimensions

Grommet lead wire type CXU10-EXA-*-2C-* Cartridge fitting: Straight







300


7

Elbow type fitting





• With DIN terminal box type (Pg7) type CXU10-EXA-*-2HS-*



Custom air unit

Valve air unit

Air unit component

Option dimensions


Option	Α	В	С	D	E
C6	27	ø6 push-in fitting	-	-	-
CL6	-	ø6 push-in fitting	31	37	18.5
C8	27	ø8 push-in fitting	-	-	-
CL8	-	ø8 push-in fitting	32	39	21



2 port direct acting solenoid valve

CXU10-FAB3 Series


NC (normally closed) Modular connection with 1000 Series Ideal for modular component blow valves



Specifications

-		
Descriptio	ns	CXU10-FAB3
Working fluid		Compressed air
Working pressure differential range MPa		AC: 0 to 1.0, DC: 0 to 0.6
Max. working pressu	ire MPa	1
Withstanding pressu	ire MPa	1.5
Fluid temperature	e ℃	AC: 5 to 60, DC: 5 to 40
Ambient tempera	iture °C	AC: 5 to 60, DC: 5 to 40
Atmosphere		Does not contact water, corrosive or flammable gas.
Valve structure		Direct acting poppet structure
Valve leakage	cm³/min	10 or less
Mounting		Flexible
Port size (IN)		None
Orifice	mm	3
C [dm³/(s·bar)]	Note 1	1.2
b		0.56
Weight	kg	0.25
Electrical specifi	cations	
Rated voltage		100VAC, 24VDC
Dated voltage VA	50Hz	At holding: 7.5, at starting 20
Rated voltage VA	60Hz	At holding: 5.5, at starting 17
	50Hz	4
Power consumption W	60Hz	3.4
	DC	6.5
Heat proof class		В

Note 1: Effective sectional area S and sonic conductance C are converted as $S \doteq 5.0 \times C$.




A Cautions for model No. selection

Note: Joiner set and a gasket included

CXU10-FAB3 series

Internal structure and parts list


• CXU10-FAB3




No.	Part name	Material	
1	Coil assembly	B class mold	ed coil
2	Plunger assembly	SUS, NBR	Stainless, nitrile rubber
3	O-ring	NBR	Nitrile rubber
4	Spring	SUS	Stainless steel
5	Body	PA66	Polyamide resin
6	Pin	SUS	Stainless steel
7	Fitting		


Dimensions


Grommet lead wire type
 CXU10-FAB3-*-2C-*
 Cartridge fitting: straight type





• With DIN terminal box (Pg7) type CXU10-FAB3-*-2HS-*









Custom air unit

Elbow type fitting





Option dimensions

Option	Α	В	С	D	E
C6	27	ø6 push-in fitting	-	-	-
CL6	-	ø6 push-in fitting	31	37	18.5
C8	27	ø8 push-in fitting	-	-	-
CL8	-	ø8 push-in fitting	32	39	21



2 port direct acting solenoid valve

CXU30-FAB4U Series


NC (normally closed)JIS syModular connection with 3000 SeriesInterchangeable with GFAB actuator assembly

JIS symbol OUT IN IN ROHS Expandable

Specifications

Descriptio	ns	CXU30-FAB4U		
Working fluid		Compressed air		
Working pressure differential range MPa		AC: 0 to 1.0, DC: 0 to 0.9		
Max. working pressu	ire MPa	1		
Withstanding pressu	ure MPa	1.5		
Fluid temperature	e ℃	AC: 5 to 60, DC: 5 to 40		
Ambient tempera	iture °C	AC: 5 to 60, DC: 5 to 40		
Atmosphere		Does not contact water, corrosive or flammable gas.		
Valve structure		Direct acting poppet structure		
Valve leakage cm ³ /m	nin (ANR)	10 or less		
Mounting		Flexible		
Dant size	IN	None		
Port size	OUT	Rc1/4		
Orifice	mm	4		
C [dm³/(s·bar)]	Note 1	2.1		
b		0.34		
Weight	kg	0.55		
Electrical specifi	cations			
Rated voltage		100VAC, 24VDC		
	50Hz	At holding: 15, at starting 40		
Rated voltage VA	60Hz	At holding: 11, at starting 35		
	50Hz	7.5		
Power consumption W	60Hz	6.5		
	DC	8		
Heat proof class		В		

Note 1: Effective sectional area S and sonic conductance C are converted as S \doteqdot 5.0 x C.




A Cautions for model No. selection

Note: Joiner set and a gasket included

CXU30-FAB4U series

Internal structure and parts list


• CXU30-FAB4U




No.	Part name	Material	
1	Coil assembly	B class mold	ed coil
2	Plunger assembly	SUS, NBR	Stainless, nitrile rubber
3	O-ring	NBR	Nitrile rubber
4	Spring	SUS	Stainless steel
5	Body	PPS	Polyphenylene Sulfide
6	Gasket	NBR	Nitrile rubber
7	Plate	SUS	Stainless steel
8	Body	ADC12	Aluminum alloy die-casting
9	O-ring	NBR	Nitrile rubber
10	Bottom plate	SPCC	Steel sheet
11	O-ring	NBR	Nitrile rubber


Dimensions


Grommet lead wire type
 CXU30-FAB4U-8L-2C-*





With DIN terminal box (Pg7) CXU30-FAB4U-8L-2HS-*








2 port pilot kick solenoid valve

CXU30-ADK Series

NC (normally closed) Diaphragm structure Modular connection with 3000 Series Suitable as modular component master valves




Specifications

	-			
Descriptio	ns	CXU30-ADK		
Working fluid		Compressed air		
Working pressure differential ra	nge MPa	AC: 0 to 1.0, DC: 0 to 0.7		
Max. working pressu	ire MPa	2		
Withstanding pressure (wa	ter) MPa	4		
Fluid temperature (No	ote 1) °C	Nitrile rubber: -10 to 60, fluoro rubber: 5 to 60		
Ambient tempera	iture °C	-10 to 60		
Atmosphere		Does not contact water, corrosive or flammable gas.		
Valve structure		Pilot kick poppet structure Diaphragm operated		
Valve leakage	cm³/min	10 or less		
Mounting		Flexible		
Port size		None		
Orifice	mm	12		
C [dm ³ /(s·bar)]	Note 2	10.4		
b		0.46		
Weight	kg	0.65		
Electrical specifi	cations			
Rated voltage		100VAC, 24VDC		
	50Hz	24		
Apparent power VA	60Hz	19		
	50Hz	10		
Power consumption W	60Hz	8		
	DC	11		
Heat proof class		В		

Note 1: To be unfrozen

Note 2: Effective sectional area S and sonic conductance C are converted as S \doteqdot 5.0 x C.



Note 1: Coil option 2C is available for rated voltage [1] only.


A Cautions for model No. selection

Note: Joiner set included

CXU30-ADK series


Internal structure and parts list

• CXU30-ADK



No.	Part name	Material	
1	Core assembly	sus	Stainless steel
2	Shading coil	Cu	Copper
3	Coil	—	—
4	Plunger assembly	SUS	Stainless steel
5	Plunger spring	SUS	Stainless steel
6	Kick spring	SUS	Stainless steel
7	Stuffing	С	Bronze casting
8	Spring	NBR (FKM)	Nitrile rubber (fluoro rubber)
9	Diaphragm assembly	SUS•NBR (SUS•FKM)	Stainless steel • nitrile rubber (stainless steel • fluoro rubber)
10	O-ring	NBR (FKM)	Nitrile rubber (fluoro rubber)
11	Body	ADC	Aluminum alloy die-casting
12	Plate cover	ABS	ABS resin

Dimensions






2 port pilot operated solenoid valve

CXU30-FAD Series

NC (normally closed) Diaphragm structure Modular connection with 3000 Series Suitable as modular component master valves




Specifications

	-			
Descriptio	ns	CXU30-FAD		
Working fluid		Compressed air		
Min. working pressure differen	nce MPa	0.1		
Max. working pressure differe	nce MPa	0.7		
Max. working pressu	ire MPa	0.7		
Withstanding pressu	ire MPa	1.4		
Fluid temperature	°℃	-10 to 60 (to be unfrozen)		
Ambient tempera	ture °C	-10 to 60		
Atmosphere		Does not contact water, corrosive or flammable gas.		
Valve structure		Pilot operated diaphragm structure		
Valve leakage cm ³ /m	nin (ANR)	10 or less		
Mounting		Flexible		
Port size		None		
Orifice	mm	15		
C [dm ³ /(s·bar)]	Note 1	18		
b		0.4		
Weight	kg	0.5		
Electrical specifi	cations			
Rated voltage		100VAC, 24VDC		
Apparent newsr 1/A	50Hz	7.5		
Apparent power VA	60Hz	5.5		
	50Hz	4		
Power consumption W	60Hz	3.4		
	DC	6.5		
Heat proof class		В		

Note 1: Effective sectional area S and sonic conductance C are converted as $S \doteq 5.0 \text{ x C}$.

Note 2: Depending on use, such as using with an extremely small flow rate or when the solenoid valve's secondary side is restricted, operation may be unstable at pressure differences less than 0.1 MPa.

How to order




A Cautions for model No. selection

Note: Joiner set included

CXU30-FAD series

Internal structure and parts list







No.	Part name	Material		
1	Coil assembly	B class molded coil		
2	Plunger assembly	SUS, NBR	Stainless, nitrile rubber	
3	O-ring	NBR	Nitrile rubber	
4	Spring	SUS	Stainless steel	
5	Stuffing	ADC	Aluminum alloy die-casting	
6	Diaphragm	U	Urethane rubber resin	
7	Body	ADC	Aluminum alloy die-casting	
8	Plate cover	ABS	ABS resin	


Dimensions


Grommet lead wire type
 CXU30-FAD-00-*-2C-*







CXU30-FAD-00-X1-2C-*





With DIN terminal box (Pg7) type CXU30-FAD-00-*-2HS-*





Valve air unit



5 port pilot operated valve

CXU30-4G2 Series

5 port solenoid valve for modular connection with 3000 Series



IN Gasket

xnandabl

:0 H


JIS symbol

2-position single solenoid




2-position double solenoid

3-position all ports closed




3-position ABR connection

3-position PAB connection



(e.g.) CXU30-4G2-13-C6-B-1



Common specifications				
Descriptions		Descriptions		
Type of valve /	operation method	Pilot operated soft spool valve		
Working flu	uid	Compressed air		
Max. working	pressure MPa	0.7		
Min. working	pressure MPa	0.2 (2 position, 3 position)		
Withstanding	pressure MPa	1.05		
Fluid tempe	erature °C	5 to 55		
Ambient te	mperature °C	-5 to 55 (to be unfrozen)		
Working er	nvironment	Does not contact water, corrosive or flammable gas.		
	A/B port	Push-in fitting ø4, ø6, ø8		
Port size	P port	None (connectable with 3000 Series)		
	R1, R2 port	Rc1/4		
Manual ove	erride	Locking/non-locking common type		
Pilot exhaust method		Main valve, pilot valve common exhaust type		
Lubrication Note 1		Not required		
Protective st	tructure Note 2	Dust proof		
Vibration /	impact m/s ²	50 or less / 300 or less		

Note 1: Use the turbine oil Class 1 ISO VG32 if lubricated.

Excessive or intermittent lubrication results in instable operation.

Note 2: Make sure water drops or oil, etc., do not come into contact.

IP65 (jet-proof type) is used for DIN terminal box specifications.

Note that the box must be fixed using the specified adaptive cord outer diameter and tightening torque.

Electrical specifications

Descrip	otions	Descriptions
Rated voltage	DC	24
	AC	100
Rated voltage flu	ctuation range	±10%
Holding current	24VDC	0.023 (0.025)
Note 3	100VAC	0.010 (0.012)
Power consumption	24VDC	0.55 (0.6)
	100VAC	0.55 (0.6)
Apparent power VA	100VAC	1.0 (1.2)
Heat proof cla	ass	В
Temperature increase °C		50
Surge suppressor		Standard
With indicator		light (standard)
Note 3: Values i	in narenthese	s include light

Note 3: Values in parentheses include light.

Weig	ght			(unit: kg)
			De	escriptions
	Solenoid po	sition	Discrete valve	Valve sub-base
Withou	t solenoid valve	: masking plate	0.02	
2-position	Single	E-connector	0.08	
		DIN terminal	0.1	
	Double	E-connector	0.1	0.32
		DIN terminal	0.14	
3-position	All ports	E-connector	0.11	
	closed	DIN terminal	0.15	

Weight: Discrete valve used ① + discrete valve ② + valve sub-base.

Refer to page 31 for solenoid valve model no. list.


CXU30-4G2 Series

Flow characteristics

Solenoid position		P→A/B		A/B→R1/R2	
		C [dm³/ (s•bar)]	b	C [dm³/ (s•bar)]	b
2-position		2.3	0.29	1.8	0.24
	All ports closed	2.1	0.27	2.3	0.27
3-position	A/B/R connection	2.1	0.34	1.7	0.2
	P/A/B connection	2.2	0.34	2.4	0.29

Note 1 : Effective sectional area S and sonic conductance C are converted as $S = 5.0 \times C$.

Note 2 : The value for 2 position and ABR connection is the value when a check valve is integrated.




A Cautions for model No. selection

- Note 1: The GWS*-8-S fitting can be mounted on the R1 port.
- Note 2: Check valve is provided as standard. The check valve specifications are not available for the 3-position all ports closed or P/A/B connection.
- Note 3: If port size, wire connection, option or voltage is different for solenoid valve ① ②, the product will
- be processed as a customized order.
- Note 4: Joiner set and a gasket included
- Note 5: Refer to dimensions drawings for positions of solenoid valves 1, 2.
- Note 6: When masking plates are used for all solenoid valves, indicated for wire connection and rated voltage options must be left blank.

CXU30-4G2 Series


Internal structure and parts list


2-position single solenoid
 E connector type




No.	Part name	Material
1	E connector socket assembly	_
2	Coil assembly	_
3	Pilot exhaust check valve	Nitrile rubber
4	Piston D assembly	—
5	Manual override	Resin
6	Piston room	Resin
7	Protective cover of manual override	Resin
8	Spool assembly	—
9	Plate	Resin
10	Body	Aluminum alloy die-casting
11	Piston S assembly	_
12	Сар	Resin
13	Modular sub-base qty.	Aluminum alloy die-casting
14	Fitting adaptor	Resin
15	Cartridge type push-in fitting	_
16	DIN terminal box assembly	_

2-position double solenoid
 E connector type





• DIN terminal box type B



52

52

^Dush-in fitting ø4, ø6, ø8 comm

49


3000 Series Module only 2×1 (P) Port

27.5

27.5

Dimensions

CXU30-4G2 Series



Dimensions

CXU30-4G2-1

• E connector type (E)

Cartridge fitting: Straight

24

CKD

23.5

47.5

28


33

 \square

27

CXU30-4G2 Series

Dimensions



23.5

ŝ

4

28

₽

CKD



Solenoid valve model no. table

	Option	Solenoid valve no.	
Solenoid valve switching position	Electric connection	Rated voltage	Solenoid valve no.
0			4G2-MP
	В	1	4GB219-00-BH-1
1	В	3	4GB219-00-BH-3
1	E20	1	4GB219-00-E20H-1
	E20	3	4GB219-00-E20H-3
	В	1	4GB229-00-BH-1
2	D	3	4GB229-00-BH-3
2	E20	1	4GB229-00-E20H-1
		3	4GB229-00-E20H-3
	В	1	4GB239-00-B-1
3		3	4GB239-00-B-3
3	E20	1	4GB239-00-E20-1
		3	4GB239-00-E20-3
	В	1	4GB249-00-BH-1
4	D	3	4GB249-00-BH-3
4	F20	1	4GB249-00-E20H-1
	E20	3	4GB249-00-E20H-3
	В	1	4GB259-00-B-1
5	В	3	4GB259-00-B-3
5	E20	1	4GB259-00-E20-1
	E20	3	4GB259-00-E20-3




Contact confirmation switch (gap switch) discrete

GPS2 Series

Port size: RC1/8 Nozzle size: ø1.5

CE ROHS CAD Face bias





Dimensions

DIN terminal box type B


•GPS2-*-*-*F


CKD






(L: With dial cover lock)





Note) The shape of the dial cover is different for models with dial cover lock. Refer to DIN terminal type on page 30 for its shape.



Note) The shape of the dial cover is different for models with dial cover lock. Refer to DIN terminal type on page 30 for its shape.

Custom air unit

Handled as a custom order




Gap switch manifold **MGPS2** Series


Nozzle diameter: ø1.5 (Standard) Station no.: 2 to 5 stations



How to order gap switch manifold









MGPS2 Series

Dimensions

Dimensions


- Manifold type (Lead wire type common terminal box: TL, TR)
 MGPS2-*-*-*** TL (TR)
- Manifold type (Lead wire type common terminal box: TL, TR)
 MGPS2-*-*-*CTL (CTR)





Station no.	n	Α
2 stations	2	29
3 stations	3	72
4 stations	4	115
5 stations	5	158

Note) The shape of the dial cover is different for models with dial cover lock. Refer to DIN terminal type on page 30 for its shape.



Note) The shape of the dial cover is different for models with dial cover lock. Refer to DIN terminal type on page 30 for its shape.



Modular check valve


Completely blocks reverse flow of fluid such as compressed air JIS symbol Modular connection with F.R.L. 1000 Series Intermediate takeout of air possible with branch port



Specifications

Descriptions	Descriptions
Working fluid	Compressed air
Max. working pressure MPa	1
Min. working pressure MPa	0.03
Withstanding pressure MPa	1.5
Port size	None
Working temperature °C	5 to 60
Product weight kg	0.08
Effective sectional area (IN⇒branching port) mm ²	28
(IN⇒OUT) mm²	28

How to order



A Cautions for model No. selection

Note 1: A joiner set (joiner/bolt/O-ring) and a gasket are included as standard.

Note 2: A joiner set (joiner/bolt/O-ring) and 2 gaskets are included as standard.


Note 3: A masking adaptor and a joiner set (joiner/bolt/ O-ring) and 1 gaskets are included as standard.

How to use



CXU10-CHV series


Internal structure and parts list




No.	Parts name	Material
1	Body	Polyamide
2	Valving element	Nitrile rubber (fluoro rubber)
3	Valve guide	Polyacetal
4	Coil spring	Stainless steel
5	Cover	Aluminum alloy
6	Stop pin	Stainless steel
7	O-ring	Nitrile rubber (fluoro rubber)

* The materials in () apply when option "A" is selected.

Dimensions







Safety precautions

CAUTION

Pipe after confirming the JIS symbol of the product.







4 directional distributor CXU10-D4·CXU30-D4 Series

Branches the joint section of a module in 4 directions. Joint section can be mounted and removed from 1 position. With pressure gauge mounting port.



Screw free


Gasket



Specifications

Descriptions	CXU10-D4	CXU30-D4	
Working fluid	Compressed air		
Max. working pressure MPa		1	
Withstanding pressure MPa	1.5		
Branching joint quantity	4		
Port size	None	Rc3/8, Rc1/2	
Working temperature °C	5 to 60		
Product weight kg	0.1	0.3	

How to order



How to order

CXU30-D4 - 15	5 - T 6		
JIS symbol		Symbol	Descriptions
Rc3/8 Rc1/2 Rc1/2		Option	
	A Option	Blank	Without pressure gauge port (blanking plug assembled)
		Т6	Pressure gauge port Rc1/8
Rc3/8		Т8	Pressure gauge port Rc1/4
		G401	With pressure gauge (G401)
		R1	Pressure switch with display PPD assembed

A Cautions for model No. selection

Note 1: The CXU30-D4 can be connected to the 2000/3000/4000 Series.

Note 2: There are four connections so the joiner set and gasket must be purchased and assembled separately.

Note 3: A joiner set (joiner/bolt/O-ring) and a gasket are included as standard.


How to use




CXU10-D4 · CXU30-D4 Series

Internal structure and parts list

• CXU10-D4





No.	Part name	Material					
NO.	Fart name	CXU10-D4	CXU30-D4				
1	Body	Polyamide resin	Aluminum alloy die-casting				
2	Blanking plug assembly	PBT resin, nitrile rubber, steel					
3	Gauge plug assembly	Polyamide resin, nitrile rubber, copper					
	Pressure gauge (G401)	PBT resin, nitrile rubber, polyacetal resin, polycarbonate resin, brass, steel					

Dimensions

• CXU10-D4


Rc1/2 20 2 40 56

Option dimensions

Option	X
T6	25.5
Т8	25.5
G401	25.5
R1	40


Rc3/8


• CXU30-D4



Option dimensions

Option	X
T6	30.5
Т8	30.5
G401	30.5
R1	45





Turn adapter CXU10-TA·CXU30-TA Series

How to use

Changes the joint section of a module in 90 directions. Changes the direction of modular component.




IN Gasket



Specifications

Descriptions	CXU10-TA	CXU30-TA			
Working fluid	Compressed air				
Max. working pressure MPa		1			
Withstanding pressure MPa	1.5				
Port size	None				
Working temperature °C	5 to 60				
Product weight kg	0.03	0.12			

How to order




A Cautions for model No. selection

- Note 1: The CXU30-TA can be connected to the 2000/3000/4000 Series.
- Note 2: A joiner set (joiner/bolt/O-ring) and a gasket are included as standard.


Internal structure and parts list

30


● CXU10-TA



10 ► Front




Cross section A-A




• CXU30-TA


Тор



Front



Cross section A-A






No.	Part name	Material						
	Part name	CXU10-TA	CXU30-TA					
1	Body	Polyamide resin	Aluminum alloy die-casting					

Side





Masking adapter CXU10-MA Series


Used for masking on the joint section of 1000 Series.

How to use



Specifications	
Descriptions	CXU10-MA
Working fluid	Compressed air
Max. working pressure MPa	1
Withstanding pressure MPa	1.5
Port size	None
Working temperature °C	5 to 60
Product weight kg	0.02

How to order




BH

T type bracket (B110-H-W)

A Cautions for model No. selection

Note 1: 1 O ring included. Note 2: Hexagon nut for fixing the T type bracket is included with the T type bracket.

Internal structure and parts list



Option dimensions

Option	Α	В	С
В	40	60	-
BH	45	65	I.D. "H"



Module transform adaptor

CXU13-CA Series

Connectable with 1000, 2000, 3000, 4000 Series

How to use



IN Gasket



Specifications

Descriptions	CXU13-CA
Working fluid	Compressed air
Max. working pressure MPa	1
Withstanding pressure MPa	1.5
Port size	None
Working temperature °C	5 to 60
Product weight kg	0.04


How to order


CXU13-CA - 00

Note: The CXU13-CA can be connected to the 2000/3000/4000 Series. A C1000-J100, C4000-J400 joiner set and gasket included.


Internal structure and parts list

• CXU13-CA






Тор




Front

Cross section A-A




Side

No.	Part name	Material
1	Body	Aluminum alloy die-casting








Bracket, joiner B-W·J-W Series O ring, gasket, pipe plug ORING, GASKET, CXU-PP Series

Model no.: B110-W·B110-H-W·B310-W·B410-W

Dimensions and applications

T type bracket set




U						Note						eries can be ad Series.	justed
	Model no.	Applicable model	Α	В	С	D	Ε	F	G	Н	I	J	κ
	B110-W	1000 Series	45	35	10	100	5.5	2	16	25	7	JAS0-2013	40
))	B110-H-W	1000 Series	45	35	10	100	5.5	2	16	30	7	JAS0-2013	45
	B310-W	2000 Series	60	45	10	125	7	-	22	27	-	JISB2401-P21	45
		3000 Series	00	45		125	'	'	22	21	1	JI3D2401-F21	45
	B410-W	4000 Series	60	45	10	125	7	7	22	37	7	JISB2401-P21	55

Fitting set

lodel no.: C1000-J100-W	
C4000-J400-W	

Applications

DM



Model no.	Applicable model	Α	В	С	D	E
C1000-J100-W	1000 Series	10	36	26	M3.5	JAS0-2013
	2000 Series					JIS
C4000-J400-W	3000 Series	21	44	32	M5	B2401-P21
	4000 Series					D2401-F21

O ring, gasket

Gasket

		Material: NBR
Model no.	Applicable model	Standards
C1000-ORING	1000 Series	JASO-2013
C1000-GASKET	1000 Selles	CKD only
C4000-ORING	2000 Series 3000 Series	JIS B2401-P21
C4000-GASKET		CKD only
Sold in sets of 5	pieces.	

Pipe plug



	Material: steel
Model no.	Thread standards
CXU-PP-6	R1/8
CXU-PP-8	R1/4
CXU-PP-10	R3/8
CXU-PP-15	R1/2
Noto: Banana n	ugo oro cold in oc

Note: Banana plugs are sold in sets of 5.

RoHS

CKD

Custom unit Model no. for custom combinations

General Description

Complicated pneumatic components can be constructed by purchasing customized units. This eliminates bothersome piping, and enables immediate use.

Features

- (1) Versatile combinations Versatile layouts reduce the labor hours required for design.
- ② Simplified order form

The CXU can be ordered with only 1 form, making purchasing and delivery management easy.

③ Reduce man-hours

The FR component and solenoid valve are connected as modules, eliminating work such as piping.

(4) Low profile

Piping free, fitting free sleek design. Ideal for use in limited space.

(5) Front access

Easy to expand, mount and remove from the front. Great for maintenance as well.

Description of icons

(1) Model no. for custom order only. Model no. that includes -UN is for custom combinations only. Can not be purchased individually.

Custom

order only

(2) Face to face dimensions

56mm	
0011111	
_	

Screw free

open type

Face to face dimensions are shown in the icon.

(3) Can not be used at terminals Since there is no connection screw is provided, a masking adapter or piping adapter is required for use at the terminal.



CONTENTS


- <F.R.L components, solenoid valve>
- Filter · regulator
- Reverse filter regulator
- Air filter
- Oil mist filter
- High performance oil mist filter
- Regulator
- Reverse regulator
- Lubricator
- Mechanical pressure switch
- Shut-off valve
- 2 port direct acting solenoid valve
- 2 port pilot kick solenoid valve
- 2 port pilot operated solenoid valve
- 5 port pilot operated valve
- <Distributor, adaptor>
- Modular check valve
- Distributor
- Piping adaptor
- L type piping adapter
- Masking adapter
- <Bracket, joiner>
- Joiner
- T type bracket

Custom unit

<F.R.L. components, solenoid valve>

Series	Model no.		dule		Page						
		1000 Series	ø4	ø6	ø8	1/8	1/4 3/8	3 1/2	i aye		
Filter•regulator	W1000							•	_		
1 E	W2000								-	54	
	W3000							\bullet	-		
	W4000										
Reverse filter • regulator	W1100						•		_		
	W3100									56	
U.S. C.S. C.S. C.S. C.S. C.S. C.S. C.S.	W4100								-		
Air filter	F1000							•			
	NEW F2000								_		
101 C	F3000		Ŏ					•		58	
Ψ.	F4000		Ŏ						_		
Oil mist filter	M1000										
	NEW M2000							• •		60	
	M3000							• •		60	
Ψ	M4000										
High performance oil mist filter	MX1000										
	MX3000							• •		62	
Ψ	MX4000							• •			
Regulator	R1000						•	•	-		
Regulator	R2000										
-	R3000		Ŏ							64	
	R4000		Ŏ					\bullet	-		
Reverse regulator	R1100							•			
1. States and the states of th	R2100) (
	R3100							• •		66	
	R4100										
Lubricator	L1000										
	L3000							• •		68	
T.	L4000		•							00	
Maghaniagl progeurs quitch			•								
Mechanical pressure switch	P1100						•			70	
	P4000							• •		70	
	P4100-UN		•					• •			
Shut-off valve	V1000									72	
	V3000							\bullet		12	
	V3010							• •		73	
2 port pilot operated solenoid valve					_	-			-		
	NEW CXU10-EXA-UN	•			•	•				74	
2 port direct acting solenoid valve	CXU10-FAB3-UN	•			•	•				75	
1	CXU30-FAB4U-UN									76	
2 port pilot operated solenoid valve	CXU30-ADK-UN		•							77	
	CXU30-FAD-UN		\bullet							78	
5 port pilot operated valve	CXU30-4G2-UN		•	•	•	•				79	

44



Series	Model no.	Mo	dule		Por	t siz	e (O	UT)		Page
	Model no.	1000 Series	3000 Series	ø6	ø8	1/8	1/4	3/8	1/2	гауе
Modular check valve	🕲 CXU10-CHV-UN	•								82
Distributor	D101-UN	•								
	D401-UN		•						•	83
	D300		•					\bullet		
4 directional distributor	CXU10-D4-UN	•								84
	CXU30-D4-UN		•							04
Piping adaptor	A100-UN	•				•	•	\bullet		85
	A400-UN		•				•	•	•	00
● L type piping adapter	A101-UN	•				•	•			85
3 0	A401-UN		•					\bullet		00
Masking adapter	CXU10-MA-UN	•								86
	CXU30-MA-UN		•							80
Module transform adaptor	CXU13-CA-UN	•	D							87

<Bracket, joiner>

Series	Model no.	Module	Height to pipe	Page	
Series	iniodel fio.	1000 Series 3000 Series	40 45	55	Faye
● T type bracket set	B110-UN				
	B110-UN-H				88
	B310-UN				00
Note: T bracket sets of different height can not be combined.	B410-UN			\bullet	
• Joiner	C1000-J100-UN	•			88
	C4000-J400-UN	•			00

Valve air unit

CXU series Series variation

Example of CXU10 Series custom combination specifications

1000 Series base

General Description


Customized combinations are customer-oriented combinations that meet user needs for diverse combinations. Place orders by filling out the specifications below.

More solenoid valve types, etc., are available than the conventional customized combinations.

Preparing custom combination specifications

① Indicate the full model in the model field for the required model.

- ② Indicate the installation position of the indicated model with a "○". Indicate "UP" or "DOWN" for the orientation.
- 3 Indicate a " \bigcirc " in the bracket and joiner fields.
- See individual pages for component ordering and details, etc.



Dimensions are calculated by totaling the face to face dimensions of each component. The bracket mounting position is also calculated.

	C	CXU10	Series	custom com	bina	tion	spe	cific	catio	ons	1	1000 S	erie	s base	
	Contact			Quantity	Se	ets				Issue					_
	Slip no.			Request date								iy name			_
										Conta Orde					-
										Orde	110.				-
	Model	no									Leav	e it bla	ank		
		CYLI4	۰ <u> </u>	- (• - I								contro			
		CAUI	0 - 0		\square				-		UND	contro		5.	
				1											
					Deele	note	the	diree	Hon o	f		sed a	in fl		
				Flow direction							npres	seu a	111 119	0w	
					as se										
				X1 Right→Left	Leave	e blar	nk wh	en n	o syn	ıbol i	s sele	ected.			
				•											
	★For product						Indicate	the inst	allation	position	in order	from the l	left as	seen from the front.	
	direction for o			ob direction, and the po	nt up/aow	'n									
					¥			¥							
1	Part r	name:	Face to face dimensions	Model no.	Direction				Mounting	a positic	n			Field for Engineers	1
				W1000-8-W		0				1					1
	Filter · regulat	or	40	W1100-			1	1	1						1
	Air filter		40	F1000-			1	1	1						1
	Oil mist filter		40	M1000-											1
	High performar	nce oil mist filter		MX1000-]
			40	R1000-											1
	Regulator*		40	R1100-				1							1
	Lubricator		40	L1000-8-W				0							1
	Pressure swi	tch	28	P1100-UN-		*2							*2		1
	Shut-off valve	e	40	V1000-											1
	2 port pilot operat	lod colonoid volue	40	CXU10-EXA-UN-		*2							*2		1
	2 poir pilor operal	leu solenolu valve	40			2							2		
				CXU10-FAB3-UN-CL8-		*2:			0	0			*2]
	2 port direct actir	na eolonoid valva	40	2HS-3		2.							2		
	2 port direct deti	ng solonola valvo	40	CXU10-FAB3-UN-		*2							*2		
piping adaptor included.													-		
is not a set of 2pcs. so	Modular cheo	k valve*	56	CXU10-CHV-UN-00-		*2	0						*2		
I in required fields.				MA			Ť								_
<u> </u>	Distributor*	-	28	D101-UN-00	_	*2							*2		_
	Pipe adaptor		21.5 28	A100-UN- A101-UN-	-										-
	L type piping			CXU10-MA-UN-00							0				-
	Masking ada	pter	10	CXU10-MA-UN-00							0				-
					-										-
					-										-
					-										-
se this field when using					-										-
roducts with different	_ ₽Į						1								1
ptions and port sizes,					1		1	-							1
tc.			1				1		1						1
			1		-				1						1
							1	1	1						1
		_					1	İ							1
	Thursday			Data UNUW	-	-		· · · ·		-					-
	T type bracke			B110-UN-W B110-H-UN-W			0	-+				_	-		-
	T type bracke	et set	*2	C1000-J100-UN-W				~					_		-
	Fitting set			C1000-J100-UN-W											Use the T-bracket at a set sp
				he mounting surface is 40									_		
				he mounting surface is 45		- /				da e a d					Single support joiners can b
				of the combination, a pipi I. (The horizontal direction					or mas	king ada	apter				for three or fewer station
	(0,000=10	<i>,</i>													double support joiners o
			Engineer Con	nment Field											used for five or fewer station
						-			Ar	proval	Inspe	ctor	Conta	ct	
									- 14	protai					
										protei	٩	_			
										provar	٩	ЦГ	Leav	ve it blank. approval stam	


CXU10 Series custom combination specifications

1000 Series base

Contact		Quantity	se	ets				Issue				
Slip no.		Request date								ny nam	e	
								Conta				
								Order	no.			
Model no.												
	0 — 111											
	0 01											
		<u> </u>	_									
		Flow direction										
		Blank Left→Right										
		X1 Right→Left										
For products with an asterisk					ndicate t	he insta	allation po	sition in	order fr	om the le	eft as se	en from the front.
Indicate up/down for the reg	ulator's knob o	direction, and the port up/do	wn directi	on								
for other components.			Ļ			↓ I						
Part name:	Face to face dimensions	Model no.	Direction			•	Mounting		<u> </u>			Field for Engineers
Fait fidilie.		W1000-	Direction					positioi	1			
Filterregulator	40	W1000-					_					
Air filter	40	F1000-										
Oil mist filter	40	M1000-										
High performance oil mist filter	40	MX1000-										
	40	R1000-										
Regulator*	40	R1100-										
Lubricator	40	L1000-										
Pressure switch	28	P1100-UN-		*2							*2	
Shut-off valve	40	V1000-										
	+0	CXU10-EXA-UN-										
2 port pilot operated solenoid valve	40			*2							*2	
		CXU10-FAB3-UN-										
				*2							*2	
2 port direct acting solenoid valve	40	CXU10-FAB3-UN-										
				*2							*2	
		CXU10-CHV-UN-00										
Modular check valve*	56			*2							*2	
Distributor*	28	D101-UN-00		*2							*2	
Pipe adaptor	21.5	A100-UN-										
L type piping adapter*	28	A101-UN-										
Masking adapter	10	CXU10-MA-UN-00										
							1					
Thurse has alref t				1			1	'	1	1	1	
T type bracket set		B110-UN-W B110-H-UN-W										
T type bracket set Fitting set	-Ζ	C1000-J100-UN-W	+									
Finding Set		10-1000-J100-UIN-W	1		1			1	1	1	1	

*1: The distance from the pipe center to the mounting surface is 40mm.
*2: The distance from the pipe center to the mounting surface is 45mm.
*3: When using the products at the end of the combination, a piping adapter (A100-UN, A101-UN) or masking adapter (CXU30-MA) must be used at the end. (The horizontal direction port does not have threads)

Engineer Co	mment Field	



Example of CXU30 Series custom combination specifications

2000, 3000 Series base

General Description


Customized combinations are customer-oriented combinations that meet user needs for diverse combinations. Place orders by filling out the specifications below.

More solenoid valve types, etc., are available than the conventional customized combinations.


Preparing custom combination specifications

① Indicate the full model in the model field for the required model.

- ② Indicate the installation position of the indicated model with a "○". Indicate "UP" or "DOWN" for the orientation.
- ③ Indicate a "〇" in the bracket and joiner fields.
- See individual pages for component ordering and details, etc.



The bracket mounting position is also calculated.



CXU30 Series custom combination specifications

2000, 3000 Series base

Valve air unit

Air unit component

Custom air unit

Handled as a custom order

Contact		Quantity sets				Issue	Issue					
Slip no.		Request date				Your company name						
·								Conta	act			
								Orde				
Model no.												
-	~ I II											
CXU3	0 — UI	N — () — (
		. ↓										
		Flow direction	7									
		Blank Left→Right	-									
		X1 Right→Left	-									
		3 • • •										
For products with an asterisk ((*) indicate un/	down			ndicate t	he insta	llation n	nsition in	order fro	m the lef	t as seen	from the front.
Indicate up/down for the regul			direction				indition p		0.00.00			
other components.												
			•			★						
Part name:	Face to face dimensions	Model no.	Direction				Mountir	ig positio	n			Field for Engineers
	50	W2000-						1				
Filter-regulator		W2100-										
	63	W3000-			<u> </u>		<u> </u>	1				
		W3100-										
Air filter	50	F2000-										
	63	F3000-										
Oil mist filter	50	M2000-										
	63	M3000-										
High performance oil mist filter	63	MX3000-										
	50	R2000-										
Regulator*		R2100-										
	63	R3000-										
		R3100-										
Lubricator	63	L3000-										
Pressure switch	80	P4000-										
	31.5	P4100-UN-		*2							*2	
Shut-off valve	63	V3000-										
		V3010-										
2 port direct acting solenoid valve	50	CXU30-FAB4U-UN-8L-		*2							*2	
2 port pilot operated solenoid valve	63	CXU30-FAD-UN-00-		*2							*2	
2 port pilot kick solenoid valve	63	CXU30-ADK-UN-00-		*2							*2	
vaive												
		CXU30-4G2-UN-						1				
5 port pilot operated valve	56			*2							*2	
		CXU30-4G2-UN-										
Distributor*	31.5	D401-UN-00-		*2							*2	
Distributor	42	D300-		2				-			2	
Pipe adaptor	*3	A400-UN-						+				
L type piping adapter*	31.5	A400-0N-						+				
Masking adapter	21.5	CXU30-MA-UN-00						+				
Iniasking adapter	21.3							+				
								+				
								+				
	l	l		L	I	I	I	1	I	I	I	
T type bracket set	*1	B310-UN-W										
Joiner set		C4000-J400-UN-W										

*1: The distance from the pipe center to the mounting surface is 45mm.
*2: When using the products at the end of the combination, a piping adapter (A400-UN, A401-UN) or masking adapter (CXU30-MA) must be used at the end. (The horizontal direction port does not have threads)

*3: Port size 8, 10, 15 are 20mm, 20 is 25mm.

Engineer Co	Engineer Comment Field						

Approval	Inspector	Contact

49

CKD

Example of CXU30 Series custom combination specifications

4000 Series base

General Description


Customized combinations are customer-oriented combinations that meet user needs for diverse combinations. Place orders by filling out the specifications below.


More solenoid valve types, etc., are available than the conventional customized combinations.

Preparing custom combination specifications

① Indicate the full model in the model field for the required model.

- ② Indicate the installation position of the indicated model with a "O". Indicate "UP" or "DOWN" for the orientation.
- 3 Indicate a " \bigcirc " in the bracket and joiner fields.
- See individual pages for component ordering and details, etc.





CXU30 Series custom combination specifications

4000 Series base

Valve air unit

Air unit component

Custom air unit

Handled as a custom order

Contact		Quantity	se	ets				Issue				
Slip no.		Request date						Your	compan	iy nam	ne	
·								Conta	act			
								Order				
Model no.												
CXU3	0 — UI	N — () — (J				
		V	1									
		Flow direction										
		Blank Left→Right										
		X1 Right→Left										
For products with an asterisk					ndicate	the insta	allation p	osition ir	n order fr	om the	left as se	een from the front.
	ulator's knob o	direction, and the port up/dow	n directi	on								
for other components.			. ↓			+						
Part name:	Face to face dimensions	Model no.	Direction				Mounting	g positio	n			Field for Engineers
		W3000-									1	
	63	W3100-										
Filterregulator		W4000-					1					
	80	W4000-										
	63	F3000-										
Air filter		F4000-										
	80				-							
Oil mist filter	63	M3000-										
	80	M4000-										
High performance oil mist filter	63	MX3000-			ļ		ļ					
	80	MX4000-										
	63	R3000-										
Regulator* -	00	R3100-										
	00	R4000-										
	80	R4100-									1	
	63	L3000-										
Lubricator	80	L4000-									1	
	80	P4000-										
Pressure switch	31.5	P4100-UN-		*2							*2	
	0.110	V3000-		-			1					
Shut-off valve	63	V3010-										
2 port direct acting solenoid valve	50	CXU30-FAB4U-UN-8L-		*2							*2	
2 port pilot kick solenoid valve	63	CXU30-ADK-UN-00-		*2							*2	
2 port pilot operated solenoid valve	63	CXU30-FAD-UN-00-		*2							*2	
					ļ		ļ					
		CXU30-4G2-UN-										
5 port pilot operated valve	56			*2							*2	
		CXU30-4G2-UN-		-							-	
Distributor*	31.5	D401-UN-00-		*2							*2	
Distributor	42	D300-										
Pipe adaptor	*3	A400-UN-										
L type piping adapter*	31.5	A401-UN-					1					
Masking adapter	21.5	CXU30-MA-UN-00					1					
							1				1	
<u> </u>												
	l	l			L	L	L				1	I
T type bracket set	*1	B410-UN-W										
Fitting set		C4000-J400-UN-W										

*1: The distance from the pipe center to the mounting surface is 55 mm.
*2: When using the products at the end of the combination, a piping adapter (A400-UN, A401-UN) or masking adapter (CXU30-MA) must be used at the end. (The horizontal direction port does not have threads)

*3: Port size 8, 10, 15 are 20mm, 20 is 25mm.

Engineer Comment Field						

Approval	Inspector	Contact

51

CKD

Example of CXU13 Series custom combination specifications

1000, 2000, 3000 Series mix

General Description


Customized combinations are customer-oriented combinations that meet user needs for diverse combinations. Place orders by filling out the specifications below.

More solenoid valve types, etc., are available than the conventional customized combinations.


Preparing custom combination specifications

① Indicate the full model in the model field for the required model.

- ② Indicate the installation position of the indicated model with a "○". Indicate "UP" or "DOWN" for the orientation.
- ③ Indicate a "〇" in the bracket and joiner fields.
- See individual pages for component ordering and details, etc.



Dimensions are calculated by totaling the face to face dimensions of each component. The bracket mounting position is also calculated.




CXU13 Series custom combination specifications

1000, 2000, 3000 Series mix

Contact		Quantity sets					Issue					
Slip no.		Request date					Your company name					
•								Conta				
								Orde				
								0100				
• • • • •												
Model no.												
CXU1	3 — UI	N — () — (
	• •											
		▼ 	7									
		Flow direction Blank Left→Right	-									
		X1 Right→Left	-									
		Right /Lon										
For products with an asterisk (*), inc	dicate un/down				Indicate t	he installati	on positior	in order fr	om the lef	t as seen fi	rom the fro	nt
Indicate up/down for the regulat		tion, and the port up/down direc	tion for oth									
components.			\perp			1						
Detromo	Foresta fore-	Modelar	V Dire -ti-			V	Marinal	a positi-				Field for Ecciments
Part name:	Face to face dimensions 40:1000	Model no.	Direction		1		iviountin	g position				Field for Engineers
Filter-regulator	50:2000 63:3000	W 100-			+	+						
	40:1000				+	1						
Air filter	50:2000 63:3000	F 000-										
Oil mint filter	40.1000	N 000			1	1	1	1				
Oil mist filter	50:2000 63:3000	M 000-										
High performance oil mist filter	40	MX1000-										
	63	MX3000-										
Regulator	40:1000 50:2000 63:3000	R 000-										
		R 100-										
Lubricator	40	L1000-										
	63	L3000-				_						
	80 28	P4000-				_						
Pressure switch	31.5	P1100-UN- P4100-UN-		*2		_					*2	
	40	V1000-										
Shut-off valve	63	V3000-			1		-					
		CXU10-EXA-UN-										
2 port pilot operated solenoid valve	40			*2							*2	
2 port direct acting solenoid valve	40	CXU10-FAB3-UN-		*2			1	1			*2	
2 port direct acting solehold valve	40			2							2	
2 port direct acting solenoid valve	50	CXU30-FAB4U-UN-8L-		*2							*2	
					-	_	-					
2 port pilot kick solenoid valve	63	CXU30-ADK-UN-00-		*2							*2	
		CXU30-FAD-UN-00-			-							
2 port pilot operated solenoid valve	63			*2							*2	
		CXU30-4G2-UN-			1	1		1				
5 port pilot operated valve	56	CXU30-4G2-UN-		*2		1		1			*2	
Modular check valve*	56	CXU10-CHV-UN-00		*2							*2	7
Module transform adaptor	16	CXU13-CA-00		*2							*2	
Distributor*	28 31.5	D101-UN-00- D401-UN-00-		*2		-	-	-			*2	
Distributor	42	D300-			+	+		-				
	21.5	A100-UN-			1	1						
Pipe adaptor	*3	A400-UN-			1	1	1	1				
L tupo nining adapter*	28	A101-UN-										
L type piping adapter*	31.5	A401-UN-										
Masking adapter	10	CXU10-MA-UN-00										
	21.5	CXU30-MA-UN-00			-							
							<u> </u>	<u> </u>				
T type bracket set		B110-H-UN-W										
T type bracket set	*1	B310-UN-W										
Joiner set		C1000-J100-UN-W										
Joiner set		C4000-J400-UN-W	1									

*1: The distance from the pipe center to the mounting surface is 45mm.
*2: When using the products at the end of the combination, a piping adapter (A*00-UN, A*01-UN) or masking adapter (CXU*0-MA) must be used at the end. (The horizontal direction port does not have threads)
*3: Port size 8, 10, 15 are 20mm, 20 is 25mm.

E	ngineer Comment Field	





Filter regulator Standard white series

W1000 · W2000 · W3000 · W4000 - W Series W1000 W2000

Introducing the 5µm dust removing element and 0.3µm tar removing element Port size: Rc1/8 to Rc1/2







A Model no.

3 000 0

0 0 0 0

Note 2

W

W 2 W

W

Ō 0 0 0

•

•

•

•

•

0

~

Note 5

Face to face 40mm

W3000

Face to face 63mm


How to order (W3000)-(8)- W -(Ζ Symbol Descriptions (White type) BPort size A Model no. B Port size 6 Rc1/8 8 Rc1/4 10 Rc3/8 15 Rc1/2 **C**Option C Option Blank With manual drain cock Automatic drain with manual override Drainage F (NO type: exhausts without pressurization) Note 3 Automatic drain with manual override F1 (NC type: no exhaust without pressurization) Blank Polycarbonate bowl Nylon bowl Bow Ζ material Μ Metal bowl D Attachment M1 With metal bowl, manual drain cock Note 4 Blank 5µm Element Υ 0.3µm (submicron) Blank 0.05 to 0.85MPa Pressure 0.05 to 0.35MPa L range Blank With relief mechanism Relief Non-relief type Ν Blank With standard pressure gauge (G401) т Without pressure gauge (gauge port assembled sealed) Pressure Т8 Port for mounting pressure gauge assembled open gauge T6 Note Cautions for model No. selection Compatibility with digital pressure sensor PPX R1 Note Pressure switch with display PPD assembly Note 1: The pressure switch with R1 indicator is black. Flow Blank Standard flow (left to right) Note 2: Select options for drainage, bowl material. element, and regulator sections. direction **X1** Reverse flow (right to left) When selecting options for several items, list D Attachment options in order from the top. Note 3: Refer to "Pneumatic, Vacuum and Auxiliary Blank Not included Components (catalog No. CB-024SA" for G49P G49D-8-P10 (L: G49D-8-P04) working conditions of the automatic drain. Note 4: A manual drain cock is provided on all drain discharges G59P G59D-8-P10 (L: G59D-8-P04) Note 5: Refer to "Pneumatic, Vacuum and Auxiliary G40P G40D-8-P10 (L: G40D-8-P04) Components (No.CV-024SA)" for max flow rate for option "Y" G50P G50D-8-P10 (L: G50D-8-P04) Note 6: When option "T6" is selected, only "Blank" or G41P G41D-8-P10 (L: G41D-8-P04) "R2" can be selected for the D attachment G52P G52D-8-P10 (L: G52D-8-P10) (included) R2 Note 6 Digital pressure sensor: PPX-R10N-6M

The digital pressure sensor PPX mounting port (Rc1/8) is assembled open.

Refer to "Modular type F.R.L. (No. CC-962)" and "Modular type F.R.L. 2000 Series (No. CC-982)" for details on specifications and internal structure.

Filter · Regulator Series

Dimensions





•		•						
Attached pressure gauge		2	X				Y	
Attached pressure gauge	W1000	W2000	W3000	W4000	W1000	W2000	W3000	W400
G49P	(73.5)	(73)	(69.5)	(74.5)	ø43.5	ø43.5	ø4:	3.5
G59P	(76)	-	(72)	(77)	ø52	-	Ø	52
G40P	(75.5)	(75)	(71.5)	(76.5)	ø42.5	ø42.5	ø4:	2.5
G50P	(75.5)	-	(71.5)	(76.5)	ø52.5	-	ø5	2.5
G41P	(74)	(73.5)	(70)	(75)	ø42	ø42	Ø4	42
G52P	(86)	(85.5)	(82)	(86)	ø52.5	ø52.5	ø5	2.5
R2	(74)	(73)	(69.5)	(75)	□ 30	□ 30		30

Option dimensions


Metal bowl (option)

with automatic drain (FM, F1M)





Standard manual drain cock (M1)



Dimensions table

Model no.	F1M	М	M1
woder no.	Α	В	С
W2000	-	-	147
W3000	163.5	143.5	154
W4000	187	166.5	177

CKD

Drain port

Drain port

Handled as a custom order



Reverse filter regulator Standard white series

W1100·W2100·W3100·W4100-W Series W1100 W2100

RoH.

Introducing the 5µm dust removing element and 0.3µm tar removing element, with back flow function, to the lineup. Ionizer purge gas flow control Port size: Rc1/8 to Rc1/2







How to order

How to order				A	Мо	del	no.
W3100-8-W-Z-				W 1 1 0	W 2 1	W 3 1	W 4 1 0
	Svr	nbol	Descriptions	ŏ	0 0	0	0
(White type)		ort siz	1				
A Model no. B Port size		6	Rc1/8				
		8	Rc1/4				
		0	Rc3/8				
		5	Rc1/2				
		-				1-4	
C Option	CO	ption		-	2, r	lot	93
		Blank	With manual drain cock				
	Drainage	F	Automatic drain with manual override				
	Note 4		(NO type: exhausts without pressurization)			Ē	Ē
		F1	Automatic drain with manual override				
		· · ·	(NC type: no exhaust without pressurization)				
		Blank	Polycarbonate bowl	\bullet		lacksquare	
	Bowl	Z	Nylon bowl	ullet	ullet	\bullet	
	material	М	Metal bowl		2 3 1 1 0 0	\bullet	
D Attachment		M1	With metal bowl, manual drain cock Note 5		lacksquare	\bullet	
		Blank	5µm		\bullet	\bullet	
	Element	Y	0.3µm(submicron) Note 6			\bullet	
	Pressure	Blank	0.05 to 0.85MPa		\bullet		
	range	L	0.05 to 0.35MPa	\bullet	\bullet	\bullet	
		Blank	With relief mechanism				
	Relief	N	Non-relief type				
			With standard pressure gauge (G401)				
		T	Without pressure gauge (gauge port assembled sealed)				
	Pressure		Port for mounting pressure gauge assembled open				
Cautions for model No. selection	gauge	T6 Note 7	Compatibility with digital pressure sensor PPX	-			
ote 1: The pressure switch with R1 indicator is black.		R1 Note 1	Pressure switch with display PPD assembly	1 1			
lote 2: Select options for drainage, bowl material,	Flow		Standard flow (left to right)				
element, and regulator sections. When selecting options for several items, list							
options in order from the top.	direction		Reverse flow (right to left)			_	_
ote 3: Position of the check valve and pressure gauge	D At	ttachm	ient				
can not be changed. If the reverse direction of IN and OUT are	Bla	ank	Not included	\bullet	ullet	lacksquare	
required, indicate "X1" in the end of optional	G4	I9P	G49D-8-P10 (L: G49D-8-P04)		ullet	ullet	
section.	G5	59P	G59D-8-P10 (L: G59D-8-P04)			\bullet	
lote 4: Refer to "Pneumatic, Vacuum and Auxiliary Components (catalog No. CB-024SA" for	G4	IOP	G40D-8-P10 (L: G40D-8-P04)	\bullet	\bullet	lacksquare	
working conditions of the automatic drain.	G5	50P	G50D-8-P10 (L: G50D-8-P04)				
ote 5: All drainage type will have an manual drain	G4	I1P	G41D-8-P10 (L: G41D-8-P04)		\bullet		•
cock.						Ĩ	

- Note 6: Refer to "Pneumatic, Vacuum and Auxiliary Components (No.CV-024SA)" for max flow rate for option "Y".
- Note 7: When option "T6" is selected, only "Blank" or "R2" can be selected for the pressure gauge (included). The digital pressure sensor PPX mounting port (Rc1/8) is assembled open.

Refer to "Modular type F.R.L. (No. CC-962)" and "Modular type F.R.L. 2000 Series (No. CC-982)" for details on specifications and internal structure.

G52P

R2 Note 7


G52D-8-P10 (L: G52D-8-P10)

Digital pressure sensor: PPX-R10N-6M 🕒 🌑 🗨



Filter · Regulator Series

Dimensions





Attached pressure gauge		2	K			Y					
Attached pressure gauge	W1000	W2000	W3000	W4000	W1000	W2000	W3000	W4000			
G49P	(73.5)	(73)	(69.5)	(74.5)	ø43.5	ø43.5	ø43	3.5			
G59P	(76)	-	(72)	(77)	ø52	-	ø52				
G40P	(75.5)	(75)	(71.5)	(76.5)	ø42.5	ø42.5	ø42.5				
G50P	(75.5)	-	(71.5)	(76.5)	ø52.5	-	ø52	2.5			
G41P	(74)	(73.5)	(70)	(75)	ø42	ø42	ø4	2			
G52P	(86)	(85.5)	(82)	(86)	ø52.5	ø52.5	ø52.5				
R2	(74)	(73)	(69.5)	(75)	□ 30	30		30			

Option dimensions


Metal bowl (option)

With automatic drain (FM, F1M)





Standard manual drain cock (M1)



Drain port

Dimensions table

Model no.	F1M	М	M1
woder no.	Α	В	С
W2100	-	-	147
W3100	163.5	143.5	154
W4000	187	166.5	177

CKD



Air filter Standard white series

F1000 · F2000 · F3000 · F4000 - W Series F1000 F2000

Introducing the 5µm element for dust removal and 0.3µm element for tar removal Port size: 1/8 to 1/2 JIS symbol




Face to face 50mm

F4000

Face to face 80mm

A Model no.

How to order



Note 3: All drainage type will have an manual drain cock.

œ

96

6

OUT

Dimensions

IN


Inner diameter ø4


soft nylon tube


Drain port

40

F1000







43


Maintenance dimensions

Air Filter Series

Dimensions




•F3000




 Regarding the plastic bowl, the same dimensions apply for the type with manual cock or automatic drain.





• Regarding the plastic bowl, the same dimensions apply for the type with manual cock or automatic drain.

Metal bowl (option)




Dimensions table


Model no.	F1M	М	M1
Model no.	Α	В	С
F2000	-	-	147
F3000	164	143.5	154
F4000	187	166.5	177

Pipe center

With petcock (M)



Standard manual drain cock (M1)



Refer to "Modular type F.R.L. (No. CC-962)" and "Modular type F.R.L. 2000 Series (No. CC-982)" for details on specifications and internal structure.



Oil mist filter Standard white Series

JIS symbol

M1000·M2000·M3000·M4000-W Series


Ideal for circuits susceptible to oil, including measuring, and instrumentation circuits Port size: 1/8 to 1/2



CAD

G

How to order



Cautions for model No. selection

- Note 1: Select the option for drainage, bowl material and mantle and flow direction. When selecting options for several items, list
- options in order from the top. Note 2: N.O. automatic drain cannot be selected.
- Note 3: Refer to "Pneumatic, Vacuum and Auxiliary Components (catalog No. CB-024SA" for working conditions of the automatic drain.
- Note 4: All drainage type will have an manual drain cock.
- Note 5: Combination with option F1 is not possible.

Dimensions

IN

Inner diameter ø4

soft nylon tube

Drain port

h

• M1000

Note 6: Not selectable with "M" and "X". Replace the element before the differential pressure indicator becomes red.


The differential pressure indicator functions only when compressed air is flowing. Please be warned that only pressurizing it will not operate it.

OUT

96

			A	Мо	del	no.
			M 1 0 0	M 2 0 0	M 3 0 0	M 4 0 0
Syn	nbol	Descriptions	0	0	0	0
BPo	ort size	9	0			
(6	Rc1/8	\bullet			
8	3	Rc1/4	\bullet	\bullet		ullet
1	0	Rc3/8				\bullet
1	5	Rc1/2				\bullet
CO	otion			1	lot	e 1
Drain	Blank	With manual drain cock				
Discharge	F1	Automatic drain with manual override				
Note 2, Note 3	F1	(NC type: no exhaust without pressurization)				
	Blank	Polycarbonate bowl				
Bowl	Z	Nylon bowl				
material	М	Metal bowl				
	M1 With metal bowl, manual drain cock Note			\bullet		
Mantle	Mantle Blank M type (nominal 0.01 m; remaining oil 0.01 mg/m ³ or less		lacksquare	lacksquare	lacksquare	lacksquare
	(element) S S type (0.3 m; remaining oil 0.5 mg/m ³ or less				lacksquare	lacksquare
(cicilient)	X Note 5 X type (deodorization; remaining oil 0.03 mg/m					\bullet
Diversi pesar inicity	Q1 Note 6	With differential pressure indicator				\bullet
Flow	Blank	Standard flow (left to right)	\bullet	lacksquare	lacksquare	\bullet
direction	X1	Reverse flow (right to left)	lacksquare	lacksquare	lacksquare	lacksquare

M2000



Tube center M5 Drain port

43


μün


8 Maintenance dimensions

Oil Mist Filter Series


Dimensions

Dimensions







the type with manual cock or automatic drain.




With differential pressure indicator (option) Q1






Metal bowl (option)


Metal manual cock With automatic drain (F1M)



With petcock (M)



Standard manual drain cock (M1)



Dimensions table

Model no.	F1M	М	M1
Model no.	Α	В	С
M2000	-	-	147
M3000	164	143.5	154
M4000	187	166.5	177

Refer to "Modular type F.R.L. (No. CC-962)" and "Modular type F.R.L. 2000 Series (No. CC-982)" for details on specifications and internal structure.



High performance oil mist filter Standard white Series

MX1000·MX3000·MX4000-W Series

Secondary side oil concentration 0.001 mg/m³

Suitable for optical equipment such as optical positioning units and laser processing machines Port size: 1/8 to 1/2





• 0

RoHS


MX1000

Face to face 40mm

MX3000 Face to face

63mm

How to order



Flow

direction

Blank

X1

Standard flow (left to right)

Reverse flow (right to left)


JIS symbol


- material and differential pressure direction. When selecting options for several items, list options in order from the top.
- Note 2: N.O. automatic drain cannot be selected. Note 3: Refer to "Pneumatic, Vacuum and Auxiliary Components (catalog No. CB-024SA" for
- working conditions of the automatic drain.


Note 4: All drainage type will have an manual drain cock.

Dimensions










Oil Mist Filter Series

Dimensions


Dimensions

• MX3000




 Regarding the plastic bowl, the same dimensions apply for the type with manual cock or automatic drain.


• MX4000




 Regarding the plastic bowl, the same dimensions apply for the type with manual cock or automatic drain.

Metal bowl (option)





Standard manual drain cock (M1)



Drain port

Dimensions table

Model no.	F1M	М	M1
woder no.	Α	В	С
MX3000	164	143.5	154
MX4000	187	166.5	177

Refer to "Modular type F.R.L. (No. CC-962)" for details on specifications and internal structure.



Regulator Standard white series

R1000/R2000/R3000/R4000-W Series

RoHS

Compact pressure gauge embedded. Port size: Rc1/8 to Rc1/2






How to order				A	Мо	del	no
R3000-8-W-L-G49P				R 1 0 0	R 2 0 0	R 3 0 0	R 4 0 0
(White type)	Syn	nbol	Descriptions	0	0	0	C
	BPc	ort siz	9				
A Model no. B Port size	(6	Rc1/8	\bullet			
	1	8	Rc1/4	ullet	\bullet	\bullet	
	1	0	Rc3/8				
	1	5	Rc1/2				
	© 0	otion			ľ	Not	е
C Option	Pressure	Blank	0.05 to 0.85MPa				
	range	L	0.05 to 0.35MPa		lacksquare	ullet	(
	Dallaf	Blank	With relief mechanism		lacksquare	lacksquare	(
	Relief	N	Non-relief type		lacksquare	lacksquare	[
		Blank	With standard pressure gauge (G401)		\bullet	\bullet	1
		т	Without pressure gauge (gauge port assembled sealed)				1
	Pressure	тв	Compatibility with round shaped pressure gauge option				
	gauge		(pressure gauge mounting port assembled open)				[
		T6 Note 2	Compatibility with digital pressure sensor PPX				Γ
		R1 Note 3	Pressure switch with display PPD assembly				Γ
	Flow	Blank	Standard flow (left to right)				[
	direction	X1	Reverse flow (right to left)				[
	D At	tachn	nent				
Attachment Cautions for model No. selection	Bla	ank	Not included				6
	G4	9P	G49D-8-P10 (L: G49D-8-P04)				1
Note 1: When selecting options for several items, list options in order from the top. Note 2: When option "T6" is selected, only "Blank" or "R2" can be selected for the pressure gauge (included).		9P	G59D-8-P10 (L: G59D-8-P04)				1
		0P	G40D-8-P10 (L: G40D-8-P04)	•			1
		0P	G50D-8-P10 (L: G50D-8-P04)				1
The digital pressure sensor PPX mounting port (Rc1/8) is assembled ventilated.	G4	1P	G41D-8-P10 (L: G41D-8-P04)				[
Note 3: The pressure switch with R1 indicator is black.	G5		G52D-8-P10 (L: G52D-8-P10)	•	ullet	ullet	[
	R2	Note 2	Digital pressure sensor: PPX-R10N-6M				6

Refer to "Modular type F.R.L. (No. CC-962)" for details on specifications and internal structure.

Regulator Series

Dimensions



(73)

(69.5)

(75)

30


30



Reverse regulator Standard white series

R1100/R2100/R3100/R4100-W Series

From secondary pressure to primary pressure with back flow function. Port size: Rc1/8 to Rc1/2



RoHS CAD



How to order				A	Mod	lel r	no.
R3100-8-W-L-G49P				R 1 1 0	2 1 0	R 3 1 0	R 4 1 0
(White type)	Syr	nbol	Descriptions	0	0	0	0
	BP	ort siz	9				
A Model no. B Port size		6	Rc1/8	ullet			
		8	Rc1/4	ullet	\bullet	\bullet	
	1	0	Rc3/8		\bullet	\bullet	
	1	15	Rc1/2				ullet
	C 0	ption	No	ote '	1, N	ote	e 2
© Option	Pressure	Blank	0.05 to 0.85MPa	\bullet	\bullet	\bullet	
	range	L	0.05 to 0.35MPa	ullet	•		
	Relief	Blank	With relief mechanism	ullet	•	•	
	Relief	Ν	Non-relief type	ullet	•	\bullet	
		Blank	With standard pressure gauge (G401)	ullet			
		Т	Without pressure gauge (gauge port assembled sealed)	ullet	\bullet		
	Pressure gauge	Т8	Compatibility with round shaped pressure gauge option (pressure gauge mounting port assembled open)	•	•	•	•
		T6 Note 3	Compatibility with digital pressure sensor PPX	ullet	\bullet	\bullet	
		R1 Note 4	Pressure switch with display PPD assembly	ullet			
	Flow	Blank	Standard flow (left to right)	ullet	•	•	
	direction	X1	Reverse flow (right to left)	ullet	\bullet	\bullet	\bullet
Attachment	DA	ttachn	nent				
Cautions for model No. selection	Bl	ank	Not included	\bullet	\bullet	\bullet	
Note 1: When selecting options for several items, list	G	19P	G49D-8-P10 (L: G49D-8-P04)	lacksquare	•	\bullet	
options in order from the top.	G	59P	G59D-8-P10 (L: G59D-8-P04)	lacksquare		\bullet	
Note 2: Position of the check valve and pressure	G4	40P	G40D-8-P10 (L: G40D-8-P04)	lacksquare	\bullet	\bullet	
gauge can not be changed. If the reverse direction of IN and OUT are required, indicate	G	50P	G50D-8-P10 (L: G50D-8-P04)	lacksquare		\bullet	\bullet
"X1" in the end of optional section.	G	41P	G41D-8-P10 (L: G41D-8-P04)	ullet	\bullet	\bullet	\bullet
Note 3: When option "T6" is selected, only "Blank" or "R2" can be selected for the pressure gauge		52P	G52D-8-P10 (L: G52D-8-P10)	ullet	\bullet	\bullet	ullet
(included). The digital pressure sensor PPX	R2	Note 3	Digital pressure sensor: PPX-R10N-6M	lacksquare	\bullet	\bullet	\bullet


mounting port (Rc1/8) is assembled ventilated.

Note 4: The pressure switch with R1 indicator is black.

Refer to "Modular type F.R.L. (No. CC-962)" for details on specifications and internal structure.

Regulator Series

Dimensions





Lubricator Standard white series L1000/L3000/L4000-W Series

Supply fine mist oil. Port size: Rc1/8 to Rc1/2

JIS symbol

ROHS CAD

L1000

Face to face

L3000 Face to face

63mm


L4000

Face to face

80mm

A Model no.

How to order



A Cautions for model No. selection

Note 1: When selecting options for several items, list options in order from the top.


Note 2: The adjusting dome is made of polycarbonate for a nylon bowl or metal bowl. Consult with CKD if a different material is required.

Drain discharge and bowl material combination ("C" in How to order)
Option With float switch

	3000, 4000 Series				
Shape					
Material	Plastic bowl		Metal bowl		
wateria	Polycarbonate	Nylon	Aluminum		
Lubricator L* 000	LL	LLZ	LLM		

Т L Т 3 0 0 4 1 0 0 0 ŏ 0 Ó 0 Symbol Descriptions BPort size 6 Rc1/8 • 8 Rc1/4 0 • 10 Rc3/8 • 15 Rc1/2 **C**Option Blank No manual cock Drainage С With manual cock LL With float switch 0 Blank Polycarbonate bowl Bowl Ζ Nylon bowl material Μ Metal bowl Flow Blank Standard flow (left to right) direction X1 Reverse flow (right to left)

Dimensions




Refer to "Modular type F.R.L. (No. CC-962)" for details on specifications and internal structure.



Mechanical pressure switch Standard white series

P4000-W Series


Wide pressure setting range covers 0.1 to 0.8 MPa. Port size: Rc1/4 to Rc1/2






Face to face

How to order



Dimensions



Refer to F.R.L. unit section on "Pneumatic, Vacuum and Auxiliary Components (No. CB-024S)" for specifications, internal structure and safety precautions.

Valve air unit


CKD




Reed switch type compact mechanical pressure switch P1100 • P4100-UN- Series Modular design with F.R.L.



How to order (modular connection compatible)



Dimensions



Custom

order only

CAD



Shut-off valve Standard white series


V1000·V3000-W Series

1 action exhaust operation, prevent accidents caused by residual pressure. Port size: Rc1/8 to Rc1/2






How to order



Dimensions



* The EXH port is dedicated for installation of the silencer.

Refer to "Modular type F.R.L. (No. CC-962)" for details on specifications and internal structure.



Lockout valve (OSHA compliant)

V3010-W Series

Prevent accidents caused by residual pressure. Port size: 1/4 to 1/2



How to use

Regular use

OSHA (Occupational Safety and Health Administration)


OSHA established US Safety Standards related to related to worker safety.

<Regulations for lockout / tagout >

How to order

When servicing or maintaining machinery, the air source shall be closed with a shut-off valve (lockout valve), and residual pressure shall be discharged. If a third party inadvertently operates the valve during such operation and compressed air is applied, the cylinder, etc., could move suddenly and injure personnel. This standard states that, "All valves used for such purposes shall have a key or a structure which can be locked with a key."





Face to face


63mm


CAD



Dimensions

•V3010






* The EXH port is dedicated for installation of the silencer.

Descriptions	С
V3010-8-W	Rc1/4
V3010-10-W	Rc3/8
V3010-15-W	Rc1/2

Air unit component

Valve air unit




A Cautions for model No. selection

Note 1: Consult with CKD for applying the lock at the air supply position.


Note 2: Silencer element is not flame resistant.



2 port pilot operated solenoid valve for compressed air



How to order



Select from the circle mark above.

Dimensions


Grommet lead wire type CXU10-EXA-UN-* -2C-* Cartridge fitting: straight type

28


15

7005

40




• With DIN terminal box type (Pg7) type CXU10-EXA-UN-* -2HS-*



Elbow type fitting

IN



Option dimensions

Option	Α	В	С	D	E
C6	27	ø6 push-in fitting	-	-	-
CL6	-	ø6 push-in fitting	31	37	18.5
C8	27	ø8 push-in fitting	-	-	-
CL8	-	ø8 push-in fitting	32	39	21



CXU10-FAB3 - UN - C6-2C- 3

A Port size (OUT)

B Coil option

C Rated voltage

2 port direct acting solenoid valve

CXU10-FAB3-UN Series Screw free open type

NC (normally closed) Modular connection with 1000 Series Ideal for modular component blow valves

Symbol

C6 CL6

C8

CL8

2C

2HS


1 3

BCoil option

A Port size (OUT)

ø6 push-in fitting

ø6 push-in fitting L type



Air unit component

Custom air unit

ø8 push-in fitting ø8 push-in fitting L type Grommet lead wire DIN terminal box with light, surge suppressor (Pg11) **C**Rated voltage 100 VAC 50/60Hz, 110 VAC 60Hz

Descriptions

Dimensions

of your order.

How to order

Grommet lead wire type CXU10-FAB3-UN-* -2C-* Cartridge fitting: straight type

28

 \oplus

Ŧ

B

40


57.

IN

* Model no. for custom order only.

Can not be purchased individually.

Refer to page 16 for the model no.



• With DIN terminal box (Pg7) type CXU10-FAB3-UN-* -2HS-*


28

¢,

- H-F-

4

24 VDC





Handled as a custom order

Elbow type fitting

OUT

IN





Option dimensions


Option	Α	В	С	D	E
C6	27	ø6 push-in fitting	-	-	-
CL6	-	ø6 push-in fitting	31	37	18.5
C8	27	ø8 push-in fitting	-	-	-
CL8	-	ø8 push-in fitting	32	39	21



2 port direct acting solenoid valve

CXU30-FAB4U-UN Series


NC (normally closed) Modular connection with 3000 Series




How to order CXU30-FAB4U-UN-8L-(2C 3 Symbol Descriptions A Coil option A Coil option 2C Grommet lead wire * Model no. for custom order only. 2HS DIN terminal box with light, surge suppressor (Pg11) Can not be purchased individually. BRated voltage Refer to page 18 for the model no. B Rated voltage 100 VAC 50/60Hz, 110 VAC 60Hz 1 of your order. 24 VDC 3


Dimensions

Grommet lead wire type
 CXU30-FAB4U-UN-8L-2C-*



With DIN terminal box (Pg7) type CXU30-FAB4U-UN-8L-2HS-*







2 port pilot kick solenoid valve

CXU30-ADK-UN Series

NC (normally closed) Diaphragm structure Modular connection with 3000 Series Suitable as modular component master valves

JIS symbol OUT




How to order CXU30-ADK-UN-00-(F)(2C)-(3 Symbol Descriptions A Selant A Selant Blank Nitrile rubber * Model no. for custom order only. Fluoro rubber F Can not be purchased individually. **B**Coil option Refer to page 20 for the model no. B Coil option 2C Grommet lead wire of your order. 2HS DIN terminal box with light, surge suppressor (Pg11) CRated voltage C Rated voltage 100 VAC 50/60Hz, 110 VAC 60Hz 1 3 24 VDC


* 1: Coil option 2C is available for rated voltage [1] only.

Dimensions

Grommet lead wire type
 CXU30-ADK-UN-00-* 2C-*



With DIN terminal box (Pg7) type CXU30-ADK-UN-00-* 2HS-*




Valve air unit



2 port pilot operated solenoid valve


CXU30-FAD-UN Series

NC (normally closed) Diaphragm structure Modular connection with 3000 Series Suitable as modular component master valves






How to order





Note 1: Depending on use, such as using with an extremely small flow rate or when the solenoid valve's secondary side is restricted, operation may be unstable at pressure differences less than 0.1 MPa.

Dimensions

Grommet lead wire type
 CXU30-FAD-UN-00-2C-*








Refer to FAD Series on "General Purpose Valves (No. CB-03-1S)" for specifications and internal structure.




5 port pilot operated valve CXU30-4G2-UN Series

5 port solenoid valve for modular connection with 3000 Series





Refer to page 29 for solenoid valve model no. list.



Refer to 4G Series on "Pneumatic Valves (No. CB-23SA)" for specifications and internal structure.


CKD

CXU30-4G2-UN Series


Dimensions




Cartridge fitting: straight type



 DIN terminal box type (B) Cartridge fitting: straight type



ø6 push-in fitting L (rear)



ß S3

4

28

ų 13

 Θ


Valve air unit

52

Push-in fitting 4, ø6, ø8 common

ŝ 27.

27.5



Dimensions


d mut





Modular check valve CXU10-CHV-UN Series

Completely blocks reverse flow of fluid such as compressed air J Modular connection with F.R.L. 1000 Series Intermediate takeout of air possible with branch port




How to order


CXU10-CHV - UN - 00 - 6 - A - X1

- * 1 Model no. for custom order only. Can not be purchased individually. Refer to page 34 for the model no. of your order.
- * 2 Piping adaptor and masking adaptor assembly is assembled on the top of the product.

	Symbo	ol	Descriptions		
	A Port	A Port size			
A Port size	6		Piping adaptor (Rc1/8") assembled		
	8		Piping adaptor (Rc1/4") assembled		
	10		Piping adaptor (Rc3/8") assembled		
	MA	I	Masking adapter assembled		
	B Optio	B Option			
B Option	Blank	.	No options		
	A	I	Fluoro rubber specification		
	C Flow	dire	ection		
G	low direction Blank		Standard flow (left to right)		
	X1	I	Reverse flow (right to left)		

Dimensions





Distributor Standard white series


D401-UN-W·D300-W Series

Applicable for pipe branching. Port size: Rc1/4 to Rc1/2




Face to face 42mm


D401 Face to face



Dimensions

• D300







Cross section A-A

Applications (D401-00-W)





4 directional distributor

CXU10-D4-UN·CXU30-D4-UN Series

Branches the fitting section of a module upto 4 directions. Fitting section can be mounted and removed from 1 position. With pressure gauge mounting port.



RoHS



How to order CXU10-D4 - UN - 00 - T6 JIS symbol Symbol Descriptions A Option A Option Blank Without pressure gauge port (blanking plug assembled) Т6 Pressure gauge port Rc1/8 Т8 Pressure gauge port Rc1/4 G401 With pressure gauge (G401) R1 Pressure switch with display PPD assembed How to order CXU30-D4 - UN - 15 - T6 JIS symbol


Rc3/8 Rc1/2 Rc1/2 Rc3/8


* Model no. for custom order only. Can not be purchased individually. Refer to page 36 for the model no. of your order.

Symbol	Descriptions					
A Option						
Blank	Without pressure gauge port (blanking plug assembled)					
Т6	Pressure gauge port Rc1/8					
Т8	Pressure gauge port Rc1/4					
G401	With pressure gauge (G401)					
R1	Pressure switch with display PPD assembed					

Dimensions


• CXU10-D4-UN






A Option

• CXU30-D4-UN






Option dimensions

-	
Option	X
Т6	30.5
Т8	30.5
G401	30.5
R1	45

Option dimensions

Option	Х
Т6	25.5
Т8	25.5
G401	25.5
R1	40

CKD



Piping adaptor, L type piping adaptor Standard white series

A100·A400-UN-W Series A101·A401-UN-W Series

Port size: Rc1/4 to Rc3/4, Rc1/4 to Rc1/2




* Model no. for custom order only. Can not be purchased individually. **Dimensions and applications Pipe adaptor** Applications (Model no.: A100-UN-6, 8, 10-W A400-UN-8, 10, 15, 20-W Model no. Port size Applicable model С Other Α В D A100-UN-6-W 1/8 A100-UN-8-W 1/4 1000 Series 21.5 13.5 40 36 A100-UN-10-W 3/8 A400-UN-8-W Rc1/4 2000, Port size A400-UN-10-W Rc3/8 3000 4000 20 6 Number withing the 50 45 A400-UN-15-W Rc1/2 Series Series (25) (11) parenthesis is Rc3/4 A400-UN-20-W Rc3/4 L type piping adapter How to order Symbol Descriptions (A101)- UN -(6)-(W A Model no. L type piping adapter A101 (White type) A401 L type piping adapter B Port size A Model no. B Port size A101 A401 6 1/8 8 1/4 10 3/8 •


> · Applicable models: · A101-UN-6, 8-W ··· 1000-W Series ·A401-UN-8, 10, 15-W ··· 2000, 3000, 4000-W Series

> > Applications

Dimensions







Front

Cross section A-A

Cross section A-A

15 1/2



CKD

85

Custom air unit

Valve air unit

Air unit component



Masking adapter CXU10-MA-UN CXU30-MA-UN Series


Used for masking on the fitting section.

CXU10-MA CXU30-MA Face to face Face to face Custom 10.5mm 21.5mm order only


How to order CXU10-MA-UN-00 CXU30-MA-UN-00

* Model no. for custom order only. Can not be purchased individually.

Internal structure and parts list



No.	Part name	Model no.
1	Module transform adaptor	CXU13-CA-00
2	O-ring	JASO-2013
3	Masking adapter	CXU10-MA-00



Module transform adaptor CXU13-CA-UN Series

Connectable with 1000, 2000, 3000, 4000 Series




Screw free open type


How to order CXU13-CA - UN - 00

* Model no. for custom order only. Can not be purchased individually. Refer to page 40 for the model no. of your order.

Dimensions


• CXU13-CA-UN-00






Тор






Front



Side


Valve air unit



Bracket, joiner B-UN-W, J-UN-W Series



Dimensions and applications * Model no. for custom order only. Can not be purchased individually. Refer to page 41 for the model no. of your order. T type bracket set • Model no: B110-UN-W•B310-UN-W•B410-UN-W • Applications • Applications




Note 1: B310-UN-W and B410-UN-W cannot be combined. Note 2: By using B110-UN-W, 1000 Series can be adjusted to the same height as 3000 Series.

Model no.	Applicable model	Α	В	С	D	Ε	F	G	н	I	κ
B110-UN-W	1000 Series	45	35	10	100	5.5	2	16	25	7	40
B110-UN-H-W	1000 Series	45	35	10	100	5.5	2	16	30	7	45
B310-UN-W	2000 Series	60	45	10	125	7	7	22	27	7	45
	3000 Series			45	45	10	125	· '	· '	22	21
B410-UN-W	4000 Series	60	45	10	125	7	7	22	37	7	55

Fitting set

Model no.: C1000-J100-UN-W C4000-J400-UN-W



Model no.	Applicable model	Α	В	С	D	
C1000-J100-UN-W	1000 Series	10	36	26	M3.5	
	2000 Series					
C4000-J400-UN-W	3000 Series	21	44	32	M5	
	4000 Series					

Order made air units

Overview

All air unit combinations are available as customized combinations from CKD.

Module connections in the vertical direction which is not available with customized units, are now available.

Features

1 Horizontal or vertical


Vertical and horizontal pipes can be arranged versatility. Solenoid valves can also be connected freely.

Unlimited flexibility

Module components not listed in this catalog are also available.

③ Reduce man-hours

All components are connected as modules, eliminating work such as piping.




CONTENTS

 Order made air units **CXUZ** Series

Custom air unit

Valve air unit

Air unit component



Air unit components can be combined depending on applications and space. Contact your sales office for combinations.

Related products (compatible modular combination products)

CXU10 (applicable model: 1000 Series)								
Model	Shut-off valve Precision regulator Electro-pneumatic re		Electro-pneumatic regulator	Reed switch type Compact mechanical pressure switch	High performance oil mist filter			
	V1000-W	RP1000	EVD-1000	P1100-W	MX1000-W			
Model no.								
Catalog No.	CC-962	CB-024S	CB-024S	CC-962	CB-024S			

CXU30 (applicable model: 3000, 4000 Series)									
Model	Slow start valve Precision regulator Electro-pnet		Electro-pneumatic regulator	Reed switch type Compact mechanical pressure switch	High performance oil mist filter				
Model no.	V3301-W V3321-W	RP2000	EVD-3000	P4100-W	MX3000-W MX4000-W				
Catalog No.	CC-962	CB-024S	CB-024S	CC-962	CB-024S				

MEMO

WORLD-NETWORK



exporter to make sure they will never be used for the development or the manufacture of weapons for mass destruction.
 Specifications are subject to change without notice.
 © CKD Corporation 2010 All copy rights reserved.