
## **Pressure control valves**



Pressure control valves are used to limit pump delivery pressure, control circuit pressure, and as safety valves. For these purposes there are relief valves and reducing pressure valves which maintain circuit pressure below set levels, and sequence and unload valves which automatically switch circuits when circuit pressure reaches setting pressure.