

Meeting the requirements of FA, compact and high torque DD actuator

DIRECT DRIVE ACTUATORS

ABSODEX



CB-32A 2

Eco-friendly, intelligent index units comptible with

different networks.

High precision/high performance

Combining 360° flexible index, intermittent revolution and continuous rotation, high precision absolute DD actuator is available now.

High Flexibility & Intelligence

Eco-friendly function

Energy and space savings, oil free and reuse, etc., environmentally friendly production equipment can be built.

Network function

One-touch connecting serial transmission slave station allows easy connection to different networks.





Return to origin not required

An absolute resolver that recognizes the current position is used without returning to origin.

Easy operation

Index time can be set directly per 0.01 second increment.

Compact/high torque

No torque down even in high speed range. (Excluding some models)

High precision positioning

Maintaining high resolution; 540672 pulses per rotation, high precision index is enabled. (Repeatability of index: ±5 ").

Easy installation and centering

Socket and spigot for mounting and thread hole are installed on rotational and fixed sections. Integrated wiring is achieved by hollow shaft.

Smooth cam curve drive

Cam curve of modified sine (MS), modified trapezoidal (MT), deformation constant velocity (MC, MC2) and tropecoid (TR) can be selected for different applications.

Dust proof structure

Sealing applied on rotational section of actuator (excluding some models) (AX8000 series is IP65 conformed.)



Energy saving

• Dedicating driver H type: high performance

S type: small/high performance GH type: high performance compatible type

GS type: small and high performance compatible type

Electric power is consumed during index, while no power is consumed during dewll time.

Change and waste of lubricant is not required.

Troublesome lubricant change and waste of oil are not required. No pollution by oil leakage.

To reduce equipment size by space saving body.

Origin detection sensor, reducer and motor, etc., are not required.

Easy change of specifications and reuse is possible.

Specifications can be changed by dialog terminal or PC, etc., also, reuse is possible, while difficult for mechanical index.



5 series available according to applications

AX2000 series
 convertible AX2000G series

AX4000 series
 convertible AX4000G series

CC-Link

 Serial transmission slave station

Body actuator

AX1000 series

AX5000 series
 AX8000 series

DeviceNet

 Dialog terminal Handy type Easy programming

Open network compatible

Compatible with 2 types of open network; CC-Link and DeviceNet

Reducing wiring cost

Drastic reduced wiring enables reduction of wiring man-hours.



AX2000G AX4000G series

Driver, actuator and cable are compatible. Flexible combination achieves easy maintenance and control.

Features

Return to origin not required

Integrating an absolute resolver that recognizes the current position when power turned on in the direct drive actuator, troublesome origin search operation is not required. Also, restart can be done from the current position after emergency stop.

Direct drive actuator resolver consists of 2 sets. One uses R/D conversion to split the sine waveform detected every 2.7° (360°/132) rotation angle into 4096. The other splits 360° into 4096 to detect the absolute position on 360°. No sensor for searching for the origin need to be used as with incremental method

The position information is recognized when power supply turned on, so back up memory is not required. This system has the reliable detection mechanism.

Index accuracy: ±15" (second), while ±30" (second) for AX3000

High resolution; 540672 pulses per rotation

Repeat positioning accuracy: ±5 " (second) *



Example of index accuracy measurement (with brake)



Example of index accuracy measurement (without brake)



High torque

High precision

and AX4000 series.

*1 " (second) = 1°/3600

Using PM type motor appropriate for indexing, this DD motor has excellent torque characteristics without torque-down even in high speed range.





Space saving

Compact and space saving direct drive actuator compared to circular table with [motor + reducer]



Smooth cam curve drive realized

5 types * of cam curve are provided as standard. Shock is suppressed to the minimum when moving or stopped. * modified sine (MS), modified trapezoidal (MT), deformation constant velocity (MC and MC2) and tropecid (TR) Four cam curves with the operating features below can be selected with parameters. This enables smooth transfer positioning not possible with simple acceleration/deceleration time setting control.

- Easy design Providing socket and spigot on fixing side of the body and table, easy centering is achieved.
- Easy connection Integration of driver and controller reduces man-hour of connection.
- Flexible programming

NC language enables positioning on the required point. Also, NC programs, up to 256 programs, can be stored in the driver.

Great variety of external interfaces

Program input, parameter setting and reading of inner state, etc., are allowed by RS-232C serial communication. Also, M code, etc., great variety of external interfaces, are

available to connect to the PLC.

Using serial transmission slave stations, 2 types of open network; CC-Link and Device-Net are also available.

Easy programming

An equal index program is created by interactively inputting the number of divisions and movement time, etc., with this dialog terminal (optional). This enables quick startup after the system is installed.

Complex operations are set by creating programs in NC language.

Driver program storage capacity is approximate 6000 characters maximum (256 programs). The use of Windows' communication software [Teaching note] allows a user to create and save programs with PC.

CE marking

CE marking products (option) conformed to the Low Voltage Directive and EMC Directive are available. Refer to the instruction manual for installation, etc., to conforming to standards.

Refer to " CKD European standards conforming products guide " for details of applicable models and conformity standards.

Low Voltage Directive

EN60034-1, EN60034-5, EN50178

EMC Directive

EN55011, EN61800-3, EN-61000-3-2, EN61000-3-3 Certificating body

TÜV Rheinland



- Optional dowel hole to positioning is available.
- Optional movable cable is available for cable bending applications.



Operating conditions Index angle 90° Index time 0.5 sec. Load moment of inertia 1.67 x 10² kg·m²

• Large diameter hollow (AX4000 and AX4000G series) This large hollow diameter specifications allow easy piping and wiring on dial plate. If a ball spline is installed, the product can be used for θ axis of a P & P unit for small parts conveyance.

(Consult with CKD for ball spline installation)

- Non-backrush model with negative actuation electromagnetic brake (option) is also available. (AX4000 and AX4000G series).
- Brake integrated type (AX5000 and AX8000 series) Integrated a pneumatic brake, the output shaft is clamped when stopped to increase holding rigidity.
 - Available for works that torque is applied to the table
 - Fine rotary vibration of table by servo is suppressed.
 - Holding torque more than the maximum output torque of actuator is provided.

(At 0.5MPa)



 High grade dust proof/waterproof (AX8000 series) IEC60529 standards IP65* conforming TÜV Rheinland certifications



Higher grade water proof is achieved by air purge.

*When performing an air purge, supply a dry clean compressed air with low pressure (0.05MPa).



Characteristics and measuring examples of cam curve

Direct drive motor compatible type series variation

| Carlos | | Torque (N·m) | | | | | | |
|------------------|----------------|---|---------|---------|---------|---------|---------|--|
| | Series | 6 | 12 | 18 | 22 | 45 | 75 | |
| ator | AX2000G series | O AX2006G | AX2012G | AX2018G | | | | |
| Actuat | AX4000G series | | | | AX4022G | AX4045G | AX4075G | |
| Available driver | GS type driver | The second se | | | | | | |
| | GH type driver | Not available | | | | | | |

| Examples of applications | Intro 10 |
|-------------------------------|----------|
| A Precautions | Intro 13 |
| Related parts model no. table | Page 71 |
| Selection quide | Page 73 |

| | | Torque (N⋅m) | | Torque (N·m) Index accuracy Repeat accuracy | | Repeat accuracy | | Dogo | |
|----------|---------|---------------|---------|---|--|---|---|---------------------------|------------|
| | 150 | 300 | 500 | (sec.) | (sec.) | Features | Applications | Page | AX |
| | | | | | | • High speed revolution (300rpm) • Compact with small | • P & P | 1 | 2000G AX40 |
| | | | | ±30 | ±5 | diameter Large hollow diameter (ø30) | Turntable Assembly machine | to 6 | 00G AX |
| | | | | | | | | | 000 |
| | | | | ±30 | ±5 | High speed revolution (AX4022GS, AX4045GS: 240rpm and AX4075GS: 140rpm) For large moment of inertia load | Turntable Inspection machine Assembly machine | 7 to | AX2000 |
| | AX4150G | AX4300G | AX4500G | | | (AX4150GH, AX4300GH and AX4500GH) Large hollow diameter and great variety of size options | • P & P | 10 | AX4000 |
| | | Not available | I | A single type | of driver can hand | dle all size of actuators. | | GS type 57 58 61 | AX5000 |
| I | | | | output, comm | and timer, etc., of a nunication to the e | an actuator flexibly. Also, u xternal PLC is possible. | sing M code | GH type 59 to 61 | AX8000 |

Direct drive actuator series variation

| Series | | Torque (N·m) | | | | | | | |
|----------|---------------|--|--------|--------|--------|--------|--------|--|--|
| | Series | 6 | 9 | 12 | 22(21) | 45(42) | 75(70) | | |
| Actuator | AX1000 series | | | | AX1022 | AX1045 | AX1075 | | |
| | AX2000 series | O AX2006 | | AX2012 | AX2021 | AX2042 | | | |
| | AX4000 series | | AX4009 | | AX4022 | AX4045 | AX4075 | | |
| | AX5000 series | | | | AX5022 | AX5045 | AX5075 | | |
| | AX8000 series | | | | | AX8045 | AX8070 | | |
| driver | S type driver | | | | | | | | |
| Availabl | H type driver | Small and high performance S type driver is recommended. | | | | | | | |

CE marking conformable products: Refer to [CKD European standards conforming products guide (catalog no.CC-543)].

•AX1000, AX2000, AX4000 and AX5000 series

 $\bullet S$ and H type drivers



| Examples of applications | Intro 10 |
|-------------------------------|----------|
| A Precautions | Intro 13 |
| Related parts model no. table | Page 71 |
| Selection guide | Page 73 |

| Torque (N·m) | | | | Index accuracy | Repeat accuracy | Fastures | Annlingtions | Dawa | | |
|--------------|---------------|--------|--------|----------------|-----------------|------------------------|---|---|--------------------------|-----------|
| | 150 | 210 | 300 | 500 | (sec.) | (sec.) | Features | Applications | Page | AX |
| | AX1150 | AX1210 | | | ±15 | ±5 | High precision specifications; index accuracy and run out of output shaft, etc. | Precision measuring Turntable Inspection machine Assembly machine | 19 to 24 | |
| | | | | | ±15 | ±5 | Compact with small diameter (AX2006 and AX2012) Easy cable wiring and piping due to hallow fixed shaft (AX2021 and AX2042) | Turntable P & P Assembly machine | 25 to 30 | |
| | AX4150 | | AX4300 | AX4500 | ±30 | ±5 | Large hollow diameter and great variety of size options Maximum output torque 9 to 500 N·m 7 models are available. | Turntable Inspection machine Assembly machine P & P | 31 to 40 | AX2000 |
| | AX5150 | AX5210 | | | ±15 | ±5 | A pneumatic brake is integrated to clamp an output shaft when stopped. Appropriate for a work that load applied after stop. | Precision measuring Turntable Inspection machine Assembly machine (pressfit) | 41 to 47 | AX4000 |
| | | | | | ±15 | ±5 | IP65 conformity (IEC standards) Appropriate for rotary positioning equipment in machining or cleaning process, or in the environment containing a lot of powder dust | Machining and grinding such as light cutting, etc. Turntable Note. Refer to Page 53 for precautions. | 49 to 53 | AX5000 A. |
| | Not available | | | | | oped a co s turning | ntroller function in a driver, angle and moving time time | a NC program er, etc., of an | S type 57 58 61 | |
| | Fi | | | | | commun output. | ication to external PLC is a | llowed using M | H type 59 to 61 | |



System configuration

- Basic settings
- 1. Input a program from PC or dialog terminal.
- 2. Set the required parameters in the same manner.
- 3. Set gain as adequate.

- Basic driving method
- 1. Select the program to run from PLC.
- 2. Input the start signal from PLC.
- 3. The positioning complete signal is outputted from the driver after driven.



Configuration

| | Name | Quantity |
|-----|--|----------|
| ard | Actuator body | 1 |
| ndâ | Driver body (controller attached) | |
| Sta | Cable set (4m) | 1 |
| | Accessory: I/O connector (MR-50LM) and fuse (10A and A | C250V |

Driver bracket

Note: Fuse is not included in accessory of GS and S type drivers.

Programming tool

- [AX0170H] is available as programming terminal for S and H type drivers.
- Computer communication software [Teaching note] is available. (Free software for Windows).

Programming, parameter setting and sending operation commands, etc. to a direct drive actuator are done from PC. It is possible to save the programs.

RS-232C interface cable is required.

| a) for D-sub 25 pin (2m) | (model no.: AX-RS232C-25P) |
|-------------------------------|----------------------------|
| b) for D-sub 9 pin (2m) | (model no.: AX-RS232C-9P) |
| c) for 14 pin half pitch (2m) | (model no.: AX-RS232C-14P) |





Applications

E.g. 1. index unit for rotary table type automatic machine

• Creating programs of process A and B, and switching these programs, two different workpieces can be processed by a single piece of equipment.

[Merit of direct drive actuator]

- Used an absolute resolver, no origin detection sensor is required.
- Equal index programs are easily inputted by a dialog terminal.
- Index number (or angle) and moving time (or maximum rotational speed), etc. are merely inputted to program.

E.g. 2. θ axis of P & P unit

• Putting a ball spline through hollow, the unit can be used as an intelligent P & P unit.

[Merit of ABODE]

blow using hollow.

• Used an absolute resolver, the actuator will not return to the origin even when power turned on, so can move directly in the either position.

*When installing the product in mechanism or equipment, care must be taken.

(Refer to Intro 12 for cautions [Design & selection] (6).)

• It is appropriate for equipment that picks up a workpiece with air





Air blow

E.g. 4. rotation and conveyance of large panel

E.g. 3. small parts inspection equipment

• It is appropriate for transferring and rotating large panels.

Note. Even if the limit of allowable load moment of inertia is reached, the product may be used depended with adjustment of parameters, etc. Consult with CKD for details.



CKD Intro 10



Operation specifications 1 (operation of index unit)

Operation specifications

- 4 Index (90° equal index)
- Moving time 0.5 sec.
- Shift 1 index counterclockwise every start input from PLC.



Example of program



(Note) When using dialog terminal or teaching note, no descriptions are required since O1 is automatically set by inputting program number 1.

Example of PLC actuating signal

Initial process: process executed once at first PLC output PLC input Process name I/O signal name Remarks 1 Program number selection · Number selection 0 bit Selecting program number 1. · Number selection 1 bit (Select the program to run. In Number selection 2 bits · Number selection 3 bits this example, no. 1 is used.) · Number setting the first digit 2 Return process Start signal Return process complete by · Positioning complete signal positioning complete signal Start input waiting output

Index process: process executed per index.

| Process name | I/O signal name | PLC output | PLC input | Remarks |
|-------------------|---|------------|-----------|---|
| ③ Index treatment | Start signal Positioning complete signal Start input waiting output | | 「「 | Index complete by positioning complete signal |

(Note) Program number selection and start signals must be inputted when start input waiting output turned on.





Operation specifications 2 (operation of oscillator unit)

Operation specifications

- Move $-45^{\circ} \iff 45^{\circ}$ repeatedly every start input from PLC.
- Moving time 0.7 sec.
- Brake is activated when stopped. (Note 1)
- Emergency stop input is to be effective. (Note 2)



Example of program

| Main program | |
|--------------|---|
| Ō2; | Use a program number [2]. |
| G105; | Set an angle(°) for unit of A of NC code. |
| G11; | Set a time (sec.) for unit of F of NC code. |
| G90; | Absolute dimension |
| N1M69; | Brake release |
| A45F0.7; | Move until 45° position in 0.7 second |
| M68; | Brake operation |
| M0; | Waiting start input from PLC |
| M69; | Brake release |
| A-45F0.7; | Move until 45° position in 0.7 second |
| M68; | Brake operation |
| M0; | Wait start input from PLC. |
| J1; | Jump to block of sequence number 1 |
| M30; | Program end |
| | |

Note 1: Use a direct drive actuator with brake.

If optional electromagnetic brake is used, refer to [control method of Electromagnetic brake]. Note 2: If emergency stop is inputted during brake operation, the brake is activated after reset.

When the start signal is inputted continuously without re-selecting a program number, release the brake by brake release input after reset, then input the first start signal.





When designing and manufacturing equipment using a direct drive actuator, the manufacturer is obligated to check that the safety of mechanism, and entire systems including electric controls are secured.

It is important to select, use, handle or maintain the product appropriately to ensure that CKD products be used safely. To ensure the safety of equipment, always observe warnings and cautions.

🛕 Danger High voltage is applied to the gland on driver front panel. Do not touch the gland during energized. Do not touch the gland approximately for 5 minutes immediately after power supply turned off, since high voltage is applied, while the charge stored in inner capacitor is discharged. 2 When removing a frame side cover for maintenance and inspection, and switch replacement in driver, etc., always turn power off since a risk of electric shock with high voltage could be created. 3 Do not install and remove a connector, etc. while power turned on, or malfunction, failure or electric shock may be caused. 🛕 Warning 1 Use the product within the specification range. If of uses out of specifications or special applications, consult with CKD for the availability. 2 The use out of specification range may prevent the product from attaining its functions, and the safety is not secured. ③The use will be limited in special applications or in special environment. Secure the safety for entire equipment. 2 Each handling explanation and cautions of the product must be observed to prevent accidents. Do not rotate an actuator output shaft more than 30 rpm when power turned off. The electricity generated by actuator may result in driver fault or create a hazard of electric shock. 2 If servo-off (including emergency stop and alarm) and brake off are done with torque applied by gravity, etc., the output shaft will rotate by torque. These operations must be done with balanced without torque, or after safety is checked. Sufficient care must be taken not to put a hand on the output shaft since an uncontrolled motion could occur during gain adjustment stage and trial runs. Also, when operating the actuator from the position where the actuator can not be seen, check that the safety is secured, even if the output shaft is rotated, before operation. 4 The brake of actuator does not always hold the position of output shaft thoroughly. When doing maintenance, while unbalanced load is applied and output shaft could rotate, it is not safe if the position is held by the brake only. Please keep the load with balanced, or provide a mechanical interlock. 3 The product is designed and manufactured as a part for general industrial machines. Therefore, the person that has sufficient knowledge and experience must handle the product. 4 For the safety on equipment design, corporate standards and regulation, etc., must be observed. 5 Do not remove components before confirming safety. 6 When restarting machine and equipment, check if countermeasures are taken not to remove installations, then perform the work. Safety cautions are ranked as [DANGER], [WARNING] and [CAUTION] in this section. A DANGER: When a dangerous situation may occur, or when there is high urgency to a warning, leading to fatal or serious injuries, if handling is mistaken. A WARNING: When a dangerous situation may occur, leading to fatal or serious injuries, if handling is mistaken. A CAUTION: When a dangerous situation may occur, leading to minor injuries or physical damage, if handling is mistaken. Note that some items described as [CAUTION] may lead to serious results depending on the situation. In any case, the important description that must be observed is listed. Intro 13

Caution

When exporting

[Direct drive actuator] is subject to [foreign exchange and trade control laws]. Therefore, when exporting direct drive actuators from Japan, an approval of Japanese government is required.

Caution

- Actuators (excluding AX8000 series) and drivers are not water proof. When using these products in the environment where water and oil will contact to the products, take countermeasures of water proof.
- 2 Adhesions of swarf and dust, etc., on the actuator and driver may result in possible leakage of electricity and failures. Please avoid these adhesions.
- 3 The cable attached as standard can not be used with repeatedly bent. Select an optional movable cable.
- If the cable length is longer than standard (4m), insert a noise filter on the motor cable. Connect the IN side of noise filter on the driver side, then install the filter near the driver as close as possible.

| | Model no. | Maker | |
|-------------------|-----------|-------------------|-------|
| AX * * 75 or less | LF-310KA | NEC TOKIN (stock) | 3-10A |
| AX * 150 and over | LF-320KA | NEC TOKIN (stock) | 3-20A |

- If power and servo are turned OFF with servo turned ON (holding state), unless applying external force, the output shaft may move from the holding position.
- 6 An optional electromagnetic brake is usually used to increase holding rigidity when the output shaft stopped.

Do not use the brake to stop the rotating output shaft.

The machine and equipment in which direct drive actuator is installed should be rigid enough to realize maximum direct drive actuator performance. If load equipment or the frame's mechanical vibration is relatively low (200 to 300 Hz or less), resonance could occur in the direct drive actuator and load equipment or frame. Fix rotary table and main unit mounting bolts to ensure sufficient rigidity without loosening [Fig. 1].



Also, gain adjustment is required depended with magnitude of load table.

Even if a direct drive actuator can not be installed on the machine directly, install the actuator on a frame with sufficient rigidity. [Fig. 2].





Design & selection

- If rigidity of machinery and equipment is not satisfactory, install a dummy inertia at the closest place to the actuator to reduce resonance of machinery and equipment.
 - If of output shaft extension, as reference, the diameter of extended shaft is

ø60mm and over if of AX * 006, AX * 009, AX * 012, AX *

018, AX * 022 and AX * 045, ø90mm and over if of AX *

075, AX * 150, AX * 210 and AX * 300, while ø150mm and over if of AX * 500.

As reference, the size of dummy inertia is [load inertia] X (0.2 to 1). [Fig. 3].





- Dummy inertia = [load inertia] X (0.5 to 2), if of connection by gears and spline, or by key.
- If speed changes with belts or gears, use load inertia with actuator output shaft converted, and install a dummy inertia on the actuator. [Fig. 4] [Fig. 5]

(Caution) Install a dummy inertia as large as possible according to performance of the actuator.

[Fig. 4] Example 2, dummy inertia installation



[Fig. 5] Example 3, dummy inertia installation





Labor saving mechanisms warnings and cautions to secure safety

Always read this section before starting use.



Design & selection



- 1) A valve for pneumatic brake is integrated in the direct drive actuator body.
- Supply 24VDC to the external power input (1, 2 3, 4 pin) of I/O connector (CN3) as power supply for the valve.
- 2) Supply clean compressed air of 0.5MPa to the joint for brake. Do not lubricate with a lubricator, etc.
- 3) The integrated brake merely increases the holding rigidity when the output shaft is stopped. Do not brake the output shaft, while the shaft is rotating.

Recommended air circuit for pneumatic brake



Intro 15 CKD



Design & selection

• Electromagnetic brake



- 1) Do not use the electromagnetic brake to brake or stop the output shaft, while the shaft is rotating.
- 2) If BK+ and BK- of the driver, and electromagnetic brakes are directly connected, the driver may be damaged.
- 3) When connecting the inductive load such as the following relay, etc., to the external contact, use a coil with rated voltage 24VDC and rated current 100mA or less, and take countermeasures for surge.
- 4) When using an electromagnetic brake, supply 24VDC to the external power input (1, 2 3, 4 pin) of I/O connector (CN3).

Recommended circuit for electromagnetic brake





Labor saving mechanisms warnings and cautions to secure safety

Always read this section before starting use.

Caution

Installation & adjustment

- Use an actuator and a driver having the same serial number combination. After opening the package, confirm that actuator, driver, and cable serial numbers are the same. When using several direct drive actuator units together, check that unlike units are not combined. Combining unlike actuator and driver may cause incorrect operation and faults.
- Connect the actuator and driver only with the enclosed cable. Check that excessive force is not applied and that the cable is not damaged. Do not change the length or material of the enclosed cable, because this may cause malfunctions or faults.
- 3 Check that the correct power supply is connected. Connecting a non-designated power supply could cause faults. Wait at least 5 seconds after turning power OFF before turning it ON again.
- Fix the direct drive actuator securely to the machine, and install loads such as the table before adjusting gain. Confirm that no interference exists and that the state is safe even when movable sections are rotated.
- **5** Do not tap the output shaft with a hammer nor assemble it forcibly. Doing so may prevent expected accuracy and functions from being realized and could cause faults.
- 6 Avoid placing the actuator near strong magnetic fields such as rare-earth magnets. Doing so may prevent maintenance of the expected accuracy.

- The temperature of the actuator body will be high depended with working conditions. Provide a protective cover, etc., not to touch the body.
- B Do not do machining such as boring, etc., on the actuator body.If machining is required, consult with CKD.
- 9 Do not step on the actuator or a movable part such as dial plate, etc., installed on the actuator for maintenance work, etc.
- Compatible type (AX * * * * GS and AX * * * * GH) can not be connected to conventional actuator body and driver AX * * * * S and AX * * * * H.
- About compatible type (AX * * * * GS and AX * * * * GH)
 - A wrong combination of actuator and driver will give Alarm 3 after program input (after parameter setting). The combination of actuator and driver must be checked.
 - Note: Alarm 3 appears to prevent malfunction if the actuator and driver combination differ from when the program was input. Alarm 3 is reset when the program and parameters are input again.
 - If operation is started with an incorrect actuator and driver combination after the program is input (after parameters are set), a malfunction could occur or equipment could be damaged.
 - When changing cable length and type, a discrete cable must be ordered.

A Caution

Usage & maintenance

- Do not disassemble the actuator. Doing so may compromise expected functions or accuracy. Attempting to disassemble the resolver could critically damage it.
- 2 When testing withstand voltage of a machine or equipment in which direct drive actuator is assembled, disconnect the main power cable (L1, L2, L3) or (R, S, T) from the direct drive actuator driver and check that voltage is not applied to the driver itself. Failure to do so may cause faults.
- If alarm "4" (actuator overload: electronic thermal) occurs, wait for actuator temperature to drop sufficiently before restarting.
 Possible causes of alarm[4] could be as following. Eliminate causes, then use the product again.
 - caused by resonance/vibration → installation rigidity be secured sufficiently.
 - caused by tact time/speed → moving time/dwell time be extended.
 - caused by structure that constricts output shaft \rightarrow M68 and M69 commands be added.

Warranty

Warranty

Conditions related to the warranty term and scope are as follows:

1. Warranty term

1 year after delivery. One day of operation is assumed to be within 8 hours. If use is exceeded within 1 year, the warranty shall terminate at that point.

Durability (Direct drive actuator)

10,000,000 times for direct drive actuator brakes with air brakes, piston packing, and valve. Conditions: room temperature, room humidity, rated voltage, rated pneumatic pressure

2. Scope of warranty

If any faults found to be the responsibility of CKD occur within the above warranty term, the faulty part shall be repaired immediately by CKD free of charge.

Note that the following faults are excluded from the warranty term:

- **1** Faults due to use exceeding conditions and environments in product specifications.
- 2 Faults caused by careless or incorrect handling or improper control.
- 3 Fault causes by factors other than those to delivered parts.
- 4 Faults caused by improper use of the product.
- Faults due to modifications to product structure, performance, or specifications by a party other than CKD after the product is delivered, or faults caused by repairs not designated by CKD.
- (a) When using this product in the user's machine or equipment, damage that can be avoided if the user's machines or equipment have the functions and structure, etc., considered normal within the industry.
- Faults caused by matters that could not be predicted with the technology applied when the product was delivered.
- Faults caused by fire, earthquake, flood, lightning, force de majeure, acts of God, pollution, salt, gas, abnormal voltage, or other external factors.

The warranty here refers to that of the actually delivered product, and does not include damage caused by a fault in the delivered product.

3. Warranty when exporting to a foreign country

- (1) Products returned to the CKD plant or to a company or plant designated by CKD shall be repaired. All work and expenses related to return shall be excluded from compensation.
- (2) The repaired product shall be returned to a designated place in Japan with domestic packaging specifications

This warranty specifies basic conditions. If warranty details given in individual specification drawings or specifications differ from these warranty conditions, specification drawings or specifications shall take priority.



Direct drive actuator compatible type

AX2000G Series

Compatibility flexibly combined with driver, actuator and cable High speed revolution (maximum rotational speed 300rpm), compact with small diameter and large hollow diameter (ø30)

- Maximum torque: 6/12/18 N•m
- Available driver: GS type driver

Actuator specifications

| Descriptions | AX2006G | AX2012G | AX2018G | | | | |
|--|--|---------|---------|--|--|--|--|
| Maximum output torque N·m | 6.0 | 12.0 | 18.0 | | | | |
| Continuous power torque N·m | 2.0 | 4.0 | 6.0 | | | | |
| Maximum rotational speed rpm | | 300 | | | | | |
| Allowable axial load N | | 1000 | | | | | |
| Allowable moment load N·m | | 40 | | | | | |
| Output shaft moment of inertia kg·m ² | 0.00575 | 0.00695 | 0.00910 | | | | |
| Allowable load moment of inertia kg·m ² | 0.3 | 0.4 | 0.5 | | | | |
| Index accuracy sec. | | ±30 | | | | | |
| Repeatability sec. | ±5 | | | | | | |
| Output shaft friction torque N·m | 0 | 0.6 | | | | | |
| Resolver resolution P/rev | | 540672 | | | | | |
| Motor insulation grade | Class F | | | | | | |
| Motor withstanding voltage | 1500V AC for 1 minute | | | | | | |
| Motor insulation resistance | 10M Ω and over 500V DC | | | | | | |
| Ambient temperature range | 0 to 45 °C | | | | | | |
| Ambient humidity range | 20 to 85%RH to be no dew condensation. | | | | | | |
| Conservation ambient temperature range | -20 to 80 °C | | | | | | |
| Conservation ambient humidity range | 20 to 90%RH to be no dew condensation. | | | | | | |
| Mass kg | 4.7 5.8 7.5 | | | | | | |
| Run out of output shaft mm | 0.03 | | | | | | |
| Surface run out of output shaft mm | 0.03 | | | | | | |

Maximum speed/torque characteristics



(Note) moment load







M (N·m) =F (N) X (L+0.02) (m) M: moment load F: load L: distance from output shaft flange plane

Always read precautions on Intro 13 to 18 before starting use.

1

CKD

X2000G Series

How to order

How to order



AX2000G Actuator

*When ordering a discrete part for maintenance, consult with CKD.

driver

Model AX2006G

AX2012G

AX2018G

3-200V AC

to 230V AC

Blank

Blank

Blank

Refer to Page 3 for dimensions of the cable.

1-100V AC

to 115V AC

J1

J1

J1

Note 3: Specify body surface and mounting base treatments in both sections () and ().

electroless nickel plating surface treatment, "P2" and "P3" can not be selected.

Note 2: If the cable is bended repeatedly, use an optional movable cable.

Note 4: If section () mounting base is "B"; blackening mounting base or "BS";

Note 5: No surface treatment may be provided for additionally machined section.

2

Cable specifications



Precautions

- If cable length is 6m and over, use the noise filter for motor cable (near driver).
- When connecting a motor cable to the driver, care must be taken to connect them correctly with matching the mark tube on cable and the mark on driver.
- If the cable is bended repeatedly, use a movable cable (option).
- Also when using the movable cable, fix the cable sheath section near the actuator body connector.
- When selecting movable cable option, the movable cable is used between the driver and actuator connector, while standard cable is used for the body extended line between the actuator body and connector. The body extended cable must be fixed at the place not moved.
- When connecting the cable, insert a connector certainly in deep inside. Also, set screws of a connector must be tightened certainly.
- Care must be taken not to pull the body extended cable.
- Modification such as cut and extension of a cable, etc., must not be done, or failure and malfunction may be caused.

Dimensions







Dimensions

•AX2012G



5

Dimensions







Direct drive actuator compatible type **AX4000G Series**

Compatibility flexibly combined with driver, actuator and cable High speed revolution (maximum rotational speed: AX4022GS, AX4045GS; 240rpm, AX4075GS; 140rpm) large hollow diameter for easy cable wiring and piping, and great variety of options

- Maximum torque: 22/45/75 N•m
- Available driver: GS type driver

Actuator specifications

| Descriptions | AX4022G | AX4045G | AX4075G | |
|--|--|---------|---------|--|
| Maximum output torque N·m | 22 | 45 | 75 | |
| Continuous power torque N·m | 7 | 15 | 25 | |
| Maximum rotational speed rpm | 24 | 40 | 140 | |
| Allowable axial load N | 3700 | | 20000 | |
| Allowable moment load N·m | 60 | 80 | 200 | |
| Output shaft moment of inertia kg·m ² | 0.0206 | 0.0268 | 0.1490 | |
| Allowable load moment of inertia kg·m ² | 0.60 | 0.90 | 5.0 | |
| Index accuracy sec. | | ±30 | | |
| Repeatability sec. | ±5 | | | |
| Output shaft friction torque N·m | 3 | 10.0 | | |
| Resolver resolution P/rev | 540672 | | | |
| Motor insulation grade | Class F | | | |
| Motor withstanding voltage | 1500V AC for 1 minute | | | |
| Motor insulation resistance | $10M\Omega$ and over 500V DC | | | |
| Ambient temperature range | 0 to 45 °C | | | |
| Ambient humidity range | 20 to 85%RH to be no dew condensation. | | | |
| Conservation ambient temperature range | -20 to 80 °C | | | |
| Conservation ambient humidity range | 20 to 90%RH to be no dew condensation. | | | |
| Mass kg | 12.3 | 15.0 | 36.0 | |
| Total mas with brake set kg | 16.4 | 19.3 | 54.0 | |
| Run out of output shaft mm mm | 0.03 | | | |
| Surface run out of output shaft mm | 0.05 | | | |

Electromagnetic brake specifications (option)

| Descriptions | Applicable model | AX4022G/AX4045G | AX4075G |
|----------------------------------|---------------------|--|-------------|
| Туре | | Non-backrush dry type deenergisation operation model | |
| Rated voltage | V | 24V DC | |
| Power supply wattage | W | 30 | 55 |
| Rated current | А | 1.25 | 2.30 |
| Static friction torque | N∙m | 35 | 200 |
| Amateur disengage time (brake or | n) msec. | 50 or less | 50 or less |
| Amateur suction time (brake off) | msec. | 150 or less | 250 or less |
| Holding accuracy | min. | Below 45 | |
| Maximum cycle rate | cycle/min. | 60 | 40 |

Note 1: When rotating the output shaft, a rubbing noise between the disk and fixed section of electromagnetic brake may be made. Note 2: In movement after brake off, delay time of a parameter must be changed per above amateur suction time. Note 3: Non-backrush method is used, however, if a load is applied in rotational direction, it will be difficult to hold the fixed position.

Note 4: The amateur may contact to the electromagnetic brake fixed section during electromagnetic brake applied, making a noise.

Always read precautions on Intro 13 to 18 before starting use.

CKD





Note 2: If the cable is bended repeatedly, use an optional movable cable.

- Refer to Page 9 for dimensions of a cable.
- Note 3: Specify body surface and mounting base treatments in both sections () and ().
- Note 4: If section () mounting base is "B"; with blackening mounting base or "BS"; electroless
- nickel plating surface treatment mounting base, "P2" and "P3" can not be selected.
- Note 5: No surface treatment may be provided for additionally machined section.
- *When ordering a discrete part for maintenance, consult with CKD.

8

Maximum speed/torque characteristics

• AX4022GS and AX4045GS





Cable specifications



A Precautions

- If cable length is 6m and over, use the noise filter for motor cable for the motor cable (near driver).
- When connecting the motor cable to the driver, care must be taken to connect them correctly with matching the mark tube on cable and the mark on driver.
- If the cable is bended repeatedly, use a movable cable (option).
- Also when using the movable cable, fix the cable sheath section near the actuator body connector.
- When connecting the cable, insert a connector certainly in deep inside. Also, setscrews of a connector must be tightened certainly.
- Modification such as cut and extension of a cable, etc., must not be done, or failure and malfunction may be caused.

(Note) moment load



Always read precautions on Intro 13 to 18 before starting use.

Dimensions

Dimensions



AX4000G Actuator

CKD

Dimensions



AX4000G Series Dimensions

Dimensions

•AX4075G

● AX4075G-EB Electromagnetic brake

Refer to the left fig. for other options.



AX4000G Actuator



Direct drive actuator compatible type **AX4000G Series**

For load with large moment of inertia

Compatibility flexibly combined with driver, actuator and cable

Large hollow diameter for easy cable wiring and pipe, great variety of options

- Maximum torque: 150/300/500 N•m
- Available driver: GH type driver

Actuator specifications

| Descriptions | AX4150G | AX4300G | AX4500G | |
|--|--|---------------|---------------|--|
| Maximum output torque N·m | 150 | 300 | 500 | |
| Continuous power torque N·m | 50 | 100 | 160 | |
| Maximum rotational speed rpm | 10 | 00 | 70 | |
| Allowable axial load N | | 20000 | | |
| Allowable moment load N·m | 300 | 400 | 500 | |
| Output shaft moment of inertia kg·m ² | 0.2120 | 0.3260 | 0.7210 | |
| Allowable load moment of inertia $kg \cdot m^2$ | 75.00 Note 1 | 180.00 Note 1 | 300.00 Note 1 | |
| Index accuracy sec. | | ±30 | | |
| Repeatability sec. | ±5 | | | |
| Output shaft friction torque N·m | 10.0 15.0 | | | |
| Resolver resolution P/rev | 540672 | | | |
| Motor insulation grade | Class F | | | |
| Motor withstanding voltage | 1500V AC for 1 min. | | | |
| Motor insulation resistance | 10MΩ and over 500V DC | | | |
| Ambient temperature range | 0 to 45 °C | | | |
| Ambient humidity range | 20 to 85%RH to be no dew condensation. | | | |
| Conservation ambient temperature range | -20 to 80 °C | | | |
| Conservation ambient humidity range | 20 to 90%RH to be no dew condensation. | | | |
| Mass kg | 44.0 | 66.0 | 115.0 | |
| Brake set total mass kg | 63.0 | 86.0 | - | |
| Run out of output shaft mm | 0.03 | | | |
| Surface run out of output shaft mm | 0.05 | | | |

Note 1: The default setting is for large moment of inertia at shipment.

Electromagnetic brake specifications (option)

| Descriptions | Applicable model | AX4150G/AX4300G |
|-----------------------------------|---------------------|--|
| Туре | | Non-backrush dry type deenergisation operation model |
| Rated voltage | V | 24V DC |
| Power supply wattage | W | 55 |
| Rated current | А | 2.30 |
| Static friction torque | N∙m | 200 |
| Amateur disengage time (brake on) |) msec. | 50 or less |
| Amateur suction time (brake off) | msec. | 250 or less |
| Holding accuracy | min. | Below 45 |
| Maximum cycle rate | cycle/min. | 40 |

Note 2: When rotating the output shaft, a rubbing noise between the disk and fixed section of an electromagnetic brake may be made. Note 3: In movement after brake off, delay time of a parameter must be changed per above amateur suction time.

Note 4: Non-backrush method is used, however, if a load is applied in rotational direction, it will be difficult to hold the fixed position. Note 5: The amateur may contact to the electromagnetic brake fixed section during electromagnetic brake applied, making a noise.



13 **CKD**



Note 2: If the cable is bended repeatedly, use an optional movable cable.

Refer to Page 15 for dimensions of cable.

Note 3: Specify body surface and mounting base treatments in both sections () and ().

Note 4: If section (mounting base is "B"; with blackening mounting base or "BS"; electroless

nickel plating surface treatment mounting base, "P2" and "P3" can not be selected.

Note 5: Select options according to the following [option table].

| Option | table |
|--------|-------|
|--------|-------|

| | AX4150G | AX4300G | AX4500G |
|-----------------------------|---------|---------|---------|
| Electromagnetic brake (-EB) | 0 | 0 | × |

Note 6: No surface treatment may be provided for additionally machined section.

*When ordering a discrete part for maintenance, consult with CKD.

Maximum speed/torque characteristics



Cable specifications



A Precautions

- If cable length is 6m and over, use the noise filter for motor cable (near driver).
- When connecting the motor cable to the driver, care must be taken to connect them correctly with matching the mark tube on cable and the mark on driver.
- If the cable is bended repeatedly, use a movable cable (option).
 Also when using the movable cable, fix the cable sheath section near the actuator body connector.
- When connecting the cable, insert a connector certainly in deep inside. Also, setscrews of the connector must be tightened certainly.
- Modification such as cut and extension of a cable, etc., must not be done, or failure and malfunction may be caused.

(Note) moment load





M (N·m) =F (N) X L (m) M: moment load F: load L: distance from output shaft center

AX4000G Series Dimensions

Dimensions



ø10H7 depth 12 (option) Not available with option mounting base installed.

Dimensions




Dimensions

•AX4500G





Direct drive actuator AX1000 Series actuator

High precision specifications (index accuracy and run out of output shaft, etc.) •Maximum torque: 22/45/75/150/210 N·m

Actuator specifications

| Descriptions | AX1022 | AX1045 | AX1075 | AX1150 | AX1210 |
|--|--|-----------|----------------------------------|------------|---------|
| Maximum output torque N·m | 22 | 45 | 75 | 150 | 210 |
| Continuous power torque N·m | 7 | 15 | 25 | 50 | 70 |
| Maximum rotational speed rpm | 100 (N | lote 1) | | 100 | |
| Allowable axial load N | 60 | 00 | | 2200 | |
| Allowable moment load N·m | 19 | 38 | 70 | 140 | 170 |
| Allowable radial load N | 10 | 00 | | 4000 | |
| Output shaft moment of inertia kg·m ² | 0.00505 | 0.00790 | 0.03660 | 0.05820 | 0.09280 |
| Allowable load moment of inertia kg·m ² | 0.6 | 0.9 | 4.0 | 6.0 | 10.0 |
| Index accuracy sec. ±15 | | | | | |
| Repeatability sec. | ±5 | | | | |
| Output shaft friction torque N·m | 2.0 8.0 | | | | |
| Resolver resolution P/rev | | | 540672 | | |
| Motor insulation grade | | | Class F | | |
| Motor withstanding voltage | | | 1500V AC for 1 min. | | |
| Motor insulation resistance | | 10 | ${\sf DM}\Omega$ and over 500V D | С | |
| Ambient temperature range | | | 0 to 45 °C | | |
| Ambient humidity range | | 20 to 85% | RH to be no dew cond | densation. | |
| Conservation ambient temperature range | -20 to 80°C | | | | |
| Conservation ambient humidity range | 20 to 90%RH to be no dew condensation. | | | | |
| Mass kg | <u>1 8.9 12.0 23.0 32.0 44.0</u> | | | | 44.0 |
| Run out of output shaft mm | 0.01 | | | | |
| Surface run out of output shaft mm | 0.01 | | | | |

Note 1: Consult with CKD for applications with 100 rpm and over.

(Consult with CKD for customized specifications; up to 150rpm for S type driver in a model with maximum torque 45 N·m or less, while up to 180rpm for H type driver. No change in maximum rotational speed is available after shipment).



Maximum speed/torque characteristics



(Note) moment load



 $M (N \cdot m) = F (N) X (L+0.02) (m)$ M: moment load F : load

L : distance from output shaft center

L : distance from output shaft flange plane

Always read precautions on Intro 13 to 18 before starting use.

CKD

How to order

How to order



*Small and high performance S type driver is recommended for a model with maximum torque 75 N·m or less. Note 2: Both connector bottom installation (-C) and CE marking product (-K) can not be selected together.

J1

J1

J2

J2

J2

J2

J2

Blank

Blank

Blank

Blank

Blank

Note 3: If the cable is bended repeatedly, use an optional movable cable.

to 115V AC

J1

J1

Refer to Page 55 for dimensions of a cable.

to 230V AC

Blank

Blank

Blank

Model AX1022

AX1045

AX1075

AX1150

AX1210

Dimensions





Rotational section



Dimensions

Dimensions







AX1000 Actuator

Dimensions





Dimensions with optional equipment

 Connector bottom installation (C) AX1022/AX1045





AX1075/AX1150/AX1210







Direct drive actuator **AX2000 Series** actuator

Compact with small diameter (AX2006 and AX2012) Types with fixed hollow shaft (AX2021 and AX2042) are available for easy cable wiring and piping.

● Maximum torque: 6/12/21/42 N·m

Actuator specifications

| Descriptions | AX2006 | AX2012 | AX2021 | AX2042 | | |
|--|------------|--|----------------------|---------|--|--|
| Maximum output torque N. | m 6 | 12 | 21 | 42 | | |
| Continuous power torque N. | m 2 | 4 | 7 | 14 | | |
| Maximum rotational speed rp | m | 100 (N | Note 1) | | | |
| Allowable axial load | N | 1000 | 20 | 00 | | |
| Allowable moment load N- | m | 40 | 6 | 0 | | |
| Output shaft moment of inertia kg-n | n² 0.00575 | 0.00695 | 0.03450 | 0.04830 | | |
| Allowable load moment of inertia kg-n | n² 0.3 | 0.4 | 0.6 | 0.9 | | |
| Index accuracy se | c. | | | | | |
| Repeatability se | c. | ± | 5 | | | |
| Output shaft friction torque N- | m | 0.4 | 3. | 3.0 | | |
| Resolver resolution P/re | ev | 540672 | | | | |
| Motor insulation grade | | Clas | ss F | | | |
| Motor withstanding voltage | | 1500V AC | c for 1 min. | | | |
| Motor insulation resistance | | 10M Ω and o | ver 500V DC | | | |
| Ambient temperature range | | 0 to 4 | 45 °C | | | |
| Ambient humidity range | | 20 to 85%RH to be r | no dew condensation. | | | |
| Conservation ambient temperature range | | -20 to 80 °C | | | | |
| Conservation ambient humidity range | | 20 to 90%RH to be no dew condensation. | | | | |
| Mass | ag 4.7 | 5.8 | 13.0 | 17.0 | | |
| Run out of output shaft m | m | 0.03 | | | | |
| Surface run out of output shaft m | m | 0.03 | | | | |

Note 1: A direct drive actuator convertible type (AX2 * * * GS) is available for applications with 100 rpm and over. Consult with CKD for customized specifications: up to 150rpm for S type driver, while up to 180rpm for H type driver. The maximum rotational speed can not be changed after shipment.



Maximum speed/torque characteristics







 $\begin{array}{l} M \ (N \cdot m) = F \ (N) \ X \ (L + 0.02) \ (m) \\ M : moment \ load \\ F \ : \ load \end{array}$

F : load

M: moment load

L : distance from output shaft center L : distance from output shaft flange plane

Always read precautions on Intro 13 to 18 before starting use.

CKD

How to order

How to order



Note 3: If the cable is bended repeatedly, use an optional movable cable. (Either AX2006 or AX2012 can be selected.)

Both top and bottom sides 1 piece each

Refer to Page 55 for dimensions of a cable.

Note 4: If section D mounting base is "B"; with blackening mounting base, " P2 " and " P3 " can not be selected.

Ο

0

×

×

Note 5: No surface treatment may be provided for additionally machined section.

(-P3)

CKD 26

Dimensions

• AX2006

•AX2012



Note: The minimum bending range of a cable outlet is 20.

Dimensions













Dimensions



•AX2042-A





Fixed section



Dimensions

CE marking products dimensions

•AX2021-K







• AX2042-K









Direct drive actuator **AX4000 Series** actuator

Large hollow shaft diameter for easy cable wiring and piping A great variety of series variation and options ● Maximum torque: 9/22/45/75/150/300/500 N·m

Actuator specifications

| Descriptions | AX4009 | AX4022 | AX4045 | AX4075 | AX4150 | AX4300 | AX4500 |
|--|-----------------------|--|-------------|-----------------------|--------------|--------|--------|
| Maximum output torque N. | n 9 | 22 | 45 | 75 | 150 | 300 | 500 |
| Continuous power torque N. | n 3 | 7 | 15 | 25 | 50 | 100 | 160 |
| Maximum rotational speed rp | n | 100 (Note 1) | | | 100 | | 70 |
| Allowable axial load | N 800 | 37 | 00 | | 200 | 000 | |
| Allowable moment load N- | m 40 | 60 | 80 | 200 | 300 | 400 | 500 |
| Output shaft moment of inertia kg-n | n ² 0.0090 | 0.0206 | 0.0268 | 0.1490 | 0.2120 | 0.3260 | 0.7210 |
| Allowable load moment of inertia kg-n | n ² 0.35 | 0.60 | 0.90 | 5.00 | 7.50 | 18.00 | 30.00 |
| Index accuracy se | c. | ±30 | | | | | |
| Repeatability se | c. ±5 | | | | | | |
| Output shaft friction torque N- | m 0.8 | 0.8 3.5 10.0 15. | | | | | 15.0 |
| Resolver resolution P/re | ev l | 540672 | | | | | |
| Motor insulation grade | | Class F | | | | | |
| Motor withstanding voltage | | | 15 | 00V AC for 1 m | in. | | |
| Motor insulation resistance | | | 10M | Ω and over 500 | V DC | | |
| Ambient temperature range | | | | 0 to 45 °C | | | |
| Ambient humidity range | | | 20 to 85%R⊦ | I to be no dew c | ondensation. | | |
| Conservation ambient temperature range | | | | -20 to 80°C | | | |
| Conservation ambient humidity range | | 20 to 90%RH to be no dew condensation. | | | | | |
| Mass | g 5.5 | 12.3 | 15.0 | 36.0 | 44.0 | 66.0 | 115.0 |
| Brake set total mass | g - | 16.4 | 19.3 | 54.0 | 63.0 | 86.0 | - |
| Run out of output shaft m | n | | | 0.03 | | | |
| Surface run out of output shaft m | n | | | 0.05 | | | |

Note 1: A direct drive actuator convertible type (AX4 * * * GS) is available for applications with 100 rpm and over.

Consult with CKD for customized specifications; up to 150rmp for S type driver, while up to 180rpm for H type driver in a model with maximum torque 45 N m or less. The maximum rotational speed can not be changed after shipment.

Electromagnetic brake specifications (option)

| Descriptions | Applicable model | AX4022/AX4045 | AX4075/AX4150/AX4300 | | | |
|-----------------------------------|---------------------|----------------------------|-----------------------------|--|--|--|
| Туре | | Non-backrush dry type deer | nergisation operation model | | | |
| Rated voltage | V | 24V DC | | | | |
| Power supply wattage | W | 30 | 55 | | | |
| Rated current | А | 1.25 | 2.3 | | | |
| Static friction torque | N∙m | 35 | 200 | | | |
| Amateur disengage time (brake on) |) msec. | 50 or less | 50 or less | | | |
| Amateur suction time (brake off) | msec. | 150 or less | 250 or less | | | |
| Holding accuracy | min. | Belo | w 45 | | | |
| Maximum cycle rate | cycle/min. | 60 | 40 | | | |

Note 2: When rotating the output shaft, a rubbing noise between the disk and the fixed section of electromagnetic brake may be made. Note 3: In movement after brake off, delay time of a parameter must be changed per above amateur suction time.

Note 4: Non-backlash type is used, however, if a load is applied in the rotational direction, fixed position holding will be difficult.

Note 5: The amateur may contact to the electromagnetic brake fixed section during electromagnetic brake applied, making a noise.

Always read precautions on Intro 13 to 18 before starting use.



How to order





*Small and high performance S type driver is recommended for a model with maximum torque 75 N·m or less. Note 2: If the cable is bended repeatedly, use an optional movable cable.

Refer to Page 55 for dimensions of a cable.

Ontion table

- Note 3: Specify body surface and mounting base treatments in both sections () and ().
- Note 4: If section O mounting base is "B"; with blackening mounting base or "BS"; electroless nickel plating surface treatment mounting base, "P2" and "P3" can not be selected.
- Note 5: Select options according to the following [option table].

| | AX4009 | AX4022 | AX4045 | AX4075 | AX4150 | AX4300 | AX4500 | |
|---------------------|--------|--------|--------|--------|--------|--------|--------|--|
| Mounting base (-B) | × | 0 | 0 | 0 | 0 | 0 | 0 | |
| Mounting base (-BS) | × | 0 | 0 | 0 | 0 | 0 | 0 | |
| Brake (-EB) | × | 0 | 0 | 0 | 0 | 0 | × | |

Note 6: No surface treatment may be provided for additionally machined section.

| BS | Use with body surface treatment S | | | | | | |
|-------------|--|--|--|--|--|--|--|
| | | | | | | | |
| | le change | (achia langth (m) | | | | | |
| Blank | Standard | (cable length 4m) | | | | | |
| | Cable lenç | gtn change | | | | | |
| DM * * | Niovable c | able length change | | | | | |
| * * cable I | ength Note: leng | oth and type can not be changed after shipment. | | | | | |
| 02 | 2m | | | | | | |
| Blank | 4m | -DM | | | | | |
| 06 | 6m | | | | | | |
| 08 | 8m | [Note] | | | | | |
| 10 | 10m | If cable length is 6m and | | | | | |
| 15 | 15m | aver use the poise filter for | | | | | |
| 20 | 20m | over, use the hoise litter for | | | | | |
| 25 | 25m | motor cable. | | | | | |
| 30 | 30m | | | | | | |
| E Brake | | | | | | | |
| Blank | Standard (without brake) | | | | | | |
| | Negative actuation model electromagnetic brake | | | | | | |
| | (Not availab | le for AX4009 and AX4500) | | | | | |
| | er nower si | upply voltage | | | | | |
| Refer to | the driver po | ower supply voltage table on the left. | | | | | |
| | morking | | | | | | |
| Blank | Standard | (not CE marking products) | | | | | |
| L L L | CE markir | a products | | | | | |
| ĸ | | | | | | | |
| 🕀 Dow | /el hole (No | te 6) | | | | | |
| Blank | Standard | (without dowel hole) | | | | | |
| P1 | Top 1 piec | e | | | | | |
| P2 | Bottom 1 | piece (AX4009: bottom 2 pieces.) | | | | | |
| P3 | Both top and botto | m sides 1 piece each (AX4009: top 1 piece/bottom 2 pieces.) | | | | | |
| I Boc | ly surface t | reatment | | | | | |
| Blank | Standard (rotationa | I section-blackening/fixed section casting surface plane-paint) | | | | | |
| S | Rotational section- | electroless nickel plating treatment and fixed section-nitriding | | | | | |
| | | CKD 32 | | | | | |



AX4000

Actuator

Maximum speed/torque characteristics

• AX4009, AX4022, AX4045 and AX4075



•AX4150, AX4300, AX4500



(Note) moment load









AX4000 Series Dimensions

Dimensions



Dimensions



Dimensions





Dimensions

•AX4075



⊕ 0.06 B

Dimensions



ഹ

f





4

₽

36.5

•::::

鼑

Electromagnetic brake

(Protection element attached)

183

145

CKD

Dimensions

104

36.5

P.C.D. 190

130

(: ФФ)

145

(12.5)

170

3-M8 depth 16 (equal) Option for electromagnetic brake mounting For mounting

38

Dimensions

•AX4300

•AX4300-EB Electromagnetic brake Refer to the left fig. for other options. 295 250 Mounting base (option) ¢ ¢ <u>P.C.D. 255</u> P.C.D. 255 127.5 ø10H7 depth 12 (option) 295 250 ⊕ 0.06 A P.C.D. 100 6-M10 depth 20 (equal) For dial plate mounting 6-M10 depth 20 (equal) -\$ For dial plate mounting Cable bending range (Downward bending range is 60.) ĥ <u>4-ø14</u> 4-M8 depth 16 (equal) <u>16</u> .27 8 Option for electromagnetic brake mounting Caution: When movable cable used, fix the cable sheath top. Cable length standard 4m ļ Cable length standard 4m ø272 Rotational section Rotational section ø160h7 (Including hollow section (Including hollow section ø272 ø118 ø160h7 <mark>⊲ø58</mark>► A 15.5 15.5 **ø**85 159 159 244 200 200 231 20 <u>36.5</u> 36.5 6:00 h 傗 曲 Electromagnetic brake 8 (Protection element attached) (15.5) ø220h7 81.5 В (15.5) ø288 ±3 ø220h7 ø2<u>8</u>8 ±3 Electromagnetic brake Lead wire outlet 300 45 30 30 10 1 AD P.C.D. 190 3-M8 depth 16 (equal) P.C.D. 265 P.C.D. 265 Option for electromagnetic brake mounting ¢ For mounting 130 3-M8 for manual release 6-M12 depth 24 (equal) 6-M12 depth 24 (equal)

ø10H7 depth 12 (option) Not available with option base installed.

⊕ 0.06 B

Dimensions





Direct drive actuator **AX5000 Series** actuator

It is appropriate for a work that load applied after stop, since a pneumatic brake is integrated, the output shaft is clamped when stopped. Maximum torque: 22/45/75/150/210 N·m

Actuator specifications

| Descriptions | | AX5022 | AX5045 | AX5075 | AX5150 | AX5210 | |
|--|--------------|--|-----------|---------------------------|------------|--------|--|
| Maximum output torque | N∙m | 22 | 45 | 75 | 150 | 210 | |
| Continuous power torque | N∙m | 7 | 15 | 25 | 50 | 70 | |
| Maximum rotational speed | rpm | 100 (N | lote 1) | | 100 | | |
| Allowable axial load | Ν | 60 | 00 | | 2200 | | |
| Allowable moment load | N∙m | 19 | 38 | 70 | 140 | 170 | |
| Allowable radial load | Ν | 10 | 00 | | 4000 | | |
| Output shaft moment of inertia | kg∙m² | 0.0056 | 0.0085 | 0.0403 | 0.0619 | 0.0987 | |
| Allowable load moment of inertia | kg∙m² | 0.6 | 0.9 | 4.0 | 6.0 | 10.0 | |
| Index accuracy | sec. | | ±15 | | | | |
| Repeatability | sec. | ec. ±5 | | | | | |
| Output shaft friction torque | N∙m | 2. | 2.0 8.0 | | | | |
| Resolver resolution | P/rev | | | 540672 | | | |
| Motor insulation grade | | | | Class F | | | |
| Motor withstanding voltage | | | | 1500V AC for 1 minute |) | | |
| Motor insulation resistance | | | 10 | $M\Omega$ and over 500V D | С | | |
| Ambient temperature range | | | | 0 to 45 °C | | | |
| Ambient humidity range | | | 20 to 85% | RH to be no dew cond | densation. | | |
| Conservation ambient temperature range | | | | -20 to 80 °C | | | |
| Conservation ambient humidity range | | 20 to 90%RH to be no dew condensation. | | | | | |
| Mass | kg | 16.0 | 20.0 | 40.0 | 50.0 | 65.0 | |
| Run out of output shaft | mm | n 0.01 | | | | | |
| Surface run out of output shaft | mm | | | 0.01 | | | |
| Brake torque | N·m 45 150 2 | | | | 210 | | |

Note 1: Consult with CKD for applications with 100 rpm and over.

(Consult with CKD for customized specifications; up to 150rpm for S type driver in a model with maximum torque 45 N m or less, while up to 180rpm for H type driver. No change in maximum rotational speed is available after shipment).



Maximum speed/torgue characteristics



(Note) moment load



 $M (N \cdot m) = F (N) X (L+0.02) (m)$ M: moment load F : load

L : distance from output shaft

flange plane

L : distance from output shaft center

Always read precautions on Intro 13 to 18 before starting use.

How to order

How to order



Note on model no. selection

Note 1: Select a driver according to the following table.

| | - | | | | | |
|------------------|-------------------------|-------------------------|---------------|-----------|-----------|--|
| Available driver | S type d | lriver | H type driver | | | |
| Type Model | 3-200V AC to 230V AC | 1-100V AC to 115V AC | 3-200V AC | 1-100V AC | 3-230V AC | |
| AX5022 | Blank | J1 | Blank | J1 | J2 | |
| AX5045 | Blank | J1 | Blank | J1 | J2 | |
| AX5075 | Blank | | Blank | | J2 | |
| AX5150 | | | Blank | | J2 | |
| AX5210 | | | Blank | | J2 | |

*Small and high performance S type driver is recommended for a model with maximum torque 75 N·m or less. Note 2: If the cable is bended repeatedly, use an optional movable cable.

Refer to Page 55 for dimensions of a cable.

Dimensions



Dimensions



Dimensions



Dimensions



Dimensions





Direct drive actuator **AX8000** Series actuator

IP65 conforming product (IEC standards)
Appropriate for rotary positioning equipment in the environment with water drip splashed and a lot of powder dust existing.
Maximum torque: 45/70 N⋅m

Actuator specifications

| Descriptions | _ | AX8045 | AX8070 | | |
|--|--|---------------------|---------------------|--|--|
| Maximum output torque | N∙m | 45 | 70 | | |
| Continuous power torque | N∙m | 15 | 23 | | |
| Maximum rotational speed | rpm | 100 (Note 1) | 100 | | |
| Allowable axial load | Ν | 1200 | 2200 | | |
| Allowable moment load | N∙m | 38 | 73 | | |
| Allowable radial load | Ν | 1700 | 4000 | | |
| Output shaft moment of inertia | kg∙m² | 0.0330 | 0.1540 | | |
| Allowable load moment of inertia | kg∙m² | 0.9 | 4.0 | | |
| Index accuracy | sec. | ±15 | | | |
| Repeatability | sec. | ±5 | | | |
| Output shaft friction torque | N∙m | 3.0 | 10.0 | | |
| Resolver resolution | P/rev | 540 | 672 | | |
| Motor insulation grade | | Clas | ss F | | |
| Motor withstanding voltage | | 1500V AC | for 1 min. | | |
| Motor insulation resistance | | 10MΩ and ov | ver 500V DC | | |
| Ambient temperature range | | 0 to 4 | 15 °C | | |
| Conservation ambient temperature range | | -20 to | °C | | |
| Conservation ambient humidity range | | 20 to 90%RH to be n | o dew condensation. | | |
| Protective structure | vtective structure IP65(IEC60529) IP55(IEC60034-5) | | | | |
| Mass | kg | 35.0 | 80.0 | | |
| Run out of output shaft | mm | 0.015 | | | |
| Surface run out of output shaft | mm | 0.015 | | | |
| Brake torque | N∙m | 80 | 210 | | |

Note 1: Consult with CKD for applications with 100 rpm and over.

(Consult with CKD for customized specifications; up to 150rpm for S type driver in a model with maximum torque 45 N m or less, while up to 180rpm for H type driver. No change in maximum rotational speed is available after shipment).

Inspection standard

CKD

49

| Inspection item | | Specification size |
|---|------|--------------------|
| Straightness of table top | (mm) | 0.015 |
| Run out of table top | (mm) | 0.015 |
| Parallelism between table top and housing bottom | (mm) | 0.02 |
| Perpendicularity between table top and housing side | (mm) | 0.02 |
| Run out of table spindle hole | (mm) | 0.015 |

Maximum speed/torque characteristics



Always read precautions on Intro 13 to 18 before starting use.

 High grade dust and waterproof IEC529 standards IP65* conforming TÜV Rheinland certifications



Also, higher grade water proof is achieved by air purge. *When air purge is done, supply a dry clean compressed air with low pressure (0.05MPa).

*IP65

IP marking that shows class of dust proof/water proof is defined by IEC60529 and IEC60034-5. AX8000 series is IP65 certificated by TUV Rheinland. IP6□: shows grades of contact and solid foreign materials

intrusion protections, and [6] shows the maximum grade [perfect dust proof structure].

IP□5: shows grade of water proof protection, and [5] shows [protective structure from jet water in all directions].

- Clamp reinforced in brake section Clamp torque: 80 N·m (AX8045) : 210 N·m (AX8070)
- *The brake integrates a pneumatic brake to clamp the output shaft, increasing holding rigidity at stop. Refer to the recommended air circuit diagram on Intro 14.

• Both vertical and horizontal installations are available.

How to order

AX8000 Series

How to order



Note 1: Select a driver according to the following table.

| Available driver | S type | driver | H type driver | | | |
|------------------|-------------------------|-------------------------------|---------------|-----------|-----------|--|
| Type Model | 3-200V AC to 230V AC | -200V AC 1-100V AC to 115V AC | | 1-100V AC | 3-230V AC | |
| AX8045 | Blank | J1 | Blank | J1 | J2 | |
| AX8070 | Blank | | Blank | | J2 | |

*Small and high performance S type driver is recommended.

Note 2: If the cable is bended repeatedly, use an optional movable cable.

Refer to Page 55 for dimensions of a cable.

Note 3: Refer to the following diagram for a shape of a plug.







Dimensions



approximate 30mm of clearance.

AX8045-T (T slot table)



AX8000 Series Dimensions

Dimensions



Precautions

A Precautions

- Driver, handy terminal and interactive terminal is not water proof. When using the product in the environment with water and oil splashed, induct water proof countermeasures. Rust proof treatment is not done for the actuator.
- When increasing water proof, install a joint for air purge on the body, then supply air with low pressure (0.05MPa), as same quality as the brake, to the motor inside. A noise may be made depended with external air leakage. If problems are posed, reduce air pressure.
- Performance and service life of sealing contact may be very significantly reduced per liquid type, since NBR (nitrile rubber) is used for sealing contact material.
 Also, the actuator is made of steel (output shaft) and cast iron (housing), and rust proof treatment is not done. If
- rust proof treatment is required, consult with CKD.
 If water proof brake integrated type is used as a circular table, (when a workpiece installed on an output shaft is machined), always apply a brake during machining. However, machining is limited to light cutting and machining.
- The actuator is designed for light cutting and machining. Performing heavy machining with large cutting resistance may generate vibration.
- An application that a workpiece is machined with a direct drive actuator rotated are not allowed.



53 **CKD**
Cable specifications

Cable dimensions



Cable bending radius

| | | Standard cable | Movable cable |
|--|-------------------|----------------|---------------|
| | Resolver cable | 60mm | 60mm |
| | Motor cable | 100mm | 110mm |
| | Resolver cable | 50mm | 60mm |
| | Motor cable | 90mm | 90mm |
| | Resolver cable | 60mm | |
| | Motor cable | 90mm | |
| | Resolver cable | 50mm | 60mm |
| | Motor cable | 100mm | 110mm |
| | Resolver cable | 60mm | 60mm |
| | Motor cable | 100mm | 110mm |

A Precautions

- The actuator body, driver and cable with same serial number, must be used.
 If a cable is broken, or if a change in cable length is necessary, consult with CKD.
- When connecting the motor cable to the driver, care must be taken not to connect them incorrectly, matching the mark tube of the cable and on the driver.
- If cable length is 6m and over, use the noise filter for motor cable for a motor cable (near driver).
- If the cable is bended repeatedly, use a movable cable (option). Also when using the movable cable of AX2000,AX3000, AX4000 series, fix the cable sheath section near the actuator body connector.
- When connecting the cable, insert a connector certainly in deep inside. Also, setscrews of the connector must be tightened certainly.
- Modification such as cut and extension of a cable, etc., must not be done, or failure and malfunction may be caused.
- If CE marking products (option) are used for both driver and actuator body sides, connect the cable shield to the case as earth using FG clamp, etc.



 Refer to cable length in "How to order" section for cable length L.



GS/S type driver

Common specifications

| | Model | | |
|--|---|----------------------------|--|
| Descriptions | S type driver AX9 * * * S | GS type driver AX9000GS | |
| Power supply voltage | 1.3-200V AC-10% to 230V AC + 10% (standard) (Note) 2.1-100V AC-10% to 115V AC+10% (option) | | |
| Power supply frequency | 50/6 | 0 Hz | |
| Configuration | Driver and controller integrated type (open frame) | | |
| Ambient temperature range 0 to 50 °C | | 50 °C | |
| Ambient humidity range | 20 to 90%RH (to be n | o dew condensation.) | |
| Conservation ambient temperature range | -20 to | 80 °C | |
| Conservation ambient humidity range | 20 to 90%RH (to be n | o dew condensation.) | |
| Atmosphere | To be no corrosive gas and powder dust. | | |
| Noise-resistance | Noise-resistance 1000V (P-P), pulse amplitude 1 micron sec. and start up 1/ | | |
| Vibration resistance | 4.9m/s ² | | |
| Mass | Approximate 1.7kg | | |

(Note) The model with maximum torque 50 $\textrm{N}\textrm{\cdot}\textrm{m}$ or less can be used for single phase 200 to 230V AC.

Power supply wattage/breaker capacity GS type driver

| • • • • • • • • • • • • • • • • • • • | Driver model no. | Electric power supply capacity (KVA) | | Breaker capacity |
|---------------------------------------|------------------|--------------------------------------|-------|-------------------|
| Actuator model no. | | Max. | Rated | Rated current (A) |
| AX2006G | AX9000GS | 0.8 | 0.5 | |
| AX2012G | | 1.0 | 0.5 | 10 |
| AX2018G and AX4022G | | | | |
| AX4045G | | 1.5 | 0.5 | |
| AX4075G | | 2.0 | 0.8 | |

S type driver

| | Driver model no. | Electric power supply capacity (KVA) | | Breaker capacity |
|-----------------------|---------------------|--------------------------------------|-------|-------------------|
| Actuator model no. | | Max. | Rated | Rated current (A) |
| AX * 006 | AX9006S | 0.8 | 0.5 | |
| AX * 009 and AX * 012 | AX9009S and AX9012S | 1.0 | 0.5 | |
| AX * 021 and AX * 022 | AX9021S and AX9022S | 1.0 | 0.5 | 10 |
| AX * 045 and AX * 042 | AX9045S and AX9042S | 1.5 | 0.5 | |
| AX * 070 and AX * 075 | AX9070S and AX9075S | 2.0 | 0.8 | |

CN3 input signal

| Pin number | Signal name | Logic | Judgment |
|------------|---|----------|----------|
| 1 to 2 | External power input+24V ±10% | | |
| 3 to 4 | External power input GND | | |
| 5 | Program number selection input (bit 0) | Positive | Level |
| 6 | Program number selection input (bit 1) | Positive | Level |
| 7 | Program number selection input (bit 2) | Positive | Level |
| 8 | Program number selection input (bit 3) | Positive | Level |
| 9 | Program number selection input (bit 4) | Positive | Level |
| | /program number setting input 2nd digit | | Edge |
| 10 | Program number setting input 1st digit | Positive | Edge |
| 11 | Reset input | Positive | Edge |
| 12 | Return to origin command input | Positive | Edge |
| 13 | Start input | Positive | Edge |
| 14 | Program stop input | Positive | Edge |
| 15 | Continuous rotation stop input | Positive | Edge |
| 16 | Answer input | Positive | Edge |
| 17 | Emergency stop input | Negative | Level |
| 18 | Brake release input | Positive | Level |

CN3 pulse string input signal

| Pin number | Signal name |
|------------|---------------------|
| 19 | PULSE/UP/A phase |
| 20 | -PULSE/-UP/-A phase |
| 21 | DIR/DOWN/B phase |
| 22 | -DIR/-DOWN/-B phase |

Performance specifications

| Descriptions | Descriptions | | |
|--------------------------------------|---|--|--|
| Number of control axis | 1 axis and 540672 pulse/turn (name: A axis) | | |
| Angle input increment | °(degree), pulse and index number | | |
| Angle least input increment | 0.001° and pulse | | |
| Speed input increment | Second and rpm | | |
| Speed setting range | 0.01 to 100 second/0.01 to 100rpm (S type) 0.01 to 100 second/0.01 to 300rpm (Note) (GS type) (Note) The maximum rotational speed may vary depended with actuator connected. | | |
| Equal index number | 1 to 255 | | |
| Maximum command value | 7 digits input ±9999999 | | |
| Timer | 0.01 to 99.99 sec. | | |
| Programming language | NC language | | |
| Programming method | Data is set up by dialog terminal or PC, etc., through a BS232C port | | |
| Operation mode | Automatic, MDI, jog, single block, servo OFF, pulse row input mode | | |
| Coordinates Absolute and incremental | | | |
| Acceleration curve | <5 types > Modified sine (MS), deformation constant velocity (MC/MC2), | | |
| | modified trapezoidal (MT) and tropecoid (TR) | | |
| Status display | Power supply display by LED | | |
| Operating indication | Display by 7 segment LED | | |
| Communication interface | RS-232C conformed | | |
| I/O signal | <pre></pre> <input/> Return to origin command, reset, start, stop, continuous rotation stop, emergency stop, answer, program number selection, brake release, program number setting and pulse row input <output> Alarm 1-2, positioning complete, in-position, start input waiting, M code 8 points, 1-2 during indexing, timing, M code strobing and index position strobing</output> | | |
| Program capacity | Approximate 6000 characters (256 programs) | | |
| Electronic thermal | Overheat protection of actuator | | |

CN3 output signal

| Pin number | Signal name | Logic |
|------------|--------------------------------|----------|
| 33 | M code output (bit 0) | Positive |
| 34 | M code output (bit 1) | Positive |
| 35 | M code output (bit 2) | Positive |
| 36 | M code output (bit 3) | Positive |
| 37 | M code output (bit 4) | Positive |
| 38 | M code output (bit 5) | Positive |
| 39 | M code output (bit 6) | Positive |
| 40 | M code output (bit 7) | Positive |
| 41 | Positioning complete output | Positive |
| 42 | Positioning complete output | Positive |
| 43 | Start input waiting output | Positive |
| 44 | Alarm output 1 | Negative |
| 45 | Alarm output 2 | Negative |
| 46 | Output during indexing 1 | Positive |
| 47 | Output during indexing 2 | Positive |
| 48 | Output of time | Positive |
| 49 | Index position strobing output | Positive |
| 50 | M code strobing output | Positive |

GS/S type driver

Dimensions, etc.

CN3 I/O circuit specifications





Rated voltage 24V ±10%, rated current 30mA (Max.)



Rated voltage 5V ±10% Maximum input frequency Line driver 400Kpps Open collector 250Kpps

Dimensions

• GS/S type driver (with controller)



Panel explanation Note) GS and S type drivers have different front panel designs.

Operating indication Operating indication 8 CKD ABSODEX 8 СКД ABSODEX € G1 € G1 Dip switch for gain 1 adjustment Dip switch for gain 1 adjustment 0, 0 DRIVER S TYPE DRIVER S TYPE (Convergence time) (Convergence time) 0 0 G2 G2 Name plate Name plate 0 þ Dip switch for gain 2 adjustment Dip switch for gain 2 adjustment (Load) (Load) ŏ 6 The main power supply AC200V The main power supply AC100V O POW R phase R phase 4 CN1 CN1 S phase S phase RS232C L1 Connector for RS232C L1 T phase NC Connector L 2 Protective earth Protective earth CN2 CN2 Actuator protective earth Actuator protective earth Ð ŧ Connector for resolver Connector for resolver Actuator U phase Actuator U phase ē ٢ Actuator V phase Actuator V phase υ ι Actuator W phase Ā (× Actuator W phase CN3 CN3 +24V for brake w +24V for brake I/O connector I/O connector вк Gland for brake Gland for brake 100V AC (50/60Hz) 200V AC (50/60Hz) Available for actuator up to Available for actuator up to 75 N⋅m torque 50 N⋅m torque CKD



Direct drive actuator GH/H type driver

Common specifications

| | Model | | | |
|--|--|----------------------------|--|--|
| Descriptions | H type driver AX9 * * * H | GH type driver AX9000GH | | |
| | 1.3-200V AC $\pm 10\%$ (standard) (Note 1) | | | |
| Device cumply valtere | 2.1-100V AC ±10% (J1: option) | 3-200V AC-10% | | |
| Power supply vollage | 3.220V AC -10% to 230V AC +10%, | to 230V AC +10% | | |
| | Three phase (J2: option) (Note 2) | | | |
| Power supply frequency | 50/60 Hz | | | |
| Configuration | Driver and controller integrated type (open frame) | | | |
| Ambient temperature range | 0 to 50 °C | | | |
| Ambient humidity range | 20 to 90%RH (to be no dew condensation.) | | | |
| Conservation ambient temperature range | -20 to 80 °C | | | |
| Conservation ambient humidity range | 20 to 90%RH (to be no dew condensation.) | | | |
| Atmosphere | To be no corrosive gas and powder dust. | | | |
| Noise-resistance | 1000V (P-P), pulse amplitude 1 micron sec. and start up 1nsec. | | | |
| Vibration resistance | 1.ce 4.9m/s ² | | | |
| Mass Approximate 4kg | | | | |

(Note 1) The models with maximum torque 50 N·m or less can be used for single phase 200V AC (standard) and 230V (option).

(Note 2) "J2" option for CE marking is available for 200V AC -10% to 230V AC+10%.

Power supply wattage/breaker capacity GH type driver

| A - 4 | Driver model no. | Electric power supply capacity (KVA) | | Breaker capacity |
|--------------------|------------------|--------------------------------------|-------|-------------------|
| Actuator model no. | | Max. | Rated | Rated current (A) |
| AX4150G | | 3.0 | 0.8 | |
| AX4300G | AX9000GH | 4.0 | 1.5 | 20 |
| AX4500G | | 4.0 | 2.0 | |

H type driver

| A stuster model no | Driver model no. | Electric power supply capacity (KVA) | | Breaker capacity |
|-----------------------|---------------------|--------------------------------------|-------|-------------------|
| Actuator model no. | | Max. | Rated | Rated current (A) |
| AX * 006 | AX9006H | 0.8 | 0.5 | |
| AX * 009 and AX * 012 | AX9009H and AX9012H | 1.0 | 0.5 | |
| AX * 021 and AX * 022 | AX9021H and AX9022H | 1.0 | 0.5 | 10 |
| AX * 045 and AX * 042 | AX9045H and AX9042H | 1.5 | 0.5 | |
| AX * 070 and AX * 075 | AX9070H and AX9075H | 2.0 | 0.8 | |
| AX * 150 | AX9150H | 3.0 | 0.8 | |
| AX * 210 | AX9210H | 4.0 | 0.8 | 20 |
| AX * 300 | AX9300H | 4.0 | 1.5 | |
| AX * 500 | AX9500H | 4.0 | 2.0 | |

CN3 input signal

| Pin number | Signal name | Logic | Judgment |
|------------|---|----------|----------|
| 1 to 2 | External power input +24V ±10% | | |
| 3 to 4 | External power input GND | | |
| 5 | Program number selection input (bit 0) | Positive | Level |
| 6 | Program number selection input (bit 1) | Positive | Level |
| 7 | Program number selection input (bit 2) | Positive | Level |
| 8 | Program number selection input (bit 3) | Positive | Level |
| 9 | Program number selection input (bit 4) | Positive | Level |
| | /program number setting input 2nd digit | | Edge |
| 10 | Program number setting input 1st digit | Positive | Edge |
| 11 | Reset input | Positive | Edge |
| 12 | Return to origin command input | Positive | Edge |
| 13 | Start input | Positive | Edge |
| 14 | Program stop input | Positive | Edge |
| 15 | Continuous rotation stop input | Positive | Edge |
| 16 | Answer input | Positive | Edge |
| 17 | Emergency stop input | Negative | Level |
| 18 | Brake release input | Positive | Level |

CN3 pulse string input signal

| • · · • | p |
|------------|---------------------|
| Pin number | Signal name |
| 19 | PULSE/UP/A phase |
| 20 | -PULSE/-UP/-A phase |
| 21 | DIR/DOWN/B phase |
| 22 | -DIR/-DOWN/-B phase |
| 59 | CKD |

Performance specifications

| Descriptions | Content | |
|-----------------------------|--|--|
| Number of control axis | 1 axis and 540672 pulse/turn (name: A axis) | |
| Angle input increment | °(degree), pulse and index number | |
| Angle least input increment | 0.001° and pulse | |
| Speed input increment | Second and rpm | |
| Croad actting range | 0.01 to 100 sec./0.01 to 100rpm | |
| Speed setting range | (Note) Maximum rotational speed may vary per actuator connected. | |
| Equal index number | 1 to 255 | |
| Maximum command value | 7 digits input ±9999999 | |
| Timer | 0.01 to 99.99 sec. | |
| Programming language | NC language | |
| Drogromming method | Data is set up by dialog terminal or PC, etc., | |
| Programming method | through a RS232C port. | |
| Operation mode | Automatic, MDI, jog, single block, servo OFF, | |
| Operation mode | pulse row input mode | |
| Coordinates | Absolute and incremental | |
| | <5 types > | |
| Acceleration curve | Modified sine (MS), deformation constant velocity (MC/MC2), | |
| | modified trapezoidal (MT) and tropecoid (TR) | |
| Status display | Power supply display by LED | |
| Operating indication | Display by 7-segment LED | |
| Communication interface | RS-232C conformed | |
| | <input/> | |
| | Return to origin command, reset, start, stop, continuous rotation stop, | |
| | emergency stop, answer, program number selection, brake release, program | |
| I/O signal | number setting and pulse string input | |
| - | <output></output> | |
| | Alarm 1/2, positioning complete, in-position, start input waiting, M code 8 | |
| | points, 1/2 during indexing, timing, M code strobing and index position strobing | |
| Program capacity | Approximate 6000 characters (256 programs) | |
| Electronic thermal | Overheat protection for actuator | |

CN3 output signal

| Pin number | Signal name | Logic |
|------------|--------------------------------|----------|
| 33 | M code output (bit 0) | Positive |
| 34 | M code output (bit 1) | Positive |
| 35 | M code output (bit 2) | Positive |
| 36 | M code output (bit 3) | Positive |
| 37 | M code output (bit 4) | Positive |
| 38 | M code output (bit 5) | Positive |
| 39 | M code output (bit 6) | Positive |
| 40 | M code output (bit 7) | Positive |
| 41 | In-position output | Positive |
| 42 | Positioning complete output | Positive |
| 43 | Start input waiting output | Positive |
| 44 | Alarm output 1 | Negative |
| 45 | Alarm output 2 | Negative |
| 46 | Output during indexing 1 | Positive |
| 47 | Output during indexing 2 | Positive |
| 48 | Output of time | Positive |
| 49 | Index position strobing output | Positive |
| 50 | M code strobing output | Positive |

GH/H type driver

Dimensions, etc.

CN3 I/O circuit specifications



_

• H type driver (with controller)



Panel explanation Note) GH and H type drivers have different front panel designs.

• H type driver (with controller)



 $100V \ AC \ (50/60Hz) \\ \left(\begin{array}{c} \text{Available for actuator up to} \\ 50 \ N \cdot m \ torque \end{array} \right)$

CKD

S H type driver

CE marking products dimensions

• S type driver (-K)



Note) Fix ground cable with setscrew for ground cable (M4).

• H type driver (-K)





220

Note) Fix ground cable with setscrew for ground cable (M4).

A Precautions

CKD

• When piping, care must be taken to make foreign materials such as electric wire tips, etc., not intruded.

• When using the product in the environment where dust and lamp black, etc., will admit into the driver, consult with CKD.

| |
|------|
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |



Direct drive motor dialog terminal **AX0170H Series**

S type/H/GS/GH type driver common

Features

- (1) Easy programming A program can be easily produced only by answering questions asked by dialog terminal for equal index program.
- ② Dedicating power supply not required Power is supplied from a direct drive actuator.
- ③ Back up possible A program/parameter can be held to make a copy of the program.
- (4) Reducing EI (environmental impact) chemical substance Lead free solder is used. (Excluding parts such as semiconductor, etc.)

Specifications

| Descriptions | AX0170H | |
|--|---|--|
| Operation mode | Each mode; editing, display, parameter, operation and copy | |
| Program capacity | Equal index or NC program 2000 characters (1program) | |
| Program number | Equal index program: program number 0 to 999 | |
| Display | 16 characters X 2 line (LCD display) | |
| Input kov | 17 keys | |
| приткеу | (Emergency stop key: 1, control key: 5 characters and numeral keys: 11) | |
| Back up | Super capacitor (approximate 3 hours) | |
| Power supply | Supply from direct drive motor driver | |
| Cable length | 2m | |
| Ambient temperature range | 0 to 50 °C | |
| Ambient humidity range | 20 to 90% (to be no dew condensation.) | |
| Conservation ambient temperature range | -20 to 80 °C | |
| Conservation ambient humidity range | 20 to 90% (to be no dew condensation.) | |
| Mass | Body only approximate 140g | |

Cable length 2m

*English version has English characters and display messages on the operation panel.

Note) For S, H, GS and GH type driver, AX0170H must be used.

AX0162 and AX0165 can not be used.

Dimensions

Dialog terminal



AX0170H Series

Interactive terminal

Interactive terminal

Г

| Γ | Edit mode | Program editing Interactive equal index programming or operation programming by NC code will be done. Only single edited program is conserved. (Memory back up time 3 hours). In addition to an equal index program, the parameter editing required for an operation can be done. A NC program input allows up to 2000 characters. Also, 12 sample programs are available to allow the editing based on the sample program. |
|-------------------|----------------|--|
| | - Display mode | Display of I/O condition and current position Input/output state of input/output signal CN3 of direct drive actuator driver, present motor position and alarm states, etc., are displayed. |
| Operation mode | Parameter mode | Setting of parameter Approximate 40 types of parameters can be referred and set up. |
| F | Operation mode | ■One-touch operation command Settings of start, stop of program, run per block, reset, number setting, input, run of MDI data, on, off of brake, on, off of servo, return to origin, JOG operation and offset value, etc., will be done. |
| L | Copy mode | Batch copy of program All programs stored in the direct drive actuator driver are stored another driver. |

| Interactive programming A program can be easily produced by inputting the following settings. | | In this case ··· | | |
|---|--|--|---|--|
| | | To try to move direct drive actuator | Edit mode Try the programs during adjustment, since 12 types of samples programs are stored. | |
| [Example of program inp | ulj | | | |
| New Return to origin position Return direction | programs no. [0 to 999] 1. Origin 2. Index 1. CW | To create a program of direct drive actuator and to store the program in the actuator | Edit mode Easy procedure to input and store programs. | |
| | 2. CCW | | | |
| Return speed Index number Moving time Rotational direction | [1.0 to 100.0]rpm [1 to 255] [0.01 to 100] second 1. CW | To run a program stored in the direct drive actuator. | Dperation mode Indication of a program number allows the program to start easily. | |
| Stop treatment | 2. CCW 1. Start waiting 2. Dwell | To achieve the best | Parameter mode | |
| Brake | 1. Use 2. Vacant | curve. | 4 types of cam curve can be selected. The best curve can be used with one-touch | |
| Delay timer | [0.01 to 99.99] second | | operation. | |
| M code | 1. M 2. Index position | To restrict the torque to protect other equipment. | Parameter mode Any torque can be set if the torque is not greater than maximum output torque. It is effective to prevent interference of other equipment. | |

Option

CKD



Serial transmission slave station CC-Link AX-OPX-7G

Features

- Connecting to the I/O connector (CN3) of S or H type driver, a direct drive actuator can be connected to field network CC-Link system (Ver. 1. 10) such as MITSUBISHI PLC, MELSEC-A and QnA series, etc.
- Drastic reduced wiring is possible.
- I/O point
- 16 inputs and 14 outputs
- Using HLD/CLR switch, either holding of output when communication failed, or all points OFF can be selected.
- 5 types of line speed can be selected.
- External emergency stop input (b contact) can be connected in series to emergency stop signal in serial communication.

How to order



Accessory (plug)

- 1) BLZ5.08/5FAU (Widemuller) 1 piece
- 2) BL3.5/2F (Widemuller) 2 pieces
- 3) ZHR-6 (JST MFG CO. LTD.) 1 piece

Note: When using emergency stop input from out side, or when activating by pulse row from external pulse generator, specify model no. of options.

Common specifications

| Descriptions | Specifications |
|---------------------------|--|
| Slave unit power supply | 24V DC $\pm 10\%$ and 100mA or less |
| AX driver power supply | 24V DC +10%, -5% and 450mA or less |
| Ambient temperature range | 5 to 50 °C |
| Ambient humidity range | 30 to 85%RH (to be no dew condensation.) |
| Atmosphere | To be no corrosive gas and dust. |
| Vibration resistance | 4.9m/s ² |
| Mass | 0.15kg |

Performance specifications

| Descriptions | Specifications |
|------------------------|--|
| Network protocol | CC-Link system (Ver1.10) conformed |
| Line speed | 156K/625K/2.5M/5M/10M bps |
| Line speed | (Selection by switch) |
| Output no. | 14 points |
| Input no. | 16 points |
| Other input | Pulse row and emergency stop |
| Output insulation type | Photo coupler insulation |
| Operating indication | LED (display of slave unit power supply and communication state) |
| Occupied unit no. | 1 station (remote I/O station) |
| Sotting switch | Station no. line speed, HLD/CLR and |
| | terminal ON/OFF |







Serial transmission slave station DeviceNet **AX-OPX-7D**

Features

- Installing onto the I/O connector (CN3) of S or H type driver allows a direct drive actuator to be compatible with DeviceNet.
- Drastic reduced wiring is possible.
- ●I/O point
- 16 inputs and 14 outputs
- Using HLD/CLR switch, either holding of output when communication failed, or all points OFF can be selected.
- 3 types of line speed can be selected.
- External emergency stop input (b contact) can be connected in series to emergency stop signal in serial communication.
- ●CE marking

How to order



Accessory (plug)

- 1) MSTB2.5/5-STF-5.08AUDVM (Phoenix contact) 1 piece
- 2) BL3.5/2F (Widemuller) 2 pieces
- 3) ZHR-6 (JST MFG CO. LTD.) 1 pieces
- Note: When using emergency stop input from out side, or when activating by pulse string from external pulse generator, specify model no. of options.

Common specifications

| Descriptions | Specifications |
|----------------------------|---|
| Slave unit power supply | 24V DC \pm 10% and 100mA or less |
| AX driver power supply | 24V DC +10%, -5% and 450mA or less |
| Communication power supply | 11V to 25V DC 50mA or less |
| Ambient temperature range | 5 to 50 °C |
| Ambient humidity range | 30 to 85%RH(To be no dew condensation.) |
| Atmosphere | To be no corrosive gas and dust. |
| Vibration resistance | 4.9m/s ² |
| Mass | 0.15kg |

Performance specifications

| Descriptions | Specifications |
|------------------------|---|
| Network protocol | Device Net conformed |
| Communication speed | 125k/250k/500k bps |
| | (Selection by switch) |
| Output no. | 14 points |
| Input no. | 16 points |
| Other input | Pulse string and emergency stop |
| Output insulation type | Photo coupler insulation |
| Operating indication | LED (display of power supply and communication state) |
| Occupied byte number | Input: 2 bytes and output: 2 bytes |
| Sotting switch | Output mode (HLD/CLR) |
| Setting Switch | Node address, communication speed |

Setscrew (top and bottom 2 places)





CKD

Slave station - AX driver input/output signal table

| input/o | uipui signai | | | |
|---------|-------------------------|--|-------------------------|---|
| Bit | AX CN3 Pin number | Slave station input signal name (AX output→ slave unit input) | AX CN3 Pin number | Slave unit output signal name (Slave unit output→ AX input) |
| 0 | 33 | M code output (bit 0) | 5 | Program number selection input (bit 0) |
| 1 | 34 | M code output (bit 1) | 6 | Program number selection input (bit 1) |
| 2 | 35 | M code output (bit 2) | 7 | Program number selection input (bit 2) |
| 3 | 36 | M code output (bit 3) | 8 | Program number selection input (bit 3) |
| 4 | 37 | M code output (bit 4) | 9 | Program number selection input (bit 4) /program number setting input 2nd digit |
| 5 | 38 | M code output (bit 5) | 10 | Program number setting input 1st digit |
| 6 | 41 | Positioning complete output | 11 | Reset input |
| 7 | 42 | Positioning complete output | 12 | Return to origin command |
| 8 | 43 | Start input waiting output | 13 | Start input |
| 9 | 44 | Alarm output 1 | 14 | Program stop input |
| А | 45 | Alarm output 2 | 15 | Continuous rotation stop input |
| В | 46 | Output during indexing 1 | 16 | Answer input |
| С | 47 | Output during indexing 2 | 17 | Emergency stop input |
| D | 48 | Output of time | 18 | Brake release input |
| E | 49 | Index position strobing output | | Vacant |
| F | 50 | M code strobing output | | Vacant |

Input/output signal

Note: M code outputs (bit 6 and 7) of AX driver can not be used.

Slave station input signal is bit 0 to F, and slave station output signal is bit 10 to 1F for AX-OPX-7G.

Dimensions (CC-Link and DeviceNet common)

•AX-OPX-7G

●AX-OPX-7D



Connector section dimension







Slave station installation (for S type driver)



Installation dimensions (for S type driver)



Note: Dimension in () is applied to H type driver.

Cautions for installation

- Depth of slave station is 68mm, while depth of plug is 16.5mm. The plug can be removed, while lead wire is connected.
- Fix a slave station on the driver with setscrews.

S type driver installation



AX-OPX Series

Connections



*Refer to the following transmission I/F connector section for connection of communication line.

Transmission I/F connector (for installation on S type)



*When connecting to H type driver, care must be taken since connector direction is reverse.



AX-OPX series Connection/cautions

Connection of connector for pulse row input (option)



When connecting the cable for pulse row input (option), use a precise screwdriver with narrow tip (-), etc., to remove the short connector, then match the notches on male and female side to insert the connector.

(Do not pull the jumper line for short connector to remove the connector.)

Precautions

- Always read [precautions] of the instruction manual before using.
- Read the instruction manual for the communication system in use and thoroughly familiarize yourself with contents before starting use.
- Do not install the product at the place where water, moisture, duct or lamp black will be formed, or fire, failure or electric shock, etc., may be caused.
- If the slave station switch is set incorrectly, the direct drive actuator could malfunction. Carefully confirm switch settings before starting use. Check the slave station number, transmission speed, and output settings at a communication error when turning power on.
- When wiring, always turn power off before starting work.
- When connected to the connector, the cable could move back instead of the connector tightening, so be sure to loosen the cable fixing screw sufficiently.
- If a connector fixing screw is provided, tighten it when inserting the connector. If the screw is not tightened, the connector come loose and cause malfunctions. If a connector fixing screw is not provided, confirm that connector hooks are secure.
- Maintain sufficient bending radius for the interface cable, and do not bend the cable forcibly.
- Disconnecting the slave station by pulling on the cable or connector could cause wire breakage or damage. Hold the slave station itself when removing it.
- If electric wiring terminal section (bare live part) is touched, a risk of electric shock may be created.
- M code outputs (bit 6 and 7) of AX driver can not be used.

Installation

- Depth of slave station is 68mm, while plugs is 16.5mm. The plug can be removed, while wired.
- If installed on H type driver, the top and bottom direction of slave station is reverse. (Switch plane faces upward.)
- Fix a slave station on the driver with setscrews.

H type driver installation



Direct drive actuator related parts model no. table

Related parts

| Part name | Model | Model no. |
|---|-----------|---------------|
| PC communication cable (DOS/V) | AX series | AX-RS232C-9P |
| PC communication cable (old PC98) 14 pin half pitch | AX series | AX-RS232C-14P |
| PC communication cable (old PC98) D-sub25 pin | AX series | AX-RS232C-25P |

Maintenance part

| Part name | Model | Model no. |
|-------------------------|----------------------|-----------|
| Pneumatic valve (brake) | AX5000/AX8000 series | AX-0002 |
| Cooling fan | H type driver | AX-0003 |

Others

| Part name | Model | Model no. |
|-------------------------|---------------|----------------------|
| Slave unit option cable | AX-OPX series | AX-OPX-CABLE-D02 |
| I/O connector | AX series | AX-CONNECTOR-MR-50LM |

Noise filter

| Part name | Model | Model no. |
|--|------------------------------------|-------------------|
| Noise filter for power supply (three phase/10A) | AX series | AX-NSF-LF-310 |
| Noise filter for power supply (three phase/15A) | AX series | AX-NSF-LF-315 |
| Noise filter for power supply (single phase/10A) | AX series | AX-NSF-LF-210 |
| Noise filter for motor cable (10A) | AX series | AX-NSF-LF-310KA |
| Noise filter for motor cable (20A) | AX series | AX-NSF-LF-320KA |
| Noise filter for power supply | AX series (CE conforming products) | AX-NSF-NF2015A-OD |
| Ferrite core for motor cable | AX series (CE conforming products) | AX-NSF-RC5060 |

Mounting base

| Part name | Model | Model no. |
|---------------|--------------------|---------------------------------|
| Mounting base | AX series (Note 1) | AX-AX * * * * -BASE- * (Note 2) |

(Note 1) No mounting base is available for AX5000, AX8000 and AX4009 series. (Note 2) Consult with CKD for mounting base model no.

| | |
|------|--|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |



Selection guide

| Unit and symbol of elements of operating condition | | | | | |
|--|--|---------------------------------|--|--|--|
| Moving angle (°) ψ | | | | | |
| Moving time (s) | | t1 | | | |
| Cycle time (s) | | to | | | |
| Load friction torque (N·m) | | T _f | | | |
| Working torque (N·m) | | Tw | | | |
| Cam curve | | Selection from (MS, MC, MT, TR) | | | |

1. Load moment of inertia

Load moment of inertia is computed, then select an actuator that allows the moment temporarily.

2. rpm

Maximum rated input speed is 100rpm. If moving angle is ψ (°), and moving time is t₁ (s),

$$N_{max} = V_{m} \cdot \frac{\psi}{6 \cdot t_1}$$
 (rpm)

 $V_{\mbox{\scriptsize m}}$ is the constant defined by cam curve.

[Cautions]

Actual moving time is the time that the recovery time is added to the command moving time of direct drive actuator.



Recovery time may vary between 0.05 to 0.2s per working condition.

When selecting a model, the command moving time of direct drive actuator must be used for moving time t₁. The command moving time is also used for setting of moving time in NC program.

3. Load torque

a) Max. load torque is asked as the following formula.

$$T_{m} = [A_{m} \cdot (J + J_{M}) \cdot \frac{\psi \cdot \pi}{180 \cdot t^{2}} + T_{F} + T_{W}] \cdot fc + T_{M}$$

b) Effective value of load torque is asked as the following formula.

$$\mathsf{T}_{\mathsf{rms}} = \sqrt{\frac{\mathsf{t}_1}{\mathsf{to}}} \cdot [\mathsf{r} \cdot \mathsf{A}_{\mathsf{m}} \cdot (\mathsf{J} + \mathsf{J}_{\mathsf{M}}) \cdot \frac{\boldsymbol{\psi} \cdot \boldsymbol{\pi}}{180 \cdot \mathsf{h}^2} \cdot \mathsf{fc}]^2 + (\mathsf{T}_{\mathsf{F}} \cdot \mathsf{fc} + \mathsf{T}_{\mathsf{W}} \cdot \mathsf{fc} + \mathsf{T}_{\mathsf{MF}})^2$$

Where Vm, Am and r use values in the table below.

| Cam curve | Vm | Am | r | |
|-----------|------|------|-------|--|
| MS | 1.76 | 5.53 | 0.707 | |
| MC | 1.28 | 8.01 | 0.500 | |
| MT | 2.00 | 4.89 | 0.866 | |
| TR | 2.18 | 6.17 | 0.773 | |

Also, J_M, T_{MF} and f are as followings.

J_M: output shaft moment of inertia (kg·m²)

TMF: output shaft friction torque (N·m)

fc: usage factor (during normal use fc=1.5)

About the actuator chosen temporarily

Max. load torque < maximum output torque

Effective value < continuous output torque

if either condition is not satisfied, increase the actuator size, then re-calculate the load torque.

Note) In AX4300 and AX4500, torque speed characteristics are reduced, limiting usage zone. Check the condition by the selecting software if max. speed

is 50rpm and over.

4. Regenerative electric power (subject to AX4300 and AX4500 only)

In AX4300 and AX4500, regenerative electric power is limited by consumption performance of regenerative resistance in the driver.

To be asked by the following simple formula.

$$W = \left(\frac{V_{m} \cdot \psi \cdot \pi}{t_{1} \cdot 180}\right)^{2} \cdot \frac{(J+J_{M})}{2 \cdot t_{0}} (W)$$

If this conditions are not satisfied, review operating and load conditions.

(Note) working torque shows the torque, converted from external load, etc., that operates an output shaft of a direct drive actuator as a load.

Working torque TW is calculated by the following formula. $T_w=F_w X R_w (N \cdot m)$ $F_w (N)$: force required for work

R_w (m): working radius (Example) If the body is side faced (output shaft horizontal),

table, workpiece and jig, etc., will be working torques.





[MC2 curve] selection guide

MC2 curve is ···

MC2 curve, same as MC (deformed constant velocity) curve, has constant velocity section during movement. If acceleration or declaration time is set, the constant velocity section can be set flexibly. In MC (common name: MCV50) curve, constant velocity section is 50%.

Note. Acceleration or deceleration time setting is 1/2 of moving time or less. If acceleration or deceleration time setting reaches 1/2 of moving time, cam curve is changed to MS (modified sine) curve automatically.

Example diagram shows the speed patterns that a constant velocity section will be 75% by setting acceleration or deceleration time (t_a) : 0.5 sec. against moving time (t_1) : 4 sec.



Selection method

A model is selected by a MC2 curve with a following formula.

| Moving angle | :ψ(°) |
|------------------------------------|----------|
| Cycle time | : to (s) |
| Moving time | : t₁ (s) |
| Acceleration and deceleration time | : ta (s) |

Load moment of inertia: J $(kg \cdot m^2)$ Output shaft moment of inertia: J_M $(kg \cdot m^2)$ Friction torque: Tf $(N \cdot m)$ Working torque: Tw $(N \cdot m)$ Output shaft friction torque: T_{MF} $(N \cdot m)$

Maximum rotational speed: Nmax (rpm)

Nmax=
$$\frac{\psi}{6(t1-0.863ta)}$$

Load torque (largest value): Tm (N·m)



Load torque (effective value): Trms (N·m)

$$\text{Trms} = \sqrt{\frac{2\text{ta}}{\text{T}_0}} \cdot \left[3.91 \text{ (J+J_M)} \cdot \frac{\psi \cdot \left(1 - \frac{\text{t}_1 - 2\text{ta}}{\text{t}_1 - 0.863\text{ta}}\right) \cdot \pi}{720 \cdot \text{ta}^2} \cdot \text{fc} \right]^2 + \left[\text{ (Tf+Tw)} \cdot \text{fc} + \text{T}_{\text{MF}} \right]^2$$



[Continuous rotation] selection guide

Continuous rotation is ...

Continuous rotation has the following functions.

- Continuous rotation : Continuous rotation will be done with constant speed until continuous rotation stop signal be inputted.
 Equal index position stop : Stopped at equal index position by equal index continuous rotation stop input.
- 3. Output of time : Output of time is pulse-outputted during rotation using equal index indication.

to ti ta ta td td Continuous

Example diagram shows the speed pattern that is accelerated with acceleration time: ta until the set rotational speed: N, then stopped by continuous rotation stop input with deceleration time: td.

Selection method

In continuous rotation, a model is selected with a following formula.

| Rotational speed : N (rpm) | Load moment of inertia | : J (kg⋅m²) | |
|--------------------------------------|--|-------------|--|
| Cycle time : to (s) | Output shaft moment of inertia : J _M (kg⋅m² | | |
| Acceleration time : ta (s) | Friction torque | : Tf (N⋅m) | |
| Moderation time : td (s) | Working torque | : Tw (N⋅m) | |
| | Output shaft friction torque | : Tм⊧ (N⋅m) | |
| Maximum rotational speed: Nmax (rpm) | | | |

Nmax=N

Load torque (largest value): Tm (N·m)

$$\mathsf{Tm} = \left[5.53 \ (\mathsf{J} + \mathsf{J}_{\mathsf{M}}) \cdot \frac{6.82 \mathsf{N} \cdot \mathsf{ta} \cdot \pi}{720 \cdot \mathsf{ta}^2} + \mathsf{Tf} + \mathsf{Tw} \right] \cdot \mathsf{fc} + \mathsf{T}_{\mathsf{MF}}$$

Load torque (effective value): Trms (N·m)

$$Trms = \sqrt{\frac{2ta}{T_0}} \cdot \left[3.91 \ (J+J_M) \cdot \frac{6.82N \cdot ta \cdot \pi}{720 \cdot ta^2} \cdot fc \right]^2 + [\ (Tf+Tw) \cdot fc+T_{MF}]^2$$

The expression above is for ta \leq td. If for ta> td, swap ta to td, then select the product again.

Formula of moment of inertia

- A When center of rotation is its own axis.
- Center of rotation 1. Disc (cylinder) R $l=\frac{mR^2}{2}$
- 2. Hollow disc (hollow cylinder)



3. Direct hexagonal side finish body





For conveyer



- *m*₁: Chain mass
- *m*²: Workpiece total mass
- m3: Jig (pallet) total mass
- m4: Sprocket A (drive)+B total mass

R

 $l=(m_1+m_2+m_3+\frac{m_4}{2})\cdot R^2$

R : Drive side sprocket radius

77

CKD

| Direct drive actuator selection guide specifications check sheets Table direct drive | | | | |
|---|---|----------------|--|--|
| Your company name | | Your name | | |
| Department | | - | | |
| TEL | | FAX | | |
| | lione | | | |
| ■Operating condit | tor | | | |
| 1. Index 2. Oscilla Moving angle | ° | rindov numbo | | |
| Moving time t1 (|) | | | |
| $\frac{1}{2}$ | | Nolatima ma | ving time , dwall time | |
| (Note) Index time - | - moving time + recovery time | Sycle time =mo | | |
| Depending | on working conditions, recovery time may | varv between 0 | 0.05 and 0.20. | |
| | | | | |
| ■Load conditions | | | Dt Workpiece | |
| Table | | | Pallet jig | |
| Material 1 | . steel 2. aluminum | | | |
| Appearance D | Dt (mm) | : | | |
| Plate thickness h | it (mm) | | <mark>← Rf</mark> | |
| Mass n | n1 (kg) | | | |
| | | | | |
| Workpiece | | | /////////////////////////////////////// | |
| Quantity | nw (piece) | | (Fig. 1) load conditions | |
| Maximum mass | mw (kg/piece) | | | |
| Installation center | r Dp (mm) | | | |
| Dellet fixture | | | | |
| | | | | |
| Maximum mass in | nn (kg/niece) | | | |
| | | | | |
| Others | | | | |
| Installation attitude | | (Fig. 2) in | stallation attitude: horizontal (Fig. 3) installation attitude: vertical | |
| 1. Horizontal (Fig. 2) | 2. Vertical (Fig. 3) | | | |
| External work | | | | |
| 1. None | 2. Present | | | |
| (Note) Eccentric le | oad by gravity and outside load, etc., by | | | |
| caulking w | ork at vertical installation | | | |
| Dial plate support f | form bottom | | | |
| 1. None, | 2. Present | | | |
| Coefficient of friction | on μ | | \square | |
| Action radius | Rf (mm) | | | |
| | | | (Fig. 4) installation rigidity: low | |
| | 2 Low (Note) | | | |
| (Note) Using spline w | then direct fixing is not allowed on equipment (Fig. 4) | | | |
| or when there is | s mechanism such as chuck, etc., on the table. | | | |
| Extension by shaft | of table | | | |
| 1. None | 2. Present (Fig. 5) | | | |
| | | | | |
| iviovable of actuato | | | | |
| | | | | |
| (INOTE) When a ac | tuator is moved while the actuator is | | | |
| (Note) If 2 is selec | cted in any description consult with CKD | | (Fig. 5) extension by shaft | |
| | the arrang decemption, consult with OND. | (Note) Th | e drawings, etc., of equipment should be attached to select a | |
| | | mo | buei accurately. | |

| |
|------|
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |

JAPAN-NETWORK





CKD株式会社

●長岡営業所 〒940-0096 新潟県長岡市春日1-6-18(春日ハイツ1階)

北 陸・信 越

| 北海 | 道 | |
|---|---|--|
| ●札幌営業所 | 〒060-0032 | 札幌市中央区北2条東14-26(苗穂駅前ビル1階) |
| 東 | 北 | |
| ●北上営業所 ●仙台営業所 ●山形営業所 ●郡山営業所 | 〒024-0034 〒984-0015 〒990-0834 〒963-8034 | 岩手県北上市諏訪町2-4-26 仙台市若林区卸町2-2-1(パックス2・1階) 山形県山形市清住町2-6-24 福島県郡山市島1-16-9 |
| 北関 | 東 | |
| ◆大宮営業所 ◆茨城営業所 ●宇都宮営業所 ◆太田営業所 | 〒330-0812 〒300-0847 〒321-0953 〒373-0813 | さいたま市北区宮原町3-429-1(第一清水ビル2階) 茨城県土浦市卸町1-1-1(関鉄つくばビル4階C) 栃木県宇都宮市東宿郷3-1-9(USK東宿郷ビル3階) 群馬県太田市内ヶ島町946-2(大槻総合ビル1階) |
| 南関 | 東 | |
| ●東京営業所 ●立川営業所 ●千葉浜営業所 ●「東京営業所 ●東京 支店 | 〒101-0047 〒190-0022 〒260-0021 〒222-0033 〒243-0035 〒409-3867 〒101-0047 | 東京都千代田区内神田3-6-3 (CKD第ニビル) 東京都山市鎮町3-2-30 (朝日告金山)朝野ビル源) 千葉市中央区新宿2-5-19 (千葉南ビル3階) 横浜市港北区新横浜2-17-19 (日総第15ビル4階) 神奈川県厚木市愛甲1212-3 山梨県中巨摩郡昭和町清水新居1509 東京都千代田区内神田3-6-3 (CKD第ニビル) |

| ●上田宮集所 ●松本営業所 ●富山営業所 ●金沢営業所 | 〒399-0033 〒939-8064 〒920-0025 | 長野県 L 山市 入 子中 2 余22 6 (NF 2 ル 103 5) 長野県 松本市大字笹賀5945 富山県富山市赤田中町494-1 石川県金沢市駅西本町3-16-8 |
|--|---|---|
| 東 | 海 | |
| ●名古屋営業所 ●小牧営業所 ●豊田営業所 ●静岡営業所 ●四日市営業所 ●名古屋支店 | 〒450-0003 〒485-8551 〒473-0912 〒422-8035 〒435-0016 〒510-0064 〒450-0003 | 名古屋市中村区名駅南2-7-2(CKD第一ビル) 愛知県小牧市応時2-250 愛知県豊田市広田町広日103 静岡県静岡市宮竹1-3-5 静岡県浜松市和田町438 三重県四日市市新正5-3-20 名古屋市中村区名駅南2-7-2(CKD第一ビル) |
| 関 | 西 | |
| ◆大阪営業所 ◆北大阪営業所 ●東大阪営業所 | 〒542-0073 〒567-0828 〒577-0013 | 大阪市中央区日本橋1-17-17(三井住友銀行日本ービル) 大阪府茨木市舟木町5-16(柴田ビル3階) 大阪府東大阪市長田中5-2-29 |
| ● 堺 営 業 所 ● 滋賀党業 所 | 〒591-8021 〒520-2361 | 大阪府堺市新金岡町5-5-6(泉マンション1階) 滋賀県野洲野洲町北野1-19-20(三田ビル3階) |
| ●京都営業所 | 〒612-8414 | 京都市伏見区竹田段川原町35-3 |
| ● | T639-1123 T673-0016 | 余長県大和師山市同开町460-15(オッンエム・ロンナ1階) 兵庫県明石市松の内2-6-8(西明石スポットビル3階) |
| ● 大 阪 支 店 | 〒542-0073 | 大阪市中央区日本橋1-17-17(三井住友銀行日本ービル) |

| 中国 |
|---|
| ●広島営業所 〒734-0023 広島市南区東雲本町3-1-10 |
| ●岡山営業所 〒700-0916 岡山県岡山市西之町10-104 |
| ●山口営業所〒747-0034 山口県防府市天神2-2-2 |
| 四国 |
| ●高松営業所 〒760-0055 香川県高松市観光通2-2-15(ダイヤビル) |
| ●松山営業所 〒790-0921 愛媛県松山市福音寺町44-1(林マンション1階) |
| |
| 九州 |
| ●北九州営業所〒802-0976 北九州市小倉南区南方5-13-34 |
| ●福岡営業所 〒812-0006 福岡市博多区上牟田1-15-2 |
| ●大分営業所 〒871-0015 大分県中津市牛神町1-11-1 |
| ●熊本営業所 〒869-1103 熊本県菊池郡菊陽町久保田2698-1 |
| 本村 |
| ●本社·工場 〒485-8551 愛知県小牧市応時2-250 |
| TEL (0568) 77-1111 FAX (0568) 75-3715 |
| ● 営業本部 〒450-0003 名古屋市中村区名駅南2-7-2(CKD第一ビル) |
| TEL (052) 581-3741 FAX (052) 571-6905 |
| ●海外営業部 〒450-0003 名古屋市中村区名駅南2-7-2(CKD第一ビル) |

FFI名来記 1450-0003 石臣町中村区石駅(12-7-2(0KD第一27)) TEL(052)581-3751 FAX(052)583-9710

Home Page Address http://www.ckd.co.jp/





CKD Corporation

OVERSEAS DPT. SALES DIV. 2-7-2, Meieki-Minami, Nakamura-ku, Nagoya 450-0003, Japan PHONE+81-(0)52-581-3751 FAX+81-(0)52-583-9710

U.S.A

CKD USA CORPORATION

- HEADQUARTERS
- 4080 Winnetka Avenue, Rolling Meadows, IL 60008 USA CINCINNATI OFFICE
- 1420 Jamike Drive, Erlanger, KY 41018 USA
- AUSTIN OFFICE 8403 Cross Park Drive, Suite 3G, Austin, TX 78754, USA
- SAN JOSE OFFICE 48501 Warm Spring Boulevard, Suite 114, Fremont,
- CA 94539 USA

EUROPE

CK EUROPE BRANCH

De Fruittuinen 28 Hoofddorp 2132NZ The Netherlands

Malaysia

M-CKD PRECISION SDN.BHD.

- Lot No.6, Jalan Modal 23/2, Seksyen 23, Kawasan, MIEL, Fasa 8, 40300 Shah Alam, Selangor Darul Ehsan, Malaysia
- JOHOR BAHRU OFFICE 116&118 Jalan Rosmerah 2/17, Taman Johor Jaya, 81100 Johor Bahru, Malaysia
- MELAKA OFFICE
- No.B-10, Ground Floor, Bachang Permai, Jalan Tun Fatimah Batu Berendam 75350 Melaka, Malaysia
- PENANG OFFICE No.2678, Ground Floor, Jalan Chain Ferry, Taman Inderwasih, 13600 Prai, Penang, Malaysia

Thailand

CKD SALES THAI CORPORATION LTD.

- HEADQUARTERS
 - Suwan Tower, 14/1 Soi Saladaeng 1, North Sathorn Rd., Bangrak, Bangkok 10500 Thailand

- LAEMCHABANG OFFICE
 - 53/67, 69 Moo 9, Tungsukla, Sriracha, Chonburi 20230 Thailand
 - NAVANAKORN OFFICE
 - 176/4-6, Moo 13, Paholyothin Rd., Klongneung, Klongluang, Prathumthani 12120 Thailand
 RAYONG OFFICE
 - 125/32 M.Charoen Nakorn, T.Maptapud, Rayong 21150, Thailand
 - LAMPHUN OFFICE 133 Moo 4, Banklang Muang, Lamphun, 51000, Thailand

Singapore

CKD SINGAPORE PTE LTD

705 Sims Drive #03-01/02, Shun Li Industrial Complex, 387384 Singapore

Taiwan

台湾旭開理股份有限公司

TAIWAN CKD CORPORATION 中華民国台湾省新竹県竹北市泰和路176號

No.176 Taiho Rd. Chupei-City, Hsinchu Taiwan R.O.C

China

- 喜開理(上海)機器有限公司 CKD (SHANGHAI) CORPORATION
- 営業部/上海事務所 (SALES HEADQUARTERS / SHANGHAI OFFICE) 中国上海市浦東新区張楊路188号 湯臣商務中心3楼304室 Room 304, 3'rd Floor, Tomson Business Center, No.188, ZhangYang Road, PuDong, ShangHai, 200120, China
- 北京事務所(BEIJING OFFICE)
 中国北京市復興路戊12号 恩菲科技大廈1015室
 En-Fei-Ke-Ji Bdg. Room #1015, Fu-xing-Lu-Wu 12,

Beijing,100038, China ● 天津事務所 (TIANJIN OFFICE)

中国天津市南開区白堤路148号 Bai-Di-Lu, 148, Nankai-Qu, Tianjin, 300193, China

Home Page Address http://www.ckd.co.jp/

● 無錫事務所 (WUXI OFFICE)

- 中国江蘇省無錫市中山路389号吟春大廈1708室 Room 1708, Yin-Chun Bdg., Zhongshan Road No.389, Wuxi, Jiangsu Province, 214001,China
- 南京事務所 (NANJING OFFICE)
 中国南京市山西路57号杰源山西路商務中心502室
 Room 502, Jieyuan Shanxi Road Business Center
 No.57, Shanxi Road, Nanjing, 210009, China
- 重慶事務所 (CHONGQING OFFICE) 申国重慶市石橋舗楡洲路8号秦興科技広場1634号 Taixing Keji Square Room 1634, Yuzhou Road No. 8
- Shiqiaopu, ChongQing, 400039, China
 成都事務所 (CHENGDU OFFICE)
 中国四川省成都市西王龍街210号成都外貿大廈22楼2207号
 Chengdu Waimao Bdg. 22F, Room #2207, Xi-Yu-Long-Jie 210, Chengdu city, Sichuan Prov., 610015, China
- 西安事務所 (XIAN OFFICE)
 中国陝西省西安市労働南路296号西北民航大廈610号
 Xi-bei-min-hang Bldg. Room #610, Lao-dong-nan-lu
 296, Xian city, Shangxi Prov., 710082, China
- 大連事務所 (DALIAN OFFICE) 中国遼寧省大連市西崗区新開路99号大連珠江国際大廈808室 DaLian ZhuJiang GuoJi-Bld. Room #808, XinKai-Lu 99, DaLian city, LiaoNing Province, 116011, China
- 長春事務所(CHANG CHUN OFFICE) 中国吉林省長春市長春一汽越野路16号単元4楼中門16-1 16-1Dan Yuan 4-Lou Zhong Men, 16, Chang Chun Yi Qi Yue Ye Lu, Chang Chun City, JiLin Province, 130011, China

Korea

CKD KOREA CORPORATION

Room No.1105, 11th FL, The Korea Teachers Pention B/L. 27-2, Yoido-Dong, Youngdeungpo-Gu, Seoul, 150-742, Korea